

## **PROGRAMMING ADDITIONAL REMOTES REQUIRE AT LEAST ALREADY PROGRAMMED REMOTE**

### **Programming Instructions:**

- 1) Ensure the vehicle is off and not running.
- 2) Have both the old and new remote available.
- 3) Insert the key into the lock found outside on the drivers outer door.
- 4) Turn the key to the unlock position five times within 5 seconds.
- 5) The (DIC) Driver Information Center displays Ready to Learn Electronic key #2,#3 or #4.
- 6) Place the new remote into the transmitter pocket with the buttons facing the front of the vehicle. (The transmitter pocket is inside the center console between the driver and front passenger seats).
- 7) A beep sounds once the remote is programmed. The DIC displays ready to learn electronic key #3 or 4 or maximum # electronic keys learned.
- 8) Press the ignition control knob to exit the programming mode.
- 9) Remove the remote from the transmitter pocket and press unlock to the remote two times.
- 10) To program any additional remotes, repeat steps 6 through 9.

### **FCC WARNING**

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

### **IC WARNING**

FVIN 6313743IC

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1) This device may not cause interference. 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs sans licence qui sont conformes aux RSS exempts de licence d'Innovation, Sciences et Développement économique Canada. Son fonctionnement est soumis aux deux conditions suivantes: 1) Cet appareil ne doit pas provoquer d'interférences. 2) Cet appareil doit accepter toute interférence, y compris les interférences pouvant entraîner un fonctionnement indésirable de l'appareil.