

User's Manual

Light Bulb Speaker

HT1087A

In order to make sure you get the best possible results from your new Light bulb speaker, please thoroughly read and carefully follow all instructions in this User's Manual or on the product. Keep this User's Manual in a convenient location for future reference.

Package contents

- Light bulb speaker x 1
- User's Manual x 1

If any of these were missing or damaged, please visit bemwireless.com to obtain replacement.

Important safety instructions

- 1. Read these instructions** – All the safety and operating instructions should be read before this product is operated.
- 2. Keep these instructions** – The safety and operating instructions should be retained for future reference.
- 3. Heed all warnings** – All warnings on the appliance and in the operating instructions should be adhered to.
- 4. Follow all instructions** – All operating and use instructions should be followed.
- 5. Do not use this apparatus near water** – The appliance should not be used near water or moisture – for example, in a wet basement or near a swimming pool.
6. Clean only with dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacture's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding plug. A polarized plug has two blades with one wider than the other. A grounding plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at the plugs, convenience receptacles, and at the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart or rack is used, use caution when moving the cart/ apparatus combination to avoid injury from tip-over.
13. Unplug the apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. Please keep the unit in a well-ventilated environment.
- 16. WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
- 17. WARNING:** The appliance coupler is used as disconnect device, the disconnect device shall remain readily operable.






This lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of non-insulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance instructions in the literature accompanying the appliance.

Meet the Light Bulb Speaker

Before learning your Light bulb speaker, take a moment to look it over and familiarize yourself with its features.



- The Light bulb speaker comes with standard E27 connector that works with most light base
- Bluetooth enhanced , compatible with any Bluetooth player under different OS , like smartphone tablet
- Eco friendly with LED technology, long working life, save energy.

Replace the light bulb

1. Turn off the power supply of your light socket where you want to install the light bulb speaker;
2. Install the light bulb speaker into the base by rotating it, like replace a normal E27 light bulb

Noted:

- (1) Make sure you turn off the power supply of the light socket before install the product;
- (2) Make sure you hand is dry;

(3) Please do not touch the light bulb when it still hot.

Pair with your mobile phone

First time pairing

Turn on the Light bulb speaker by turn the on/off switch of the light socket to “on”, and the Light bulb speaker will lights up with a beep.

Activate Bluetooth on your mobile phone and select “Light bulb speaker”.

After paired for the first time, the Light bulb speaker can pair to your mobile phone automatically when it is on.

Trouble shooting

No connection:

- Make sure the Bluetooth connection of your mobile phone is on;
- Make sure the speaker is on;
- The working range of the Bluetooth is about 8 meters w/o block, try closer;
- Pair the speaker again.

Maintenance

Cleaning the Case:

To clean the case, first unplug the power. To remove dirt or dust, wipe the casing with a soft, dry, lint-free cloth. To remove stubborn dirt or stains, moisten a soft cloth with water and a neutral detergent and then wipe the casing.

Do not use alcohol, benzene, thinners or other chemical detergents as these can cause the casing to be warped or discolored.

Storage

Always power off the Light bulb speaker when you finish using it.

If the unit will not be used for an extended period, be sure to follow these guidelines:

Do not store the unit in a damp environment

- Avoid exposing the unit to very high or low temperatures
- Avoid prolonged exposure to direct sunlight.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

IC Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device."

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement."

Cet équipement doit être installé et utilisé à une distance minimale de 20 cm entre le radiateur et votre corps.

CE 2200