


User's Manual for RC Jumper with Lighted Wheels

For Ages 8+

FEATURE

Transmitter

- Channel : 1
- Battery: 9V battery




Transmitter


1. Aerial
2. Jump Button
3. Indicator
4. Run Lever

Car

- Can perform various stunts the most exciting one of which is jumping. Jumping height is remarkable when battery power is sufficient.
- Uses 7.2V rechargeable batter pack



5. Power Switch
6. 9V Battery
7. Battery Cover



Car


8. Front Wheel
9. Power Switch
10. Tail wheel

CHARGING

1. Plug the charger to an indoor 110V AC power socket.
2. Plug the outlet line of the charger to the charging jack of the 7.2V battery pack outlet line.
3. Optimum charging time is 6 hours.

CAUTIONS:


1. Charge only with our included in the toy set charger. charging with other unspecified chargers may cause damages to the circuits in the car.
2. Do not charge for too long.(6 hours is sufficient for charging. overcharging may shorten battery's useful life or may even totally destroy the battery.)



7.2V rechargeable battery pack.

SAFETY CAUTIONS


- Never give this toy to children under 8.
- After the power of this car is turned on . Keep your fingers, hair, and clothes away from the wheels to avoid accidental damages.
- Do not try to catch the car by hand while it is in action.
- Keep the transmitter and the car away from any heat sources, such as electric stove, gas stove, or strong sunlight.
- Do not play with it in a dangerous place, such as on a road or on a slope.
- Do not wet the car. Do not play with it outdoors in a rainy day.
- Do not play with it on thr sands.
- Avoid bumping into any other articles, such as other people or glass, when playing.
- Do not allow children to disassemble the trasmitter or the car by themselves.
- If the car is broken during use, it should be checked by adult or repaired, when necessary, by professional technician before it can be reused.



OPERATIONS

1. Fully extend the aerial on the transmitter.
2. Set the power switches underneath the transmitter and the chassis to on.
3. Use the control levers on the transmitter to control the car to run or perform various stunts. The most exciting stunt is jumping .


1. Advance (high speed! be careful not to run into people!)



2. High speed headstand spin.




3. High speed spin




4. Sharp forward turn




5. Sharp backward turn



6. Jumping



7. Control the car that has fallen over to restore standing pose (on left front wheel)



8. Control the car that has fallen over to restore standing pose (on right front wheel)



- NOTES: 1. Make sure the power switch underneath the car turned off after use. Otherwise power of the batteries in the car may be soon consumed.
2. If the car cannot run at high speed or jump high enough, or cannot restore normal pose after falling over, it means the battery power has become insufficient, charge the batteries or replace with new ones.

Battery Information

1. The charger is not a toy.
Charging should be carried out by an adult.
Don't give it to children for playing.
2. Batteries should be installed and replaced only by an adult.
3. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
4. Do not mix old and new batteries.
5. Do not use rechargeable batteries.
6. Remove exhausted batteries from the unit.
7. Do not short circuit battery terminals.
8. Remove batteries and store them in a cool, dry place when not in use.
9. To avoid explosion or leakage, do not dispose of batteries in a fire or attempt to recharge alkaline or other non-chargeable batteries.
10. Only batteries of the same type and equivalency.

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



WARNING:

CHOKING HAZARD - Small parts.
Not for children under 3 years.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Model No. EI-YR09231B / EI-YR09231 R

90-DAY LIMITED WARRANTY

EXCALIBUR ELECTRONICS, INC., warrants to the original consumer that its products are free from any electrical or mechanical defects for a period of 90 DAYS from the date of purchase. If any such defect is discovered within the warranty period, EXCALIBUR ELECTRONICS, INC., will repair or replace the unit free of charge upon receipt of the unit, shipped postage prepaid and insured to the factory address shown below.

The warranty covers normal consumer use and does not cover damage that occurs in shipment or failure that results from alterations, accident, misuse, abuse, neglect, wear and tear, inadequate maintenance, commercial use, or unreasonable use of the unit. Removal of the top panel voids all warranties. This warranty does not cover cost of repairs made or attempted outside of the factory.

Any applicable implied warranties, including warranties of merchantability and fitness, are hereby limited to 90 DAYS from the date of purchase. Consequential or incidental damages resulting from a breach of any applicable express or implied warranties are hereby excluded. Some states do not allow limitations on the duration of LIMITED 90-DAY WARRANTY implied warranties and do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions in these instances may not apply.

The only authorized service center in the United States is:
Excalibur Electronics, Inc.

13755 SW 119th Ave
Miami, Florida 33186 U.S.A.
Phone: 305.477.8080
Fax: 305.477.9516

www.ExcaliburElectronics.com

Ship the unit carefully packed, preferably in the original carton, and send it prepaid, and adequately insured. Include a letter, detailing the complaint and including your daytime telephone number, inside the shipping carton. If your warranty has expired and you want an estimated fee for service, write to the above address, specifying the model and the problem.

NOTE: Please do not send your unit without first receiving an estimate for servicing from EXCALIBUR ELECTRONICS, INC. Contact us before sending your unit. We cannot store your unit!

Excalibur Electronics, Inc. reserves the right to make technical changes without notice in the interest of progress.