



ECHO  
TECH

2.4  
GHz  
FOR MULTI-RACER ACTION

RC SPHERE CYCLE

ECHO  
TECH

RC SPHERE CYCLE

RADIO CONTROLLED STUNT VEHICLE

2.4  
GHz  
FOR MULTI-RACER ACTION

37612 12w 6.5h 7.5d

+PVC

ECHO  
TECH

2.4  
GHz  
FOR MULTI-RACER ACTION

ECHO  
TECH

ECHO  
TECH

2.4  
GHz  
FOR MULTI-RACER ACTION




RC SPHERE CYCLE  
RADIO CONTROLLED STUNT VEHICLE

AGES  
8+

RC SPHERE CYCLE  
RADIO CONTROLLED STUNT VEHICLE



RC SPHERE CYCLE  
RADIO CONTROLLED STUNT VEHICLE




#### Battery Warnings:


Important! Only adults should replace batteries.  
Non-rechargeable batteries are not to be recharged.  
Rechargeable batteries are only to be charged under adult supervision.  
Rechargeable batteries are to be removed from the toy before being charged.  
Different types of batteries or new and used batteries are not to be mixed.  
Batteries are to be inserted with the correct polarity.  
Exhausted batteries are to be removed from the toy.  
The supply terminals are not to be short-circuited.  
Alkaline batteries are recommended.  
Do not mix old and new batteries.  
Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.  
Please keep this information for future reference.  
Remove batteries from the product before extended storage.

#### Battery Installation

The Sphere Cycle requires 5 "AA" 1.5V (not included) alkaline batteries for the vehicle and one 9V battery for the transmitter (not included).



1. Turn "ON/OFF" switch to the OFF position for the Sphere Cycle.
2. Open the battery compartment cover by loosening the screw and insert AA batteries following the correct polarity (Fig. 2).
3. Replace the battery compartment cover and tighten the screw (Fig. 3).



1. Turn "ON/OFF" switch to the OFF position for the transmitter.
  2. Open the battery compartment cover by loosening the screw (Fig. 4) and insert a 9V battery inside following the correct polarities (Fig. 5).
  3. Replace the battery compartment cover and tighten the screw (Fig. 6).
- Note: 1) When replacing Sphere Cycle battery, use alkaline battery only.  
2) If the Sphere Cycle slows down during play, this may indicate low battery power, therefore it would be necessary to replace new batteries.

#### Precautions and Care



#### FCC Statement

This device complies with Part 15 of the FCC Rules.  
Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.  
WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment.  
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
- Reorient or relocate the receiving antenna.  
- Increase the separation between the equipment and receiver.  
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
- Consult the dealer or an experienced radio/TV technician for help.



17017AY



