

Bluetooth Speaker

Model Name: LBT-SPP11


FCC ID : YWO-LBT-SPP11

Introduction

Thank you for purchasing our Bluetooth speaker.

The Bluetooth Speaker is a high quality wireless audio device that provides users the freedom to share music and calls whenever you want. It functions as " wireless Bluetooth speaker " when linked to Bluetooth phones or Bluetooth PC.

Overview The Speaker contains the following parts as show in the figure:



Operation:

1>Turn on: When the LBT-SPP11 is in the off state, switch the On/Off Button to "ON" and then you can find the LED flashes with blue light, also with a reminder voice.

2>Turn off: When the LBT-SPP11 is in the on state, switch the On/Off Button to "OFF" and then you can find the LED flashes with red light, also with a reminder voice.

3> Prepare your LBT-SPP11 for pairing: When the LBT-SPP11 is in the ON state, then press the MFB buttons for about 6 seconds until the blue and red light flash alternatively. The Headset is now in the pairing mode.

4>Answer call: Short Press the MFB.

5>End a call: short press MFB once

6> Voice transfer: In calling state, press and hold the MFB for about 3 seconds until there is beep sound from the speaker. The call will be transferred from headset to mobile or vice versa.

Specifications:

* Bluetooth Specification V3.0 system

* Bluetooth® Profile Supported: Support Headset and Hand free profile, Support A2DP

* RF Frequency Range: 2.402-2.480GHZ, 2.4G ISM band,

* Radio Performance: Receive Sensitivity of -90dBm, TX Power Max 4dBm,

*Class2 Bluetooth device, operating range: 5-10M,

AUDIO:

* Frequency Response: 20 Hz - 20 KHz, Very high Signal to Noise Ratio(SNR):95 Db, Total Harmonic Distortion(THD):0.1%,

* Frequency Response: 60 Hz - 20 kHz

* 3W Speaker Output Level: 80dB at 0.5m,

* Built-in Anti-noise Microphone,

POWER:

* Rechargeable Li-Polymer Battery

* Charger adapter Output: DC 5V&200mA

* Nominal charging time: Max 2 hours

*Talk time: Up to 12 hours

*music play time: Up to 2-3 hours

* Standby time: Up to 500 hours

*Operating Temperature: -10 °C ~ 50°C

Troubleshooting

If you cannot connect the speaker to your phone, do as follows:

- Ensure that the speaker is charged, switched on, paired with and connected to your phone.
- Ensure that the Bluetooth feature is activated on your phone.
- Check that the headset is within 10 meters(30 feet) of your phone and that there are no obstructions between the headset and the phone, such as walls or other electronic devices.

If no pairing is made over a period of time, the Bluetooth speaker will retreat pairing mode. You have to turn off the Bluetooth speaker and operate again.

10. Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.

Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

Leaving the device in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

11 Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep all accessories and enhancements out of the reach of small children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, allow it to dry completely.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.

All of the above suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorized service facility.

Important Regulatory Information

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.