


- functions. It is critical that you do not switch your Cloud Frame off during this process. 10 min
- Please Wait.. approx
- 16 DIGITAL SERIAL NUMBER: Your Frame should display a 16 digit serial number that you will need to enter on the www.nixplay.com website, after step 8.

6	WEB BROWSER
	nixplay 🝺
	<u> </u>
Ľ	•




FANTASTIC! YOU'RE NOW READY TO PAIR YOUR FRAME TO ITS OWN NIXPLAY CLOUD ACCOUNT

(9) changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- guarantee that interference will not occur in a particular installation. -- Reorient or relocate the receiving antenna. receiver is connected.

5 CONNECT TO YOUR WiFi: Use the UP/DOWN arrows on the Remote or the 4-way key on the back of the Cloud Frame, press OK to select your WiFi.



ENTER YOUR WiFi PASSWORD (if required) and then select



This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the

-- Consult the dealer or an experienced radio/TV technician for help.