

Front



TECHNICAL DATA	
Speaker Type	2 IN 1 Bottle Speaker
Speaker System	Dual drivers and dual passive bass radiators audio system
Bluetooth Version	AX 4.2
Connection Method	Wireless Bluetooth Connection
Recharge Method	DC5V-500MA USB Power Sources
Battery Capacity	650mAh
Rated Power	3W
Product Size	Diameter 75X 268mm
Product Weight	204g
Bottle Material	PETA

Power Charge
Use a computer USB port/ power adapter to charge the speaker. When the battery is low, 80% power capacity can be recovered after two hours fast charging and it will take 3 hours to fully charge the speaker.


Speaker Connection
Connect the speaker to the notebook, tablet PC, devices by using the USB cable.

Wireless Water Bottle Speaker

Thank you for purchasing the Everlast Wireless Water Bottle Speaker. For best use of this device, we recommend carefully reading this user manual and keeping it for your records.

Package Contains

- a. Wireless Water Bottle Speaker
- b. USB Charging Cable
- c. User Manual



Battery information

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two to three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out.

Do not leave a fully charged battery connected to a charger, overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. Never use any charger that is damaged.

Leaving the device in hot or cold places will reduce the capacity and lifetime of the battery. Optimal temperature for the battery is between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Always dispose of batteries according to local regulations. Please recycle. Do not dispose as household waste.

BATTERY CAUTION: Do not disassemble, short circuit, or expose to fire or high temperature. Properly connect specified devices. Recycle battery according to local, state and national regulations.



All other trademarks are property of their respective companies. Bluetooth® is a registered trademark of Bluetooth SIG, Inc.

It may damage your hearing if you listen with high volume for a long time. It is recommended you use the lowest volume possible for listening to music.

Back

Button Functions

Volume Up/Next Song

Press quickly for next song, press and hold to increase volume.

Power On/Off/Light

Press and hold for 3-5 second to boot speaker, press, and hold for 3-5 second again to switch off the speaker. Shortly press the button to turn on and off light when playing music.

Volume Down/Last Song


Press quickly for the last song, press and hold to decrease volume.

Play/Pause

When music playing, press the button to pause and play.

Hands-free Calls

Double tap to call the last number dialed. Press again to end the call.




Button Functions

Power Bank Port

Use USB port to recharge your mobile device

Micro USB Charge Socket

Use a computer USB port/power adapter to recharge speaker




Notes for the Bottle Cleaning


When cleaning the speaker bottle, please separate bottle and bottle speaker by counterclockwise rotation with a little force. Clean bottle separately to avoid part damage to the speaker.

Bluetooth Connection

Press power on/off button and hold for 3-5 seconds, then a prompt voice for Bluetooth connection, blue light flashing, Bluetooth is ready for connection.



Click the settings in Bluetooth devices, then search for device list and find "EV-WT-BT-SPK", then click for connection. Blue lights on and the speaker will beep, Bluetooth is connected successfully.



Notes:

1. "EV-WT-BT-SPK" Bluetooth Speaker can be connected to Mobile phone or tablets with a Bluetooth chip inside and can be paired with a notebook, compatible with ios, Android, and another mainstream operating system.
2. After first successful connection, restart the speaker, Bluetooth will be automatically connected back again.

LIMITED WARRANTY

ESI Cases and Accessories warrants to the first consumer purchaser that this product, when shipped in its original container to the original purchaser, will be free from defective workmanship and materials for one year and agrees that, it will, at its option, either repair the defect or replace the defective product or part thereof at no charge to the purchaser for parts or labor for the time periods described.

This warranty does not apply to any appearance items of the product nor to the additional excluded items set forth below nor to any product the exterior of which has been damaged or defaced which has been subjected to misuse, abnormal service or handling or which has been altered or modified in design or construction. The limited warranty described herein is in addition to an applicable law. ALL IMPLIED WARRANTIES INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE LIMITED TO THE PERIOD FROM THE DATE OF ORIGINAL PURCHASE SET FORTH BELOW. Some states do not allow limitations on how long an implied warranty last, so the above limitation may not apply to you. Neither the sales personnel of the seller nor any other person is authorized to make any warranties other than those described herein or to extend the duration of any warranties beyond the time period described herein on the behalf of ESI Cases and Accessories.

The warranties described herein shall be the sole and exclusive warranties granted by ESI Cases and Accessories and shall be the sole and exclusive remedy available to the purchaser corrections of defects, in the manner and for the period of time described herein, shall constitute complete fulfillment of all liabilities and responsibilities of ESI Cases and Accessories to the purchaser with respect to the product and shall constitute full satisfaction of all claims, whether based on contract negligence, strict liability or otherwise. In no event shall ESI Cases and Accessories be liable or in any way responsible, for any incidental or consequential economic or property damage. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

Bubble wrap & Send your device and the product to:

ESI Cases & Accessories Tech Support: 212 883-8838
44 East 32nd Street Techsupport@ESICellular.com
New York, NY 10016

* Enclose proof of purchase and \$11.95 for Shipping and Handling.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.