










<div><div>US UK</div><div>Dear user</div><div>Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.</div><div>1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.</div><div>2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.</div></div> <div>1</div>	<div><div>Remark: Switch system mode by  button, button light OFF for Windows OS( Default), button light ON for MAC OS.</div><div>How to connect the keyboard with a computer</div><div>Wired Connection</div><div>Slide the 2.4G/OFF/BT switch on left side of the keyboard to OFF for USB mode,plug the keyboard cable to computer USB port for wired connecting.</div><div>2.4G Wireless Connection</div><div>1. Slide the 2.4G/OFF/BT switch on left side of keyboard to 2.4G.</div><div>2. press [FN]+[4] for about 3 seconds, the LED marked with M flashes quickly in green, plug the USB receiver into any available USB port on your computer within 20 seconds. The computer will recognize and configure the keyboard automatically.</div><div>3. The indicator will flash on Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please note LED marked with M will be light on Red while charging, it turn to Green when charging completed( In 2.4g connecting mode).</div><div>Bluetooth Connection</div><div>1. Slide the ON/OFF/BT switch on left side of keyboard to BT.</div><div>2. Press [FN]+[1](or [2]/[3] for other Bluetooth devices), the LED marked with M flashes in blue (or cyan/magenta for the others)</div><div>3. Turn on Bluetooth and scan for available devices on your computer or smart phone. It will find "BT3.0 Keyboard or BT5.0 KB" device. Select one of them to get connected with it automatically.</div><div>4. The indicator will flash in Red when the battery is low. Please recharge the keyboard in time by plug type C cable into computer or it will turn off automatically soon, Please</div></div> <div>2</div>	<div><div>note LED marked with M will be light on Red while charging, it turn to cyan/magenta when charging completed( In Bluetooth connecting mode)</div><div>Function Introduction</div><div>1. With standard USB and 2.4G/BT connections, the keyboard can be used on computer without any software or driver installation.</div><div>2. There are 13 backlight patterns switch by  key, switch color by  key.</div><div>3. Commands of key combinations with [FN] key</div><div>[FN] + [←]: Slow down the running speed of backlight.</div><div>[FN] + [→]: Add up the running speed of backlight.</div><div>[FN] + [Win]: Disable or enable the [Win] key.</div><div>[FN] + [1]: Select Bluetooth device one (for Bluetooth connection).</div><div>[FN] + [2]: Select Bluetooth device two (for Bluetooth connection).</div><div>[FN] + [3]: Select Bluetooth device three (for Bluetooth connection).</div><div>[FN] + [4]: Change to 2.4G wireless connection. Press and hold the [FN]+[4] for 3 seconds to pair the keyboard with its receiver.</div><div>[FN] + [ESC]: Back to default setting.</div><div>[FN]+[W]: swapping ASDW keys to arrow key.</div><div>Scroll button function</div><div>Scroll button is place on right upcorner of keyboard for volume adjustment and keyboard backlight brightness adjustment function.</div><div>Backlight brightness adjustment: Press  key, it is light on White color, Scroll button can switch in different brightness level.</div></div> <div>3</div>	<div><div>Volume adjustment: Press  key, the key light's OFF, scroll button can be switch the volume level.</div><div>Multimedia function on F5-F12 for WIN OS</div><div>FN+F1: Screen display brightness -</div><div>FN+F2: Screen display brightness +</div><div>FN+F3: Multiple task</div><div>FN+F4: Computer desk</div><div>FN+F5: Back</div><div>FN+F6: Research</div><div>FN+F7: Previous track</div><div>FN+F8: Pause/Play</div><div>FN+F9: Next track</div><div>FN+F10: Mute</div><div>FN+F11: Calculator</div><div>FN+F12: My Email</div><div>Multimedia function on F5-F12 for MAC OS</div><div>F1: Screen display brightness-</div><div>F2: Screen display brightness+</div><div>F3: Multiple task</div><div>F4: Siri</div><div>F5: App expose</div><div>F6: Search</div><div>F7: Previous track</div><div>F8: Pause/Play</div><div>F9: Next track</div></div> <div>4</div>	<div><div>F10: Mute</div><div>F11: N/A</div><div>F12: N/A</div><div>Macro recording function</div><div>There are 4 profiles keys from M1 to M4, each profile can assign with 5 macro keys from G1 to G5, total 20 group macro recording.</div><div>1. Press M1~M4 to choose a profile group, the key lights ON.</div><div>2. Press MR key (MR key lights ON), then press G key (G1/G2/G3/G4/G5 ), the key lights ON.</div><div>3. Record the desired keys.</div><div>4. Press MR key to complete recording (MR key lights OFF).</div><div>For example: FN+F1→ MR→ G1→ ABC→ MR</div><div>How to play Macro</div><div>1. Choose the profile group by press M key from M1 to M4</div><div>2. Press the Macro key from G1 to G5</div><div>For example : M1→ G1(ABC)</div><div>How to delete Macro</div><div>1. Choose the profile group by press M key from M1 to M4 (The key lights ON).</div><div>2. Press MR key (MR key lights ON).</div><div>3. Double press G keys from G1 to G5 (The key lights OFF).</div><div>4. Press MR key to save(MR key lights OFF).</div><div>Keyboard sleep mode and power safe function</div><div>In 2.4Ghz and Bluetooth connecting, there are two coditions that keyboard get into sleep mode, all LEDs and backlight turn OFF, please click any key to wake up the keyboard.</div></div> <div>5</div>
<div><div>1. Sleep mode grade #1: Keyboard is out of working for 3 minutes, all backlight turns OFF, keyboard is working, 2.4G and bluetooth are connecting.</div><div>2. Sleep mode grade #2: Keyboard is out of working for 30 minutes, backlight turns OFF, keyboard is OFF, 2.4G and bluetooth are not connecting, keyboard need take some times for reconnect to wake it up.</div><div>3. Slide the keyboard at OFF when traveling to safe power.</div><div>How to recharge the keyboard</div><div>Find the USB A to USB type C cable in the packaging, plug the keyboard and connect it with computer for charging, the LED indicator(M) of keyboard will be turn to red.</div><div>Battery statu indication: Press FN+space, all backlight turn OFF, the Number keys from 【1!】 ~ 【0!】 are indicator of power statu as from 0%~100%, when 【1!】 ~ 【3#】 are ON red means keyboard is low power, need to be charge ASAP.</div><div>FAQ</div><div>1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.</div><div>2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.</div></div> <div>6</div> <div></div>	<div><div>BATTERY SAFETY GUIDELINES</div><div>DO NOT replace the battery with a different model.</div><div>DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.</div><div>DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.</div><div>DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.</div><div>DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.</div><div>DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.</div><div> CAUTION:</div><div>Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.</div><div>This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device.</div><div>Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.</div></div> <div>7</div>	<div><div>FCC Statement</div><div>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div><div>This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div><div>-- Reorient or relocate the receiving antenna.</div><div>-- Increase the separation between the equipment and receiver.</div><div>--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.</div><div>-- Consult the dealer or an experienced radio/TV technician for help</div><div>This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div></div> <div>8</div>	<div><div></div></div> <div>9</div>	<div><div></div><div>REDRAGON</div><div>HORUS PRO</div><div>WIRED /2.4G /BT 3 MODES MECHANICAL KEYBOARD</div><div>Mechanical Gaming Keyboard</div><div>Operating Instructions</div></div> <div>10</div>

封底

封面

型号	K618RGB-PRO/8945		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷				
名称	说明书						
日期	2023-11-17(修改)						
页码	1 OF 1		文件编号				
绘图	雷国建	审核	香敏琪	核准		版本	A.1