

eteicycle

ATTENTION PARENTS:
IT IS RECOMMENDED THAT THIS TOY AND
ALL ACCESSORIES BE PERIODICALLY
EXAMINED FOR POTENTIAL HAZARDS
AND THAT ANY POTENTIALLY HAZARDOUS
PARTS BE REPAIRED OR REPLACED

©2001 Geoffrey, Inc. Distributed by Toys"R*Us Paramus, NJ 07652 Made in China




OPERATING INSTRUCTIONS: BATTERY INSTALLATION:


TRANSMITTER:

- A. Press and pull the battery door downwards to open.
- B. Insert one 9V battery. (See Diagram 1.)
- C. Observe correct polarities (positive and negative poles).
- D. Replace the battery door,

VEHICLE:


- A. Make sure the ON/OFF switch on the vehicle is turned "OFF."
- B. Use a Phillips Head screwdriver (not included) to unscrew battery door. (See Diagram 2.)
- Take out the battery compartment. (See Diagram 3.)
 Install 4 AA alkaline (1.5V) or Ni-Cd (1.2V) batteries into the battery compartment. (See Diagram 4.)
- E. Insert the battery compartment into the original position.
 (See Diagram 5.)
- F. Place the battery door on the compartment and screw the battery door closed. (See Diagram 6.)





VEHICLE OPERATION:

- A. Make sure the ON/OFF switch on the vehicle is turned "ON."
- To make the vehicle move to the left, push the left knob of the controller away from you, while pushing the right knob of the controller to the left. (See Diagram 7).
- C. To make the vehicle drive forward, push the left knob of the controller away from you. (See Diagram 8).
- D. To make the vehicle move to the right, push the left knob of the controller away from you, while pushing the right knob of the controller to the right. (See Diagram 9).



PERFORMANCE TIPS

- · Do not drive car on grass, sand or carpet.
- . Do not drive car through water.
- Be sure to rest your vehicle for at least 30 minutes after every 15 minutes of operation.
- Make sure ON/OFF switch on your vehicle is in the "OFF" position when it is not in use.
- . Do not bend the antenna.
- Electrical, CB interference, mobile phones, air conditioning, elevators and steel girders in buildings will affect the operation of your vehicle.
- Do not leave the vehicle or transmitter near sources of heat or in direct sunlight for long periods of time.
- Remove the batteries from the vehicle and transmitter when they are not in use.
- Install batteries making sure the positive and negative poles of the batteries are positioned accurately.
- Avoid combined use of charged Ni-Cd batteries and discharged Ni-Cd batteries.
- · Do not mix old batteries with new batteries.
- Avoid using alkaline batteries and Ni-Cd batteries together.

USE 4"AA"SIZE BATTERIES FOR BODY(NOT INCLUDED). USE 1"9V"BATTERY FOR CONTROLLER(NOT INCLUDED).



CAUTION:

DO NOT MIX ALKALINE.STANDARD

(CARBON-ZIN) OR PECHAPIGEABLE

(MICKLE-CAOMIUN) BATTERIES.

DO NOT MIX OLD AND NEW BATTERIES.

OBSERVE CORRECT POLARITY.

REMOVE BATTERIES WHEN NOT IN USE

FL90333LC E.T. BICYCLE Sheet Size: 10.25"x 4.75"

3 Fold Sheet Prints 1 Color Process Black