
1. Functional schematic diagram



2. Instructions

1) Change color manually.

According to the Functional schematic diagram, link the output terminal, LED lamp pipe and power input , press the middle button ("MODEL") to turn on, it will flash in a kind of color , press this button ordinal to control the Ambient light for changing colors (change seven color most). Press the button eighth time to turn off (other buttons to lose effectiveness).

2) Change color automatically .

Press the button "MODEL" to turn on, hold on two seconds, Enter the automatic mode. Now the Ambient light will change color automatically every five seconds. Press the right button "UP" to speed up the speed of changing color, when press the button fifth, the Ambient light will change color automatically every seconds. Press the left button "DOWN" decelerate the speed of changing color, when press the button fifth, the Ambient light will change color automatically every seconds.

3)Press the button "MODEL" again, turn back to the a kind of color mode, now change color manually and press the button "UP" to turn on sound control, then the Ambient light will flash and change color automatically according to the music. Press the button "MODEL" again; it will flash in a kind of color. When it is flashing, press the button "MODEL" continuously to enter "change color manually" mode.

FCC ID: VII-ELAMMD

IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules:

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference and
- 2. This device must accept any interference that is received, including any interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipments.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV Technician for help.