back

WELCOME! 4. UNDERSTANDING THE LIGHT BAR 7. TIPS FOR WARMING 3. ADJUSTING THE TEMPERATURE 5. UNDERSTANDING THE LIGHT BAR 6. TIPS FOR COOLING 2. ACTIVATING EMBR WAVE embr wave There are multiple levels of temperature. The Light Bar will indicate the Occasionally, Embr Wave will not be able to fulfill a Please read and keep this User Manual and take the In Warming Mode, you want to keep as much heat as status of your Embr Wave. The metal top will get warm as Embr Wave pulls time to carefully read and follow the Important Want warmth? temperature request. During operation, you can hold down the left side of heat away from your skin (just like an air condition-Safety Instructions. the Light Bar to lower the temperature, or the right 1. For best results, insulate the device when in Too cold to start er). In order to avoid overheating, Embr Wave needs Warming Mode (such as by covering the device with side to raise it. If the device is too cold, the Light Bar will alternate When you hold down the left to recuperate from time to time. For best results: Welcome to Embr Wave! slowly between blue and orange to indicate that it (or right) side of the Light Bar, Embr Wave is a thermal wristband that provides needs to warm up — wear it against your skin for a 1. Avoid touching the metal during Cooling Mode. Embr Wave will ramp up to 2. Knocking the metal twice will switch back and thermal relief at the touch of a button. few seconds, and you should be all set! 2. If Embr Wave gets uncomfortably warm, loosen forth between two different warming rhythms. Whenever you're feeling uncomfortably warm or the wristband or take it off for a few minutes for a warming). The Light Bar will ramping to a Too warm to start colder cold, simply hold down the light bar for a session of warmer blink to show that Embr Wave few minutes to let it cool down. nice temperature. If Embr Wave is too hot to start, the Light Bar will cool or warmth. Turning on and off is ramping up. alternate slowly between orange and red. Let it rest 3. Leave the metal body uncovered to facilitate heat 1. Click anywhere on the Light Bar to wake up the Experience localized temperature that comes in 3-5 minutes, or until the Light Bar turns back off. dissipation. waves designed to maximize your thermal comfort. device. The Light Bar will turn on. Use this sensation to take the edge off and warm up | 2. Hold down the left side of the Light Bar to start or cool down — anytime, anywhere. If your device gets really hot for some reason, the cooling, or the right side to start warming. Release Temperature waves entire Light Bar will flash orange and red. If this when the device has reached a pleasant tempera-Because the human body is more sensitive to What's in the box? happens, wait to use your Embr Wave until it has changing temperatures than to static ones, Embr Your Embr Wave box includes: | Wave cools and warms in rhythmic waves. If you pay | cooled down. 3. Each cooling session lasts 3 minutes. Each • Embr Wave thermal wristband close attention, you'll notice that the Light Bar gets When in Warming Mode, Embr Wave will glow red. warming session lasts 5 minutes. The skin gets cold. brighter and dimmer to show you the rhythm. Micro USB charging cable When in Cooling Mode, it will glow blue. the metal warms up. 4. To turn off, press the middle of the light bar until Storage pouch The Light Bar will blink if you can't increase or you feel both sides click. You can reactivate at any decrease further! Quickstart guide PRO TIP: If your session has ended in the last 5 Double-knock the metal to switch rhythms. **USER MANUAL VERSION 1.3** minutes, you can reactivate it by double-tapping the aluminum body.

front