

Frame Synchronization When a signal is attenuated by rain, the CPE increases its power to boost the signal transmitted to its base station. In such cases, this power boost allows the signal to reach other base stations, especially if there is no rain in the path between the CPE and the other base stations. Base station-to-CPE synchronization within a cluster of cells can reduce this type of interference.

RF Exposure Guidelines

Note Refer to the FCC Office of Engineering and Technology Bulletin No. 65 for RF exposure guidelines.
