


rukus XL

The super-loud, solar-powered, music-blasting wireless sound system




USER MANUAL


eton
EMPOWERED BY NATURE

2 | Thank you for purchasing the Etón Rukus XL, an iPhone® and/or iPod® docking station with beautiful sound quality. The So ultra XL is powered from the rechargeable Li-ion battery charged by the solar panel or the AC adapter (included). Please read this user manual to get a good understanding of how the Rukus XL works and how to fully enjoy it.

WHAT'S IN THE BOX





Rukus XL



Adapter

Rukus XL FUNCTIONS






Charge On/Off

Charge standby switch. Turn 'Off' when unit not in use to conserve the battery life of the device.

LET'S GET STARTED


1  Press the ON/OFF button

2  Icons will sequentially flash starting from solar icon

3  Lit up icon indicates power source

6 |

rukus XL



Press and hold  to view battery life

			0 - 10 %
			11 - 40 %
			41 - 70 %
			71 - 100 %

(2 blinks every 2 secs)




- Solar: charging in direct sunlight
- DC: power adaptor
- Battery: using internal battery
- Battery full

REGULAR CHARGING MODES

POWER	SOLAR	DC	BATTERY	UNIT DISPLAY
OFF				
OFF		●		(1 blink every 2 secs)
OFF	●			
ON			●	
ON	●			
ON		●		

(1 blink every 2 secs)

Pressing and holding the  button shows the condition of the Li-ion battery. The Li-ion battery (SW9) starts charging once the AC adapter is plugged in or when the solar panel is in direct sunlight.

PLUGGING IN THE AC ADAPTER

The Rukus XL comes equipped with an AC adapter. Plug the AC adapter into the right socket labeled DC located under the rubber plug on the side of the Rukus XL. Plug the other end into an AC socket. With the AC adapter plugged in, the Rukus XL starts charging its Li-ion battery and is ready to play.

CONNECTING YOUR BLUETOOTH DEVICE

Press and HOLD the ON/OFF Power button for 3 seconds (until you hear the beep).

CHARGING A SMARTPHONE OR OTHER USB DEVICE THROUGH USB PORT

The smartphone or USB device starts charging once it is inserted into the USB port. When the Rukus XL's **POWER** is **OFF** it can still charge your device. Please be advised that leaving your device after it has received a full charge from the Rukus XL, if <charge> is still set '**ON**', it will continue to drain the Rukus XL's internal battery.

ADJUSTING THE VOLUME **+** **-**

Press the volume buttons, **+** **-**, to increase or decrease volume levels or control it on your Bluetooth® device.

BASS BOOST FUNCTION

Press the **bass** button to turn on Bass Boost.

AUX (AUXILIARY)

The **AUX** button switches between Bluetooth® device and AUX-input if there is a signal from the port. The iPod and iPhone signal takes priority if there is a signal and an audio-in signal at the same time. If the audio-in signal is present, the switching function of the '**AUX**' button is available. The **AUX** light turns on when auxiliary input is being used.

PLAY/PAUSE **▶||**

Pressing the **▶||** button switches from play to pause for the the Bluetooth device, or control it directly on your device.

FWD/REW, ◀◀▶▶

Pressing these buttons, ◀◀▶▶, selects previous track/next track with a short press; hold down to scrub forward/reverse or control it directly on your Bluetooth device..

REPLACING THE LITHIUM-ION BATTERY

A new rechargeable battery can be purchased by contacting us at www.etoncorp.com or by calling (US) 1-800-872-2228 or (Worldwide) 650-903-3866.

WARRANTY REGISTRATION

To ensure full warranty coverage or product updates, registration of your product should be completed as soon as possible after purchase or receipt. Please go to <http://www.etoncorp.com/productregistration> to register your product.

Please go to <http://http://www.etoncorp.com/productregistration> to register your product.

LIMITED WARRANTY

Retain the warranty information from your warranty card with your proof of purchase or the Limited Warranty information can also be viewed at www.etoncorp.com.

SERVICE FOR YOUR PRODUCT

To obtain service for your product, we recommend first contacting an Etón service representative at 800-872-2228 US, 800-637-1648 Canada or (650) 903-3866 for problem determination and trouble-shooting. If further service is required, the technical staff will instruct how to proceed based on whether the radio is still under warranty or needs non-warranty service.

WARRANTY – If your product is still in warranty and the Etón service representative determines that warranty service is needed, a return authorization will be issued and instructions for shipment to an authorized warranty repair facility. Do not ship your radio back without obtaining the return authorization number.

NON-WARRANTY – If your product is no longer under warranty and requires service our technical staff will refer you to the nearest repair facility that will be able to best handle the repair. For service outside of North America, please refer to the distributor information included at time of purchase/receipt.

DO YOU NEED HELP?

If you need help, please contact us, Monday-Friday, 8:00 a.m.- 4:30 p.m., North American Pacific Standard Time.

US:

1-800-872-2228

CANADA:

1-800-637-1648

WORLDWIDE:

650-903-3866

FAX:

650-903-3867

WARNING

- Do not submerge or expose for extended period to water.
- Protect from high humidity and rain.
- Only operate within specified temperature range (0 °C to 40 °C).
- Unplug immediately if liquid has been spilled into or any object has fallen into the apparatus.
- Clean only with a dry cloth. Do not use detergents or chemical solvents as this might damage the finish.
- Do not remove cover [or back].
- Refer servicing to qualified service personnel.

DISPOSAL

Please dispose of old electrical and electronic equipment according to your local environmental laws and guidelines.



Eton Corporation

1015 Corporation Way
Palo Alto, CA 94303, USA

www.etoncorp.com

v030113

