217S53 User manual

BATTERY INSTALLATION

- a. Lift off the bracket stand of the RF remote sensor by releasing the 2 fixing snaps at the bottom, then use a small Philips screwdriver to remove the battery cover screws.
- b. Insert 2pcs of AAA size batteries according to the "+" and "-" polarity marks shown in the battery compartment.
- c. Once the batteries are inserted, the sensor will automatically transmit temperature signal to the main body at 30 seconds intervals. The sensor is also equipped with a reset button, you can enforce the sensor to reset and then it will transmit again.
- d. The outdoor temperature will be displayed on the lower part of the screen when the main unit receives temperature signal(s).

RESET SWITCH

A reset switch reserves for abnormal condition.

DETACHABLE PROBE

- a. In order to avoid freezing up of battery, when the outdoor temperature is below 10^oC, open the side cover of the RF remote sensor and insert the probe plug. Extend the 6 feet probe cord, leave the probe sensor outdoor and place the remote sensor unit indoor
- b. Besides overcomes the extreme low temperature, the detachable probe can also be used to measure the temperature of water, Soil or other liquid.

SPECIFICATION

Sensor without LCD Display: -20° C to $+50^{\circ}$ C (-4° F to $+122^{\circ}$ F)

Detachable Outdoor Probe: -50° C to $+70^{\circ}$ C (-58° F to $+158^{\circ}$ F)

Transmission Range: 100 feet Battery: DC 3V, 2xAAA size

Modifications not authorized by the manufacturer may void users authority to operate this device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures;

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.