

Wireless Door Chime

Bell Push - Model No. 190
Door Chime Unit - Model No. 900

INSTRUCTION FOR USE AND INSTALLATION (USA)

Special Features

- 1) Operating range up to 30 Meter (100 ft) depending upon location;
- 2) Digital encoded with 16 selectable channels prevents interference occurring should a neighbor be using a similar device;
- 3) Low battery warning light on door chime unit;
- 4) Light (LED) on bell push to inform you of correct operation.

Bell Push

- 1) The bell push can be mounted on or near the front door with the screws provided. A security screw is supplied to prevent unwanted removal of the bell push after it is inserted in the mount;
- 2) The bell push is operated by a 9V alkaline battery. To replace battery simply remove security screw at the base of the bell push, and remove the unit from the mount (Remember to remove bell push from the bottom first). Then remove battery cover from the back of the bell push.

* IMPORTANT: Ensure that the bell push has the same channel pre-selected as that of the door chime unit. The selectors can be found at the back of each bell push, located at the left hand side, in the form of four rows of jumpers, after the battery cover is removed.

Door Chime Unit

- 1) Remove battery cover from the front of the door chime unit and insert 3 'C' size alkaline batteries;
- 2) Ensure that the door chime unit has the same channel selected as that on the bell push. The channel selection panel can be found in the front of the unit, after the battery cover is removed;

* IMPORTANT: The door chime unit is not water resistant and should not be exposed to rain or immersed in water.

- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:-

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.