

Fisher-Price

L4878
M2750

SMARTCYCLE™

PHYSICAL LEARNING ARCADE SYSTEM




GO NICK JR.
DieGO GO!™

Animal Rescue™

CYCLE CONTROLS

Handlebar

Use for steering on the road or in games.



Horn Button

Press to make a selection or hear the horn.

Snap Shot Button

Press to make a selection or take "pictures" (see page 5).

Power Switch

Slide the switch to **on**  or **off** .

Map Button

Press to see a map of all activities (see page 10).

Joystick

Use to make selections on the menus or in activities.

Exit Button

Press to exit the activities.

Travel Journal Button

Press to see the pictures you took along your journey.

GETTING STARTED



- Please keep these instructions for future reference, as they contain important information.
- Insert the game cartridge into the socket in the side of the cycle. Push to be sure it's fully inserted.
- Turn your TV or VCR power **on**.
- Slide the power switch on the cycle to **on** **I**.
- To find the picture on your TV screen, set your TV's or VCR's mode selector to INPUT or VIDEO IN.



CHOOSE YOUR RESCUE VEHICLE



DIEGO'S ANIMAL RESCUE



- Use the joystick to choose your rescue vehicle.
- Press either handlebar button to make your selection.
- Repeat this process to choose a color for your vehicle and a horn sound.

Find the objects

- Pedal the cycle to move down the road. *The faster you pedal the faster you go!*
- Use the handlebar to steer.
- Collect all the objects shown in the upper left of the screen. Simply drive into them. Don't bump into the other objects.



Taking Snap Shots

- Press the right handlebar button to take snap shots.



Off Ramps

- Keep traveling down the road and go all the way around the road or head onto an off-ramp for other fun games and activities. Simply bear to the side of the road as you see one approaching.

Hint: If you miss your ramp, you can pedal in reverse to back up.



SWING TO THE RESCUE

Baby Animal



Return the baby animals to its mommy in the shortest time possible!

- Use the joystick to help Diego swing from vine to vine or to move up and down on a vine.
- Get to the baby animal and it hops on Diego's shoulder.

- Return the baby animal to its mother.
- Try to avoid the snake or it will slow you down.
- When all the baby animals are rescued, your time is displayed. Move to the next level where there are more baby animals to rescue.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.

SPOT THE HIDDEN ANIMALS



Spot all the hidden animals in the forest!

- Use the joystick to “search” the trees for the hidden animals.
- When you spot an animal, press a handlebar button. Diego tells you an interesting fact about the animal.
- Try to find all the animals!
- When you’re finished with this activity, press the exit button  to return to the road. Pedal to the next activity.

RIVER RESCUE



Animals Rescued

Rescue These Animals

Travel down the river and rescue animals along the way in the shortest time possible!

- Use the joystick to choose your rescue vehicle. Press either handlebar button to make your selection.
- Look at the bottom of the screen to see the number and type of animal you need to rescue.
- Use the joystick to move down the river and rescue stranded animals.

Hint: You don’t need to pedal to play this game, but you can pedal to go faster.



THE BIG RACE



Time



*Pedal as fast as you
can to the finish line!*

- Try to avoid obstacles and move to the stranded animals.
- Your time is displayed on the bottom of the screen.
- After you rescue all the animals, move to the next level where there are more animals to help and the river moves faster.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.

- Use the joystick to choose 1 Player or 2 Player game. Press either handlebar button to select the game.



1 Player

- Pedal down the road as fast as you can to the finish line. Try to speed past the other racers. Get to the finish line first and you win!

2 Player

- Each player takes a turn. Pedal down the road as fast as you can to the finish line. Look at your time.
- Now it's time for Player 2 to beat your time.
- The player with the fastest time wins.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



DIEGO'S FIELD JOURNAL



Learn fun facts about animals.

- Use the joystick to choose an animal. Press either handlebar button to make your selection.
- Learn interesting facts about the animal you chose.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



NEST QUEST



Return the baby animal to its mommy in the shortest amount of time!

- Use the joystick to move the hot air balloon up and through the trees.
- Get to the nest at the top of the tree and return the baby animal to its mother.
- Try to reach the top of the tree as fast as you can.
- Try to avoid obstacles along the way. They will slow you down.
- A gauge on the right of the screen shows your progress through the layers of the rainforest.



BONUS ACTIVITY

Hint: You don't need to pedal to play this game, but you can pedal to go faster.

- When you return the baby animal to the nest, you move to the next level where there are more obstacles.
- When you complete each level, your time is displayed.
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.



- To visit here, you need to visit all of the activities around the road first.
- Diego presents you with a patch for rescuing all the animals!
- When you're finished with this activity, press the exit button  to return to the road. Pedal to the next activity.




TRAVEL JOURNAL



See previous
snap shot

See next
snap shot



Stamp Tool Erase

- Press the travel journal button . Then use the joystick and handlebar buttons to review and select a snap shot.

- Next, use the joystick and handlebar buttons to select the stamp tool  to decorate your picture.
- Choose a stamp with the joystick and handlebar buttons and place it on the snap shot.
- Select the erase button  to clear the screen and decorate another picture.



THE MAP



- You can travel down the road and head onto an off-ramp to access activities or simply press the map button  to visit any of the activities around the course.

CARE

- Wipe with a clean cloth dampened with a mild soap and water solution.
Do not immerse.
- This product has no consumer serviceable parts. Do not take this product apart.

 • Protect the environment by not disposing of this product with household waste (2002/96/EC). Check your local authority for recycling advice and facilities (Europe only).

CONSUMER INFORMATION

VISIT US ON LINE AT
WWW.SERVICE.FISHER-PRICE.COM

Call our Consumer Relations Department, toll-free at **1-800-432-5437**, 9 AM - 7 PM EST Monday through Friday and 11 AM - 5 PM EST Saturday. Hearing-impaired consumers using TTY/TDD equipment, please call 1-800-382-7470. Write to us at: Fisher-Price® Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052.

GREAT BRITAIN: Mattel UK Ltd, Vanwall Business Park, Maidenhead SL6 4UB.
Helpline: 01628 500303. www.service.mattel.com/uk

For countries outside the United States:

CANADA: Questions? 1-800-432-5437. Mattel Canada Inc., 6155 Freemont Blvd., Mississauga, Ontario L5R 3W2; www.service.mattel.com.

AUSTRALIA: Mattel Australia Pty. Ltd., 658 Church Street, Locked Bag #870, Richmond, Victoria 3121 Australia. Consumer Advisory Service 1300 135 312.

NEW ZEALAND: 16-18 William Pickering Drive, Albany 1331, Auckland.

ASIA: Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Fisher-Price, Inc., a subsidiary of Mattel, Inc., East Aurora, NY 14052 U.S.A.
©2007 Mattel, Inc. All Rights Reserved. ® and ™ designate U.S. trademarks of Mattel, Inc.

Stretch your mind with other software titles for your Smart Cycle™!

Each sold separately and subject to availability.



©2007 Viacom International, Inc. All Rights Reserved. Dora the Explorer, Go Diego Go, SpongeBob SquarePants and all related titles, logos and characters are trademarks of Viacom International, Inc. SpongeBob SquarePants created by Stephen Hillenburg.

www.fisher-price.com

PRINTED IN CHINA

L4878pr-0920