



Introduction:

Imperial 2.4G Media Center remote is one of the best computer input devices in the market today. It combines the convenience of radio frequency wireless and the optical trackball with mouse keys and MCE start Key.

As no cable connected to the keyboard, you can put it away to save space when you finish using it. Imperial 2.4G MCE remote is ergonomically designed allowing for comfortable use on hands.

Please read carefully the information and instructions contained in this manual and you are sure to obtain a higher level of computing enjoyment.

Installation

1. Turn on the computer



2. Plug the RF Receiver into the USB port of your computer



3. Open the battery cover under the remote and place 2 AA batteries inside the battery compartment.

Push to open



4. Setting ID:

- a. Press ID button on the receiver (Picture A), the LED is on flash which mean ID is sourcing.
- b. Press ID button on the back of remote (Picture B). The LED on the receiver is off which mean setting is successful.
- c. Close the battery cover



Picture A



Picture B

Note:

1. RF signal LED on the receiver will flash when the remote is being used.
2. When Battery Low LED lights, it means the remote requires a change of batteries.
3. When doing this process, please make sure the distance between the receiver and remote is within 60 cm (2 feet).

Trouble Shooting

If your remote cannot work after installation, please check followings:

- a. Make sure you have connected the receiver correctly to the computer. The receiver has been properly plugged into computer's USB ports.
- b. Make sure you have inserted two AA batteries into its compartment correctly.
- c. If without any interference, such as other computer peripherals, the working distance (distance between remote and the receiver) is about 10 meters.
- d. If using more than two units and interfere occurred, please reset ID again.

Keys Description

PC Remote Control

This remote control is function in PC mode only.



- 1 **Power Switch**
Press this button to temporarily turn off the PC and switch PC to standby mode. Press it again to switch on the PC from the standby mode.
- 2 **Start Key**
Press this button to start the media center functions.
- 3 **Channel**
When the Live TV is showing, use + and - button to change channel.
- 4 **Information**
Press this button to showing file or program information.
- 5 **◀ ▶ ▲ ▼ and OK**
When the media center interface is displayed, use these buttons to operate the menu setting.
- 6 **Mouse - Right Button**
Press this mouse right button to select setting and information.
- 7 **Multimedia Control Buttons**
Use these buttons to control as you need.
- 8 **Number Buttons**
Press these buttons to select channels, press again to the second digit.
- 9 **Enter**
Press this button to confirm selection.
- 10 **Clear**
Press this button to clear all information.
- 11 **Num Lock**
Press this button to lock on Numeric status.
- 12 **Mouse - Left Button**
Press this mouse left button to enter selection.
- 13 **Optical Trackball**
Rolling the trackball to move the mouse cursor.
- 14 **Back**
Press this button to move back previous program or page.
- 15 **Volume**
When the program is showing, use + and - button to adjust the volume.
- 16 **Audio-visual Buttons**
These function buttons have below features after press Start key:

<input type="radio"/> to My TV	<input type="radio"/> to Live TV
<input type="radio"/> to My Music	<input type="radio"/> to My Recorded TV
<input type="radio"/> to My Photo	<input type="radio"/> to Guide
<input type="radio"/> to My Video	<input type="radio"/> to DVD menu
- 17 **Close**
Press this button to close the program.
- 18 **Battery Low**

FCC information

The Federal Communication Commission Radio Frequency Interference Statement includes the following paragraph:

The equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The user should not modify or change this equipment without written approval from FOCUS Electronic Co., Ltd. Modification could void authority to use this equipment.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.