


2Buds Pro Wireless Earbuds White

Manual



Product overview:

1. USB-C input port
2. Earbuds slot
3. Charging case indicator light
4. Left earbuds
5. Left earbuds indicator light+touch button
6. Right earbuds indicator light+touch button
7. Right earbuds

Specifications:

- Touch Button
- Bluetooth V5.3
- Battery capacity: 40mAh*2 & 240mAh
- USB-C Input: 5V=0.2A
- Total Play Time(75% volume): 16h
- Size: 58.5*49*26(mm)
- Material: Recycled ABS

Accessory:

- Manual
- 30CM USB-A to USB-C Recycled TPE Charging cable

Operating Instructions:

- Power On: Take out the earbuds from the charging case, and it will automatically turn on; if there is no connection or operation, the earbuds will turn off automatically after 5 minutes.
- Power Off: Put the earbuds back into the charging case to charge or long-press the

touch button(5.) or (6.) for 5 seconds, and the earbuds will turn off automatically.

- Pairing: The left and right earbuds is already paired, and you can pick it up from the charging case for normal use. For the first use, click "Pairing" after you find the pairing name in the Bluetooth search interface of the phone setting. Next time the product will automatically connect.

- Play/Pause: When playing music, double-click the touch button on the left or right earbuds(5.) or (6.) to play/pause.

- Incoming call function: Click the touch button of the left/right earbuds(5.) or (6.) to answer, double click to hang up. Long press the touch button of the left ear/right earbuds for 2 seconds to reject incoming call.

- Previous track: Click the touch button of the left ear earbuds for four times;

- Next track: Click the touch button of the right earbuds for four times;

- Volume + : Click the touch button of the right earbuds;

- Volume - : Click the touch button of the left earbuds.

- When it reaches the maximum volume, there will be a prompt tone. The volume adjustment is synchronized with the mobile phone.

- Activate SIRI: Triple-click the touch button of the left or right earbuds(5.) or (6.) to enter SIRI mode.

- ANC Mode: Long-press the touch button of the left or right earbuds(5.) or (6.) for 2 seconds and there will be a prompt tone, which can switch between three modes: Transparency Mode/ANC ON/ANC OFF.

- Earbuds Charging: Put the earbuds into the corresponding slot(2.) of the charging case, and the red light of the earbuds will remain on to indicate that it is charging. The light will go off when it is fully charged.

- Charging Case Charging: Connect the USB end of the charging cable to the adapter and the other end to the USB-C charging port(1.) of the charging case. When charging, the red light of the charging case will flash, and it will remain on when it is fully charged.

IMPORTANT SAFETY INSTRUCTIONS:

In order to ensure the life of the product, if it is not use for a long time, please store the product fully charged.

- Do not drop,apply excessive force to the controls,or put heavy objects on top of the Charging case and earphones.

- Do not attempt to repair,disassemble or modify the product. There are no user-serviceable parts inside this unit.

- If you do not use the earphones for long periods if time,be sure to store it on the dry charging case,free from extreme temperature,humidity and duct.

- Keep speaker away from any heat source.

- This is not a toy, not suitable for children under the age of 7.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.