

Wireless Barcode Scanner Operating Manual

Multiscan Functions - 1

OUTPUT FIRMWARE VERSION
0A

RESET CONFIGURATION TO DEFAULTS
0B

OUTPUT MODE-KEYBOARD WEDGE
000800

OUTPUT MODE
000801

GOOD READ BEEP TONE - NONE
014200

BUZZER/LED
0142

GOOD READ BEEP TONE - RESET
014201

GOOD READ BEEP DURATION - MEDIUM
014301

LED POWER SAVE MODE - ENABLE
01451

Multiscan Functions - 2

DECODE OPTIONS REVERSE IMAGE - ENABLE
01391

IMAGE
01390

DECODE OPTIONS REVERSE IMAGE - DISABLE

DECODE OPTIONS SEND BAR CODEID - DISABLE
01400

CODEID
01401

DECODE OPTIONS SEND BAR CODEID - ASA PREFIX

DECODE OPTIONS SEND BAR CODE ID - RESET
01410

DECODE OPTIONS SEND BAR CODE ID - ASA SUFFIX
01402

LASER/CCD MODE - SINGLE SCAN
013300

READING MODE
013301

LASER/CCD MODE - MULTISCAN
013302

LASER/CCD MODE - MULTISCAN NO TRIGGER
013303

LASER/CCD MODE - CONTINUOUS SCAN
013304

LASER/CCD MODE - PULSE
013305

-1-

Note 1

一、 Channel settings

Channel settings
Setting range 01-20

二、 User ID settings

User ID settings
Setting range 00-99

三、 Parameter settings

Parameter settings
0 1 2 3
4 5 6 7
8 9

四、 Sleep Time settings

Sleep Time
20 seconds 30 seconds 60 seconds 2 minutes
5 minutes 10 minutes 20 minutes

五、 Normal mode

六、 Inventory mode

Inventory mode
Upload data Total number of data Clear data

七、 barcode type display settings

barcode type display settings
0000001 0000002
display barcode type behind the barcode not display barcode type behind the barcode

-2-

Note 2

1. Add prefix

The first step: scan the set-up code below (this step will clear the pre-set prefix)

0C001
Add prefix

The second step: scan the needed character codes (maximum add 10 characters)
E.g. To add prefix "MG", scan character M and G orderly.

77 M
71 G

Now "MG" will be added when scanning the normal bar codes.

TEST

Scan the above testing bar code, "MGTEST" will show.

2. Add suffix

The first step: scan the set-up code below (this step will clear the pre-set suffix)

0C002
Add suffix

The second step: scan the needed character codes (maximum add 10 characters)
E.g. To add suffix "OK", scan character O and K orderly.

73 O
75 K

Now "OK" will be added when scanning the normal bar codes.

TEST

Scan the above testing bar code, "TESTOK" will be shown.

3. Hide the front characters

The first step: scan the set-up code below (this step will clear the pre-set settings)

0C003
Hide the front characters

The second step: scan the number needs to be hidden (maximum hide 10 characters)
E.g. To hide two front characters, scan the set-up code "02".

02
123456789

Now two front characters will be hidden when scanning the normal bar codes.

Scan the above testing bar code, "3456789" will be shown.

4. Hide the behind characters

The first step: scan the set-up code below (this step will clear the previous settings)

0C04
Hide the behind characters

The second step: scan the number needs to be hidden (maximum hide 10 characters)
E.g. To hide three behind characters, scan the set-up code "03".

03
123456789

Now three behind characters will be hidden when scanning the normal bar codes.

Scan the above testing bar code, "987654" will be shown.

-3-

Note 3

0C001 add prefix	10 LF/F10	24 CAN/HOME	38 k	52 4
0C002 add suffix	11 VT/F11	25 EM/Back Space	39 j	53 5
0C003 hide the front characters	12 FF/F12	26 SUB/CTRL ON	40 (54 6
0C004 hide the behind characters	13 CR/ENTER	27 ESC/CTRL OFF	41)	55 7
00 NIL/SP	14 SO/END	28 FS/ALT ON	42 *	56 8
01 SOH/F1	15 SI/RIGHT	29 GS/ALT OFF	43 +	57 9
02 STX/F2	16 DL/LEFT	30 RS/SHIFT ON	44 ,	58 :
03 ETX/F3	17 DCL/UP	31 US/SHIFT OFF	45 -	59 ;
04 EOT/F4	18 DC2/DOWN	32 SP	46 .	60 <
05 ENQ/F5	19 DC3/PgUp	33 !	47 /	61 =
06 ACK/F6	20 DC4/PgDn	34 "	48 0	62 >
07 BEL/F7	21 NAK/TAB	35 #	49 1	63 ?
08 BS/F8	22 SYN/Bak TAB	36 \$	50 2	64 @
09 HT/F9	23 ETB/ESC	37 %	51 3	65 A

-4-

Note 4

66 b	80 p	94 r	108 t	122 z
67 c	81 q	95 s	109 u	123 {
68 d	82 r	96 t	110 v	124
69 e	83 s	97 u	111 w	125 }
70 f	84 t	98 v	112 x	126 ~
71 g	85 u	99 w	113 y	127 DEL
72 h	86 v	100 x	114 z	
73 i	87 w	101 y	115 {	
74 j	88 x	102 z	116 	
75 k	89 y	103 {	117 ~	
76 l	90 z	104 	118 _	
77 m	91 {	105 ~	119 `	
78 n	92 {	106 _	120 a	
79 o	93 	107 ~	121 b	
			122 c	

-5-

FCC ID: 2AAPVX-988

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.