


USER MANUAL for CODING CAR




<Exterior of Coding Car>

1. Unplugged Mode


(1) Card Coding

- ① Turn the power on 开机
- ② Scan the "Initialization of Sensor" card
 - Push the front-top of Coding car for 3 time in a sec, on the card.
- ③ Scan the "Start of Card Coding" card.
 - Push the front-top of Coding car for 1 time, on the card.
- ④ Scan the coding cards in order and lastly scan "End of Card Coding" card
 - Push the front-top of Coding car for 1 time, on the card.
- ⑤ Put the coding car on the ground, and Push the front-top of Coding car for three seconds.
- ⑥ It will be terminated automatically after action for coding.



(2) Line Coding

- ① Turn the power on
开机
- ② Scan the "Start of Line Coding" card
 - Push the front-top of Coding car for 3 time in a sec, on the card.
- ③ Put the coding car on the Line
- ④ The Line coding will start in 2~3 seconds automatically.



<Example of Line>

(3) Piano Coding

- ① Turn the power on
- ② Scan the "Start of Piano Coding" card
 - Push the front-top of Coding car for 3 time in a sec, on the card.
- ③ Scan the Scale coding cards in order and lastly scan "End of Piano Coding" card
 - Push the front-top of Coding car for 1 time, on the card.
- ④ It will play the Scale in 2~3 seconds automatically.

2. Plugged Mode

(1) Bluetooth – Remote Control(RC)

- ① Turn the power on
- ② Run the App on smart device(Tablet or Smartphone etc.)
- ③ Select the Coding Car on the list and Connect it through Bluetooth
- ④ Enter "Drive Menu"
- ⑤ Control the coding car using lever on the screen.

(2) Bluetooth – Block Coding

- ① Turn the power on
- ② Run the App on smart device(Tablet or Smartphone etc.)
- ③ Select the Coding Car on the list and Connect it through Bluetooth
- ④ Enter "Coding Menu"
- ④ Construct the coding blocks in order
- ⑤ Touch the Start button
- ⑥ It will be terminated automatically after action for coding



<Application Screen>

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction