ROG KERIS II ACE

מדריך להתחלה מהירה (HB)


WIRELESS OPTICAL GAMING MOUSE P714

快速使用指南(繁體中文) 快速使用指南(简体中文)

dnik szybkiego startu (PL) apidă (RO) دليل التشغيل السريع (AR)

BC /5U5


Package Contents



- e recommend using the wireless dongle extender when using the mouse in 2.4GH: 們建議當您在使用鍵盤的 RF 2.4GHz 無線模式時,使用無線接收器延長器。 们建议当您在使用键盘的 RF 2.4GHz 无线模式时,使用无线接收器延长器。

Mouse features / 滑鼠功能 / 鼠标功能





- Left-click button / 左鍵 / 左键
- Scroll wheel / 滾輪 / 滚轮
- Right-click button / 右鍵 / 右键
- 4 Forward button / 向前按鈕 / 向前按钮
- 5 Backward button / 向後按鈕 / 向后按钮
- 6 Mouse feet / 滑鼠腳墊 / 鼠标脚垫
- USB Type-C° connector / USB Type-C° 連接埠 / USB Type-C° 接口
- 图 DPI button / DPI 按鈕 / DPI 按钮
- Pairing button/配對按鈕/配对按钮
- USB dongle / USB 無線訊號接收器 / USB 无线信号接收器
- 11 Optical sensor / 光學感測器 / 光学感应器
- Connection mode switch / 連線模式切換開關 / 连接模式切换开关

Resolution DPI 1 DPI 2 DPI 3 (Default) DPI 4

Polling rate level switch

Sensor Lift-off-distance

Specifications*

level switch

Hardware Reset

	100 DPI to 42000 DPI	400 DPI	800 DPI	800 DPI 1600 DPI 3200 DPI					
* You may customize the DPI settings for DPI 1-4 through Armoury Crate or the DPI On-The-Scroll tuning function.									

Hold Left-click button + Right-click

button + Scroll wheel + DPI button

Pairing button + Backward button

Pairing button + Forward button

for 3 seconds

Connecting your gaming mouse

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C° to Type-A cable to your ming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse

- 2. Set the connection switch to the RF 2.4G Wireless mode Setting up your gaming mouse as a Bluetooth® wireless
- t the connection switch to the **Bluetooth® mode**.
- Pairing Bluetooth® mode to additional host devices (max. 3)
- Set the connection switch to the **Bluetooth® mode**.
 Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

follow the software instructions to update your gaming mouse

The Scroll LED will blink red once the key

Cycles through the following polling rates:

The scroll LED will blink green once the reset is

combination is held down until the reset is comple

125 (red) / 250 (purple) / 500 (blue, BT not support

/ 1000 Hz (green, BT not supported) / 2000 Hz (velloy with polling booster, BT not supported) / 4000 Hz

(blue-green, with polling booster, BT not supported

/ 8000 Hz (white, with polling booster, BT not

Cycles through the following lift-off-distances: Low (red, default) / High (purple)

supported)

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

 Download and install the Armoury Crate software from https://rog.asus.com
- and dongle's firmware. Customize your gaming mouse using Armoury Crate.
- Using the DPI On-The-Scroll tuning function
- The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your
- gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.
- DPI adjustment. Press the DPI button once you have finished customizing the DP value to save the changes made.

Connecting your gaming mouse

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C® to Type-A cable to your ning mouse and a USB port on your compute

Setting up your gaming mouse as a RF wireless mouse

Connecting your gaming mouse

ouse and a USB port on your

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

1. Connect the USB dongle to a USB port on your computable. Set the connection switch to the RF 2.4G Wireless mouse.

Setting up your gaming mouse as a Bluetooth® wireless

Pairing Bluetooth® mode to additional host devices (max. 3)

witch to the Bluet

Press and hold the **Pairing** button for 3 seconds until the LED on

your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

the connection switch to the **Bluetooth® mode**.

- Set the connection switch to the RF 2.4G Wireless mode.
- Setting up your gaming mouse as a Bluetooth® wireless Set the connection switch to the Bluetooth® mode
- Pairing Bluetooth® mode to additional host devices (max. 3)
- Set the connection switch to the **Bluetooth® mode**.
 Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming use will light up blue for 3 seconds

Updating the firmware and customization

Updating the firmware and customization

Connect your gaming mouse to your computer using the

https://rog.asus.com
Follow the software instructions to update your gaming mouse and donole's firmware.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up.

Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

Press the DPI button once you have finished customizing the DPI

Download and install the Armoury Crate software from

and dongle's firmware.
4. Customize your gaming mouse using Armoury Crate.

value to save the changes made.

bundled cable, then connect the USB dongle to a USB port.

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.
- Download and install the Armoury Crate software from https://rog.asus.com Follow the software instructions to update your gaming mouse
- 4. Customize your gaming mouse using Armoury Crate.
- Using the DPI On-The-Scroll tuning function The DPI On-The-Scroll tuning function allows you to customize the
- DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your
- paming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the DPI adjustment.

 Press the DPI button once you have finished customizing the DPI
- value to save the changes made

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your compute

Connecting your gaming mouse

ng mouse and a USB port on your o

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

1. Connect the USB dongle to a USB port on your compu

2. Set the connection switch to the RF 2.4G Wireless management of the set of t

Setting up your gaming mouse as a Bluetooth® wireless

Pairing Bluetooth® mode to additional host devices (max. 3)

witch to the Blue

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

the connection switch to the Bluetooth® mode

Setting up your gaming mouse as a RF wireless mouse

- 2. Set the connection switch to the RF 2.4G Wireless mode
- Setting up your gaming mouse as a Bluetooth® wireless

Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

 Set the connection switch to the **Bluetooth® mode**.
 Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming ise will light up blue for 3 seconds

Updating the firmware and customization

Updating the firmware and customization

Download and install the Armoury Crate software from

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

https://rog.asus.com
Follow the software instructions to update your gaming mouse and donale's firmware.

ongle's tirmware. mize your gaming mouse using Armoury Crate

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

DPI adjustment.
Press the DPI button once you have finished customizing the DPI

value to save the changes made.

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

 Download and install the Armoury Crate software from
- https://rog.asus.com Follow the software instructions to update your gaming mouse and dongle's firmware.
- omize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

- DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your
- paming mouse light up.

 croll the scroll wheel forwards or backwards to adjust the DPI.

 the LED color hue on your mouse will differ depending on the
- value to save the changes made

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your ning mouse and a USB port on your comp

Setting up your gaming mouse as a RF wireless mouse 1. Connect the USB donale to a USB port on your come

Set the connection switch to the RF 2.4G Wireless mode. Setting up your gaming mouse as a Bluetooth® wireless

mouse Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3) h to the Bluet

Connecting your gaming mouse

gaming mouse and a USB port on your compute

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

Setting up your gaming mouse as a Bluetooth® wireless

mouse
Set the connection switch to the Bluetooth® mode

Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode.

Pairing Bluetooth® mode to additional host devices (max. 3)

Set the connection switch to the Bluetooth® mode

Set the connection switch to the **Bluetooth*** **mode**.

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. Download and install the Armoury Crate software fron
- https://rog.asus.com
 Follow the software instructions to update your gaming mouse and dongle's firmware.
 Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

- The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your
- gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the

DPI adjustment.

https://rog.asus.com

value to save the changes made

3. Press the DPI button once you have finished customizing the DPI

Updating the firmware and customization

Connect your gaming mouse to your computer using the

bundled cable, then connect the USB dongle to a USB port.

Download and install the Armoury Crate software from https://rog.asue.com

ollow the software instructions to update your gaming mouse

e your gaming mouse using Armoury Crate. Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the

DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up.

Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

DPI adjustment.

3. Press the DPI button once you have finished customizing the DPI

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable

Setting up your gaming mouse as a RF wireless mo

- Setting up your gaming mouse as a Bluetooth® wireless Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3

Connecting your gaming mouse

ming mouse and a USB port on your computer

Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode.

Pairing Bluetooth® mode to additional host devices (max. 3)

h to the **Blue**

Press and hold the Pairing button for 3 seconds until the LED on

ress and note the **raning** button for 5 seconds until the EED of our gaming mouse start to blink blue. Once your gaming mouse as been successfully paired, the LED indicator on your gaming nouse will light up blue for 3 seconds.

Setting up your gaming mouse as a Bluetooth® wireless

<u>mouse</u> Set the connection switch to the **Bluetooth® mode**.

- Set the connection switch to the **Bluetooth*** **mode**. Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse. has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. ownload and install the Armoury Crate software from
- https://rog.asus.com
 3. Follow the software instructions to update your gaming mouse and dongle's firmware.
 4. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

- The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up.
- Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the
- Press the DPI button once you have finished customizing the DPI

Connecting your gaming mouse Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to you

gaming mouse and a USB port on your compute Setting up your gaming mouse as a RF wireless mouse

Connect the USB dongle to a USB port on your con Set the connection switch to the RF 2.4G Wireless

Setting up your gaming mouse as a Bluetooth® wireless

<u>mouse</u> Set the connection switch to the **Bluetooth® mode**. Pairing Bluetooth® mode to additional host devices (max. 3)

- Iring Bluetooth* mode to additional host devices (max. 3) Set the connection switch to the Bluetooth* mode. Press and hold the Pairing button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfull y paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

nload and install the Armoury Crate software fron

- DPI of your gaming mouse without using Armoury Crate. 1. Press and hold the DPI button for 3 seconds until the LED on your
- ning mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.
- Press the DPI button once you have finished customizing the DPI

Connecting your gaming mouse

Updating the firmware and customization Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

- Download and install the Armoury Crate software from https://rog.asus.com
- and dongle's firmware.Customize your gaming mouse using Armoury Crate.
- Using the DPI On-The-Scroll tuning function
- Press the DPI button once you have finished customizing the DPI

- The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your
- The LED color hue on your mouse will differ depending on the

- gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.
- value to save the changes made

Connect the USB dongle to a USB port on you Set the connection switch to the RF 2.4G Wire

Setting up your gaming mouse as a Bluetooth® wireless

mouse Set the connection switch to the Bluetooth® mode.

Pairing Bluetooth® mode to additional host devices (max. 3) witch to the Blu

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

gaming mouse and a USB port on your compute

2. Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

- and dongle's firmware.

 4. Customize your gaming mouse using Armoury Crate.

gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

- The LED color hue on your mouse will differ depending on the
- DPI adjustment.

 3. Press the DPI button once you have finished customizing the DPI value to save the changes made

Profile switching





Profile	Hot Key	Lighting effect
Profile 1	(Cycles through Profiles 1–5)	Color Cycle
Profile 2		Breathing (purple)
Profile 3		Static (blue)
Profile 4		Breathing (green)
Profile 5		Reactive (yellow)

Press and hold the **Pairing** button for 3 seconds until the LED on

your gaming mouse start to blink blue. Once your gaming n has been successfully paired, the LED indicator on your gam

Connecting your gaming mouse Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your

ing mouse and a USB port on your compute Setting up your gaming mouse as a RF wireless mouse
1. Connect the USB dongle to a USB port on your computer.
2. Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless mouse Set the connection switch to the Bluetooth® mode. Pairing Bluetooth® mode to additional host devices (max. 3)

Set the connection switch to the **Bluetooth* mode**.

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

 Download and install the Armoury Crate software from
- and dongle's firmware. Customize your gaming mouse using Armoury Crate. Using the DPI On-The-Scroll tuning function
- DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the

The DPI On-The-Scroll tuning function allows you to customize the

Press the DPI button once you have finished customizing the DPI

Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your
gaming mouse and a USB port on your computer Setting up your gaming mouse as a RF wireless mouse

Connecting your gaming mouse

Setting up your gaming mouse as a Bluetooth® wireless Set the connection switch to the **Bluetooth® mode**.

Connect the USB dongle to a USB port on your computer
 Set the connection switch to the RF 2.4G Wireless mode

Pairing Bluetooth® mode to additional host devices (max. 3) iring Bluetooth® mode to additional host devices (max. 3)
Set the connection switch to the Bluetooth® mode.
Press and hold the Pairing button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

 Download and install the Armoury Crate software from
- https://rog.asus.com
 Follow the software instructions to update your gaming mouse and dongle's firmware. 4. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function The DPI On-The-Scroll tuning function allows you to customize the

- DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up.
 Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the
- DPI adjustment.
 Press the DPI button once you have finished customizing the DPI value to save the changes made.

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse
Connect the bundled USB Type-C° to Type-A cable to your
gaming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse 1. Connect the USB dongle to a USB port on your computer. 2. Set the connection switch to the RF 2.4G Wireless mode Setting up your gaming mouse as a Bluetooth® wireless

mouse Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

airing Bluetooth* mode to additional host devices (max. 3) Set the connection switch to the Bluetooth* mode. Press and hold the Pairing button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

The DPI On-The-Scroll tuning function allows you to customize the

- The DPI On-The-Scroll tuning function allows you to customize the
- DPI adjustment.
 Press the DPI button once you have finished customizing the DPI
- <u>https://rog.asus.com</u> Follow the software instructions to update your gaming mouse
- and dongle's firmware.

 Customize your gaming mouse using Armoury Crate.

Updating the firmware and customization

- Download and install the Armoury Crate software from
- https://rog.asus.com Follow the software instructions to update your gaming mouse
- Using the DPI On-The-Scroll tuning function The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your

Updating the firmware and customization

- https://rog.asus.com Follow the software instructions to update your gaming mouse
- Using the DPI On-The-Scroll tuning function
- The LED color hue on your mouse will differ depending on the

- Updating the firmware and customization Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.
- Using the DPI On-The-Scroll tuning function DPI On-The-Scroll tuning function allows you to customize the
- The LED color hue on your mouse will differ depending on the

- Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

- OPI of your gaming mouse without using Armoury Crate.

 1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up.
 Scroll the scroll wheel forwards or backwards to adjust the DPI.
- DPI adjustment.
 Press the DPI button once you have finished customizing the DPI value to save the changes made.

Connecting your gaming mouse

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C® to Type-A cable to your

ouse and a USB port on your

Setting up your gaming mouse as a RF wireless mouse

1. Connect the USB dongle to a USB port on your computer.

2. Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless mouse
Set the connection switch to the Bluetooth® mode.

Pairing Bluetooth® mode to additional host devices (max. 3) tch to the Blue

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

and dongle's firmware. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

Updating the firmware and customization

Download and install the Armoury Crate software from

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

//rog.asus.com v the software instructions to update your gaming mouse

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the

Press the DPI button once you have finished customizing the DPI value to save the changes made.

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your a mouse and a USB port on your

Setting up your gaming mouse as a RF wireless mouse

1. Connect the USB dongle to a USB port on your computer.
2. Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

vitch to the Blue Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

and dongle's firmware. Customize your gaming mouse using Armoury Crate.

Download and install the Armoury Crate software from //rog.asus.com w the software instructions to update your gaming mouse

Updating the firmware and customization

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the DPI adjustment.
Press the DPI button once you have finished customizing the DPI value to save the changes made.

Connecting your gaming mouse

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse

Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless

Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

Set the connection switch to the **Bluetooth® mode**.

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming ouse will light up blue for 3 seconds

Updating the firmware and customization

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. Download and install the Armoury Crate software from

https://rog.asus.com 3. Follow the software instructions to update your gaming mouse

4. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up.

Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

DPI adjustment.
Press the DPI button once you have finished customizing the DPI value to save the changes made.

Connecting your gaming mouse

<u>Setting up your gaming mouse as a wired mouse</u> Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless

Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

 Set the connection switch to the **Bluetooth* mode**.
 Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. Download and install the Armoury Crate software from

Follow the sortware induced and dongle's firmware.
 Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the

gaming mouse light up.

Scroll wheel forwards or backwards to adjust the DPI.

value to save the changes made.

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C* to Type-A cable to your gaming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse

Set the connection switch to the **RF 2.4G Wireless mode**

Setting up your gaming mouse as a Bluetooth® wireless

mouse
Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

Connecting your gaming mouse

gaming mouse and a USB port on your computer

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your

Setting up your gaming mouse as a RF wireless mouse

mouse
Set the connection switch to the **Bluetooth® mode**.

 Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode. Setting up your gaming mouse as a Bluetooth® wireless

Pairing Bluetooth® mode to additional host devices (max. 3)

h to the **Blue**

Press and hold the **Pairing** button for 3 seconds until the LED on

your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Set the connection switch to the **Bluetooth® mode**.

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your carrier mouse. has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. ownload and install the Armoury Crate software from

https://rog.asus.com Follow the software instructions to update your gaming mouse and dongle's firmware. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up.
Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the Press the DPI button once you have finished customizing the DPI

Updating the firmware and customization

Download and install the Armoury Crate software from

bothmout dinistant the Armoury Cate software from https://rog.asus.com
 Follow the software instructions to update your gaming mouse and dongle's firmware.
 Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

Press the DPI button once you have finished customizing the DPI

value to save the changes made

and dongle's firmware.

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer Setting up your gaming mouse as a RF wireless mouse

 Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode Setting up your gaming mouse as a Bluetooth® wireless

mouse Set the connection switch to the Bluetooth® mode.

Pairing Bluetooth® mode to additional host devices (max. 3)

Iring Bluetooth* mode to additional host devices (max. 3) Set the connection switch to the Bluetooth* mode. Press and hold the Pairing button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfull y paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

rnload and install the Armoury Crate software from

The DPI On-The-Scroll tuning function allows you to customize the

DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

The LED color hue on your mouse will differ depending on the

Connecting your gaming mouse

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer

Setting up your gaming mouse as a RF wireless mouse

Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode.

Setting up your gaming mouse as a Bluetooth® wireless

<u>mouse</u> Set the connection switch to the **Bluetooth® mode**.

Pairing Bluetooth® mode to additional host devices (max. 3)

Set the connection switch to the **Bluetooth**" **mode**.

Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Updating the firmware and customization

Download and install the Armoury Crate software from

https://rog.asus.com Follow the software instructions to update your gaming mouse and dongle's firmware.

Customize your gaming mouse using Armoury Crate.

The DPI On-The-Scroll tuning function allows you to customize the DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

Press the DPI button once you have finished customizing the DPI value to save the changes made

质不致发生外泄或突变,从而对环境造成 10

部件名称						
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板及电子组件	×	0	0	0	0	0
塑胶外壳	0	0	0	0	0	0
按键	0	0	0	0	0	0
外部信号连接头及线材	0	0	0	0	0	0
电池	×	0	0	0	0	0
本表格依据 S./T 11364 的规定编制。 〇:表示该有害物质在设部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。 ×:表示该有害物质至少在该部件的某一均原材料中的含量超出 GB/T 26572 规定的限量要求,然该部件仍符合欲置指令 2011/65/EU 的规范。 备注:此产品所标元之环保使用期限,系指在一般正常使用扰然下。						

Updating the firmware and customization

https://rog.asus.com Follow the software instructions to update your gaming mouse

DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your

The LED color hue on your mouse will differ depending on the

DPI adjustment.
Press the DPI button once you have finished customizing the DPI

Updating the firmware and customization

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

https://rog.asus.com
. Follow the software instructions to update your gaming mouse and dongle's firmware.
. Customize your gaming mouse using Armoury Crate.

Using the DPI On-The-Scroll tuning function

gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

is the DPI button once you have finished customizing the DPI

tion with this product. Never use accessories for other products to 付属品は本製品専用です。本製品を使用の際には、必ず製品パッケージに付属のも

をお使いください。また、付属品は絶対他の製品には使用しないでください。製品破員もしくは、火災や感電の原因となる場合があります。 Compliance Statement of Innovation, Science and Eco

This device complies with Innovation, Science and Economic Development Canada incence exempt RSS standard(s). Operation is subject to the following two cond (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Déclaration de conformité de Innovation, Sciences et

ouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage ra bi, même si le brouillage et suppareil doit accepter tout brouillage ra CAN ICES-003(B)/NMB-003(B)

Radio Frequency (RF) Exposure Information

This device has been evaluated for and shown compliant with the ISED Specific Absorption Rate ("SAR") limits when operated in portable exposure conditions.

Informations concernant l'exposition aux fréquences radio (RF) La puissance de sortie rayonnée du dispositif sans fil est inférieure aux limites d'exposition aux radiofréquences d'Innovation, Sciences et Développement économique Canada (ISED). Le dispositif sans fil doit être utilisé de manière à minimiser le potentiel de contact humain pendant le fonctionnement normal.

Complying with the REACH (Registration, Evaluation, Authorisation, and Restriction of Chemicals) regulatory framework, we published the chemical substances in our products at ASUS REACH website at https://csrasus.com/english/REACH.htm.

ASUS recycling and takeback programs come from our commitme standards for protecting our environment. We believe in providing to be able to responsibly recycle our products, batteries, other cor



Lithium-Ion Battery Warning —

CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer

NCC: Wireless Statement

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率 加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合 法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法 通信,指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、

VCCI: Japan Compliance Statement VCCI Class B Statement

警告 VCCI準拠クラスB機器(日本)

取扱説明書に従って正しい取り扱いをして下さい。

KC: Korea Warning Statemen

B 급 기기 (가정용 방송통신기자재) 이 기기는 가정용 (B 급) 전자파적합기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

Regional notice for Singapor

Complies with

This ASUS product complies with IMDA Standards

- Précautions d'emploi de l'appareil:
- e niveau de rayonnement. Ce n'est pas toujours le cas dans ce stituations, notamment les parkings souterrains, les ascenseurs, en train ou en voiture ou tout simplement dans un secteur mal couvert par le réseau.

 Tenez cet appareil à distance du ventre des femmes enceintes et du bas-vent

ASUS Recycling/Takeback Services



科學及醫療用電波輻射性電機設備之干擾。

この装置は、情報処理装置等電波障害自主規制協議会(VCCI)の基準に基づくクラスB情 報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装 置がラジオやテレビジョン受信機に近接しaで使用されると、受信障害を引き起てする



- Soyez particulièrement vigilant quant à votre sécurité lors de l'utilisation de cet appareil dans certains lieux (les aéroports, les hôpitaux, les stations-service et les
- r cet appareil à proximité de dispositifs médicaux implantés lors éphonique. Si vous portez un implant électronique (stimulateurs

Ukraine Certification Logo

備考 1. "0" 係指該項限用物質之百分比含量未超出百分比含量基準值備考 2. "一" 係指該項限用物質為排除項目。

「產品之限用物質含有情況」之相關資訊,請參考下表



EAC Certification Logo

UKCA RF Output table (The Radio Equipment Regulations 2017)

Function	rrequency	maximum output rower (EIRF)					
2.4GHz wireless	(2403 - 2480MHz) - Mouse	10 dBm					
2.4GHZ WITEIESS	(2403 - 2480 MHz) - Dongle	10 dBm					
BLE	(2403 - 2480MHz) - Mouse	10 dBm					
CE RED RF Output table (Directive 2014/53/EU)							

(2403 - 2480MHz) - Mous Simplified UKCA Declaration of Conformity

ASUSTek Computer Inc. hereby declares that this device is in compliance with the essential requirements and other relevant provisions of The Radio Equipment Regulation 2017 (S.I. 2017/1206). Full text of UKCA declaration of conformity is available at https://www.asus.com/support/. CE Mark Warning



English ASUSTeK Computer Inc. hereby declares that this device is in with the essential requirements and other relevant provisions of relaturation of conformity is available at: www.asus.com Français AsusTek Computer Inc. déclare par la présente que cet appa aux critèree sesentiels et autres clauses pertinentes des directives con

Deutsch ASDISTRE Computer Inc. erklärt hiermit, dass dieses Gerät mit den wesentlichen Anforderungen und anderen relevanten Bestimmun der zugehörigen Richtlinien übereinstimmt. Der gesamte Text der EU-Konformitätserklärung ist verfügbar unter: www.aus.us.com/support

Подровную винформацию, пожалунста, смотрите на <u>www.astus.com/support</u>

Български С настоящиото ASUTEK C Computer In с. дескарира, че това устройство е в съответствие със съществените изисквания и другите приложими постановления на выправните придожими постановления на выправните придожими постановления на выправните приментами. Тамира на ЕС с достъпна на адрес <u>www.astus.com/support</u>

H-wtastik ASUSTEK Computer Inc. ovim tiglavljuje da je ovaj uredaj sukladan s bitnim zahtjevima i ostalim odgovarajućim odredbama vezanih direktiva. Cijeli tekst EU izilave o sukladnosti dostupan je na <u>www.astus.com/support</u>

Castina Společnost ASUSTEK Computer Inc. timto prohlašuje, že toto zařízení splňuje základní požadavky a dalá příslušná ustanovení souvisejích smerin. Plné znění prohlášení o shodě EU je k dispozicí na adrese: <u>www.astus.com/support</u>

ния ASUS заявляет, что это устройство соответствует

Dansk ASUSTEK Computer Inc. erklærer hermed, at denne enhed er overensstemmelse med hovedkravene og andre relevante bestemm relaterede direktiver. Hele EU-overensstemmelseserklæringen kan fii

Eesti Käesolevaga kinnitab ASUSTeK Computer Inc, et see seade vastab asjakohaste direktiivide oluliste nõuetele ja teistele asjassepuutuvatele si vastavusdeklaratsiooni täielik tekst on saadaval järgmisel aadressil: www. <u>ott</u> ni. ASUSTeK Computer Inc. ilmoittaa täten, että tämä laite on asiaank iivien olennaisten vaatimusten ja muiden tätä koskevien säädösten idenmukaisuusilmoituksen koko teksti on luettavissa osoitteessa: <u>w</u>

Com/support

Ελληνικά Με το παρόν, η AsusTek Computer Inc. δηλώνει ότι αυτή η συσκευή
συμμορφώνεται με τις θεμελιώδεις απαιτήσεις και άλλες σχετικές διατάξεις των
Οδηγιών της Ε.Τ. ο πλήρες κείμενο της δηλωσης συμβατότητας είναι διαθέσιμο στι
διεύθυνση: www.asus.com/support

Magyar Az ASUSTeK Computer Inc. ezennel kijelenti, hogy ez az eszköz megfelel
a kapcsolódo Irányelvek lényeges követelménvelnek és anadás unanatása.

reikalavimus ir kitas svarblas susijusių direktyvų nuostatas. Visą ES attitkties deklaracijos tekstą aalima rasti - waw.asus.com/support Norsik ASUSTek Computer Inc. erklarers herved at denne enhetne er i samsvar med hovedsaklige kitav ao gandre relevante forskrifter i relater te direktiver. Fullstendig teks for EU-samsvarserklæringen finnes på: www.asus.com/support Polski Firma ASUSTek Computer Inc. nineljezym oświadcza, że urządzenie to piest zgodne z zasadniczymi wymogami i innymi właściwymi postanowieniami powiązanych dyrektyw. Pehry tekst deklaracji zgodności UE jest dostępny pod adresem: www.asus.com/support **Português** A ASUSTEK Computer Inc. declara que este dispositivo está em conformidade com os requisitos essenciais e outras disposições relevantes das

im os requisitos essericiais e outras disposiço nadas. Texto integral da declaração da UE disp aus SUSTeK Computer Inc. declară că acest dispozitiv se conformează sențiale și altor prevederi relevante ale directivelor conexe. Textul comple ei de conformitate a Uniunii Europene se găsește la: <u>www.asus.com/</u>

<u>Support</u>

Srpski AUSTEK Computer Inc. ovim izjavljuje da je ovaj uređaj u saglasnosti sa osnovnim zahtevima i drugim relevantnim odredbama povezanih Direktiva. Pun teks EU deklaracije o usaglašenosti je dostupan da adresi: <u>www.asus.com/support</u>

Slovensky Spoločnosť ASUSTeK Computer Inc. týmto vyhlasuje, že toto zariadenie vyhovuje základným požiadavkám a ostatým príslušným ustanoveniam príslušných опизирия: lovenščina ASUSTeK Computer Inc. izjavlja, da je ta naprava skladna z bistvenimi sklavnom in druzimi ustraznimi določbami novezanih direktiv. Celotno besedilo EL

somisəyipəri. T**ürkçe** AsusTek Computer İnc., bu aygıtın temel gereksinimlerle ve ilişkili Yönergeleri diğer ilgili koşullarıyla uyumlu olduğunu beyan eder. AB uygunluk bildiriminin tam

nski ASUSTeK Computer Inc. ovim izjavljuje da je ovaj uređaj usklađen sa bitnim ע**ברית** ASUSTek Computer Inc. מצהירה בזאת כי מכשיר זה תואם לדרישות החיוניות ולשאר הסעיפים הרלוונטיים של תקנה. ניתן לקרוא את הנוסח המלא של ו התאימות הרגולטורית עבור האיחוד האירופי בכתובת: www.asus.com/support

Service and Support Visit our multi-language website at https://www.asus.com/support/



Connecting your gaming mouse Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer

Setting up your gaming mouse as a Bluetooth® wireless mouse
Set the connection switch to the **Bluetooth® mode**.

Setting up your gaming mouse as a RF wireless mouse

Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode.

Pairing Bluetooth® mode to additional host devices (max. 3) iring Bluetooth* mode to additional host devices (max. 3) Set the connection switch to the Bluetooth* mode. Press and hold the Pairing button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming

mouse will light up blue for 3 seconds.

Updating the firmware and customization Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port. Download and install the Armoury Crate software from

https://rog.asus.com Follow the software instructions to update your gaming mouse

Customize your gaming mouse using Armoury Crate. Using the DPI On-The-Scroll tuning function The DPI On-The-Scroll tuning function allows you to customize the

DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up.

Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the

Press the DPI button once you have finished customizing the DPI value to save the changes made.

Setting up your gaming mouse as a wired mouse Connect the bundled USB Type-C° to Type-A cable to your gaming mouse and a USB port on your computer

 Connect the USB dongle to a USB port on your computer.
 Set the connection switch to the RF 2.4G Wireless mode Setting up your gaming mouse as a Bluetooth® wireless

Setting up your gaming mouse as a RF wireless mouse

Connecting your gaming mouse

Set the connection switch to the **Bluetooth® mode**. Pairing Bluetooth® mode to additional host devices (max. 3)

1. Set the connection switch to the **Bluetooth® mode**.
2. Press and hold the **Pairing** button for 3 seconds until the LED on your gaming mouse start to blink blue. Once your gaming mouse has been successfully paired, the LED indicator on your gaming mouse will light up blue for 3 seconds.

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

- Using the DPI On-The-Scroll tuning function
- gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI. The LED color hue on your mouse will differ depending on the

Connect your gaming mouse to your computer using the bundled cable, then connect the USB dongle to a USB port.

Download and install the Armoury Crate software from https://rog.asus.com Follow the software instructions to update your gaming mouse

Customize your gaming mouse using Armoury Crate.

and dongle's firmware.

Updating the firmware and customization

DPI of your gaming mouse without using Armoury Crate.

1. Press and hold the DPI button for 3 seconds until the LED on your gaming mouse light up. Scroll the scroll wheel forwards or backwards to adjust the DPI.

The LED color hue on your mouse will differ depending on the

Using the DPI On-The-Scroll tuning function

Press the DPI button once you have finished customizing the DPI value to save the changes made.

The DPI On-The-Scroll tuning function allows you to customize the

Safety Guidelines

Keep the device away from liquid, humidity, or moisture. Operate the device only within the specific temperature range of 0°C(32°F) to 40°C(104°F). When the device exceeds the maximum temperature, unplug or switch off the device to let it cool down.

此滑鼠只應在溫度不高於 40°C(104°F)的環境下使用。 安裝錯誤型號的電池可能會導致爆炸。

本产品为微功率设备,消费者使用时应遵守以下规范,以免造成危害或损伤。 (一)本产品2.4G微功率模式使用频率为;2400-2483.5MHz发射功率限值;10mW(c.i.r.p),频率容限;75kHz搭载2.4GHz无线技术,透过USB Dongle配对连接PC,提供低延迟音讯

(一)本产品2.4G微功率模式使用频率为2400-2483.5MHz.发射功率限值: 10mW(ci.r.p),频率容限: 75kHz搭载2.4GHz无线技术。透过USB Dongle配对连接PC,提供低差迟音讯 传输: 符合"微功率短距离天线电发射设备目录和技术要求":

(三)不得附值改变使用场保护文块频解率范围,加大发射功率(包括额外加装射频功率放大器),不得擅自更改发射天线;

(三)不得对其他合法的无线电台(站)产生有害干扰,也不得提出免受有害干扰保护;
(四)应当承受辐射制制能量的工业、科学及医疗(ISM)应用设备的干扰成其他合法的天线电台(站)干扰;
(四)应当承受辐射制制能量的工业、科学及医疗(ISM)应用设备的干扰成其他合法的天线电台(站)干扰;
(四)应当承受辐射制制能量的工业、科学及医疗(ISM)应用设备的干扰成其他合法的天线电台(站)干扰;
(四)应当承受辐射制能量的工业、科学及压疗(ISM)应用设备的干扰成其他合法的天线电台(站)干扰;
(元) 新以某他合法的无线电台(站)产生有害于产时,应应即使上使用,并来取措能资格下状后方可继续使用;
(六)在新空器内和依据法律法模、国家有关规定、标准则投切射电天空人一气象雷达站;卫星地球站(合测控、濒散、导航站)等军民用无线电台(站)、机场等的电磁环境保护区域内使用微功率设备。应当遵守电磁环境保护及相关行业主管部门的规定;
(七)禁止在以机场地设中心点为脆点、半径5000米的区域内使用发表模型递控器;
(八)本产品使用时工作温度为0~45度,工作电压3.4-4.2V。

Notices

Limitation of Liability

Circumstances may arise where because of a default on ASUS' part or other liability, you are entitled to recover damages from ASUS. In each such instance, regardless of the basis on which you are entitled to claim damages from ASUS, ASUS is liable for more than damages for bodily injury (including death) and damage to real property and tangible personal property; or any other actual and direct damages result omission or failure of performing legal duties under this Warranty Statement, up to the listed contract price of each product.

ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement. This limit also applies to ASUS' suppliers and its reseller. It is the maximum for which ASUS, its suppliers, and your reseller are collectively responsible.

UNDER NO CIRCUMSTANCES IS ASUS LIABLE FOR ANY OF THE FOLLOWING: (1) THIRD-PARTY CLAIMS AGAINST YOU FOR DAMAGES; (2) LOSS OF, OR DAMAGE TO, YOUR RECORDS OR DATE; OR (3) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR, FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES (INCLUDING LOST PROFITS OR SAVINGS), EVEN IF ASUS, ITS SUPPLIERS OR YOUR RESELLER IS INFORMED OF THEIR POSSIBILITY.

This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposur to radio frequency (RF) energy set by the Federal Communications Commission of the communications of orption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are

anducted using standard operating positions accepted by the FCC with the EUT ansmitting at the specified power level in different channels. he FCC has granted an Equipment Authorization for this device with all reported AR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR nformation on this device is on file with the FCC and can be found

levice complies with Part 15 of the FCC Rules. Operation is subject to the This device may not cause harmful interference. This device must accept any interference received including int

Federal Communications Commission Statement

quipment has been tested and found to comply with the limits for a Class tal device, pursuant to Part 15 of the FCC Rules. These limits are designed is equipment no best of the FCC Rules. These limits are usaspined provide reasonable protection against harmful interference in a residential stallation. This equipment generates, uses and can radiate radio frequency ener nd, if not installed and used in accordance with manufacturer's instructions, man ause harmful interference to radio or television reception, which can be determine by turning the equipment off and on, the user is encouraged to try to correct the nterference by one or more of the following measures:

Recircitor or locate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment to an outlet on a circuit different from that to which the

CAUTION! The use of shielded cables for connection of the monitor to the graphic card is required to assure compliance with FCC regulations. Changes or modification to this unit not expressly approved by the party responsible for compliance could the user's authority to operate this equipment. Accessories that came with this product have been designed and verified for the

receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

ment Canada (ISED)

Développement économique Canada (ISED)

	电子电气产品有害物质限制使用标识:图中之数字为产品之环保使用期限。仅指电子电气产品中含有的有害污染或对人身、财产造成严重损害的期限。								
名称	有害物质								
		_	_		_	-			

ASUSTEK (UK) LIMITED uthorized Representative in United Kingdom st Floor, Sackville House, 143-149 Fenchurch Street, London, EC3M 6BL England

Номер для пользователей в Москве: +7(495)231-1999

Официальные сайты ASUS в России:

www.asus.com/ru/support

dress, City uthorized Rep ntative in Europe ASUS COMPUTER GmbH larkortstrasse 21-23, 40880 Ratinger

ASUSTek COMPUTER INC. Manufacture

Горячая линия Службы технической поддержки в России Бесплатный федеральный номер для звонков по России: 8-800-100-278