

# **ATTACHMENT E.**

## **- USER'S MANUAL**

## U.S.A.

### U.S.FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT INFORMATION TO THE USER

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet of a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for assistance.

Changes or modification not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Connecting of peripherals requires the use of grounded shielded signal cables.

Car battery

### FM STEREO TRANSMITTER MANUAL


#### 1. Summary

It is the device, which transmits the stereo audio signal to FM stereo signal by wireless so as to rec

#### 2. Specification


- Output Frequencies : 88.1 ~ 88.7MHz(User selectable)
- Input audio signal :
- Input audio frequencies : 50Hz ~ 15KHz
- Method of modulation : FM
- Type of radiowave :
- Type of communication : one way communication
- Number of channels : 4
- Electric field strength :
- Input Power : 1.5V AAA battery X 2 / DC 12V **(Car battery only)**
- Operating temperature : 0 ~ 40°C

#### 3. Appearance



\* Input power φ3.5 DC PLUG (Inside: +, Outside: -)

#### 4. Frequency selection



#### 5. Specification of antenna

- The positive circuit such as amplifier is not added between aerial wire (antenna) and transmitter
- Tye of aerial wire :
- Connection type of transmitter : built-in earcode type
- The polarization characteristic of the aerial wire : vertically polarized wave

\* Please refer to the additional drawing for the details

#### 6. GST-100 use 1.5V AAA battery X 2 and Car battery only.