

AIRE K17

Slim Wireless Touchpad Keyboard

User's Manual



Product Information

GIGABYTE

Model No.: GK-AIRE K17

Model Name : Slim Wireless Touchpad Keyboard

Receiver Model No.: AIREK17RX

Model Name: Wireless Receiver

All other brands and trademarks are the properties of their respective owners.

The product specifications are subject to change without notice.

How to Start Your Keyboard

1. Turn on your keyboard and mobile device.
2. Pull out the dongle from the back of the keyboard inside the lid.
3. Plug your dongle into the USB port of your device.
4. Make sure to turn ON the keyboard.
5. The blue LED would shine if the keyboard turns on.

Use Your Keyboard

1. Just type normally as the original keyboard you are using.
2. Functions printed BLUE on the keyboard is to be activated when pressing FN key at the same time.
3. Before using figures printed BLUE on the keyboard, please make sure numberlock function is ON.
4. Note: The unit offers a strong power saving management. When you put it away for more than 30 seconds, the indication light will turn off. Once the keyboard accesses sleeping mode, to clip any key on the keyboard is compulsory to wake it up.
5. There is a power on/off switch designed to save the batteries power while non-usage of a longer period.

Multi-Media Control Touchpad & Indication Light

Control your TV-connected laptop and easily turn up/down the volume, open default browser or media player by the keyboard without leaving your coach!

1. Power On: The blue light will shine for 5 seconds, then fade out.
2. Touchpad (icon)
Press this icon, and the blue light shines. Use the touchpad the same way as your notebook. *The actual left/right keys serve function regardless of the mode.
3. Calculator (icon)
Press this icon, and the white light shines. Press the white icons just like using number pad. *Please make sure numberlock function is ON before using.
4. Function (icon)
Press this icon, and the azure light shines. Press the azure functions keys to make it work.
5. Media (icon)
Press this icon, and the dark-pink light shines. Press the dark-pink media keys to activate functions.

Charge the batteries

1. There is a micro-USB nano-receiver. Use the micro-USB line in the box to charge the batteries by plugging the other side into the USB port. The BLUE indicator light will start to blink to show that the battery is charging.
2. Charge your keyboard until the indication light stops blinking.
3. The red LED light indicates that batteries inside needs to be re-charged.

Rechargeable battery notice

Danger

Do not attempt to disassemble or modify the battery pack. Attempting to do so can cause an explosion, or liquid leakage from the battery pack. A battery pack other than the one specified, or a disassembled or modified battery pack is not covered by the warranty.

Built-in rechargeable battery notice

Danger

Do not attempt to replace the internal rechargeable lithium batteries. Please contact support for replacement.

Troubleshooting and Tips:

1. Make sure you have connected the receiver correctly on the PC's USB port
2. For the best performance, we suggest you to locate the receiver with a distance from other electric devices, such as the computer monitor or external storage devices
3. Make sure you have set the communications between the receiver and the keyboard. Refer to the communication section.
4. Some system devices might conflict with the keyboard. Confirm the IRQ/address settings of these devices for conflicts, and change the settings as required.
5. When the battery is low, the RED indication light will start blinking. Please charge the batteries.
6. When your keyboard is inactive, it will enter standby mode. The keyboard lights will turn off. Your keyboard is not broken or powered off. Press any key and wait for three seconds, and the keyboard will revert to its normal state.
7. To prolong keyboard life, we suggest switching off the power after each use.
8. Some multi-function keys (eg. Windows, capslock. print, home, play, next, previous, mute, and scroll-lock, etc.) may not be effective or activate certain programs on mobile devices.

Attention

1. Keep away from sharp objects.
2. Do not put objects on the keyboard.
3. Do not force or distort the keyboard.
4. Avoid contact with liquid or food.
5. Do not drop keyboard.
6. Keys may be wiped gently with damp cloth only. Do not soak the keys in water.
Only clean the keyboard when it's powered off.

FCC Statement

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example-use only shielded interface cables when connecting to computer or peripheral devices).

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference. and
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
-



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end its life separately from your household waste. There are separate collection system for recycling in the EU.

For more information, please contact the local authority or your retailer where you purchased the product.