

www.tuv.com


1.6 User Manual








1.



2.









ENGLISH

PLEASE NOTE: Before using your new Jabra WAVE headset, charge and pair it with your selected *Bluetooth® wireless technology* enabled device.

1 ABOUT YOUR JABRA WAVE

- A Answer/end button
- B On/off button
- C StatusDisplay™ with battery indicator and *Bluetooth®* connection indicator
- D Charging socket
- E Volume up/down
- F Jabra Comfort Eargel™

2 HOW THE DISPLAY WORKS

<p><i>Bluetooth®</i> Indicator</p> 	<p>Indicates if your headset is connected to your phone</p> <ul style="list-style-type: none"> - Solid light means headset is connected to your phone - Flashing light means headset is in 'pairing mode' and ready to be connected to a new phone
<p>Battery Indicator</p> 	<p>Indicates battery level and if headset is turned ON</p> <ul style="list-style-type: none"> - Green light indicates that the headset has more than 30 minutes of talk time remaining - Red light indicates that the headset has less than 30 minutes of talk time remaining

Tap volume up or volume down to get a status indication from the Jabra StatusDisplay™.

3 JABRA VOICE ALERTS

3.1: Connection Voice Alert:

When your headset has successfully established connection with your phone and is ready

to be used, the Jabra Voice Alert will say "connected".

3.2: Battery Low Voice Alert:

When your headset has battery for less than 30 minutes the Jabra voice alert will say "low battery". This message will be repeated with a ten minute interval

4 CHARGE YOUR HEADSET

The charging socket can be accessed by lifting the rubber cover on the back of the headset. While charging the headset, the battery indicator will be solid red. When the headset is charged, the battery indicator will turn solid green and turn off after 5 minutes. Charging time is approximately 2 hours.

5 TURNING YOUR HEADSET ON AND OFF

Slide the "on/off" button to turn the headset on or off. The StatusDisplay™ will light up when the headset is turned on.

6 PAIRING THE HEADSET WITH YOUR PHONE

6.1a: First time pairing:

Turn the headset on - the headset is in automatic pairing mode when the *Bluetooth*® connection indicator is flashing blue.

6.1b: Later pairing:

Turn the headset on. Press and hold the answer/end button until the *Bluetooth*® connection indicator is flashing blue.

6.2 Activate *Bluetooth*® on your phone. Then set your phone to search for *Bluetooth*® wireless technology enabled devices and select Jabra WAVE.

6.3 Press 'OK' on the phone and if you are asked for a PIN code, confirm with PIN code 0000 (4 zeros).

7 USING YOUR HEADSET

Answering or ending a call

- Tap (less than 1sec) the answer/end button on your headset to answer a call.

Make a call

- The call will automatically transfer to your headset*. If it does not, please tap the

Visit www.jabra.com/WAVE for full user manual

answer/end button on your headset.

Reject a call *

- Press (approx 1 sec) the answer/end button.

Activate voice dialing *

- Press the answer/end button. For best results, record the voice-dialing tag through your headset.

Redial last number *

- Double tap the answer/end button when the headset is connected to your phone.

Adjust sound and volume *

- Tap the volume up or down to adjust the volume.

8 WEARING STYLE

You can wear your Jabra "WAVE" on left or right ear. Simply turn the Jabra Comfort Eargel 180 degrees to change from right to left ear wearing.

WARNING!

Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low a volume as possible.

Headsets are capable of delivering sounds at loud volumes and high pitched tones. Under certain circumstances, exposure to such sounds can result in permanent hearing loss damage. The volume level may vary based on conditions such as the phone you are using, its reception and volume settings, and the environment. Avoid prolonged use of the headset at excessive sound pressure levels. Please read the safety guidelines below prior to using this headset.

You can reduce the risk of hearing damage by following these safety guidelines:

1. Prior to using this product follow these steps

- Before putting on the headset, turn the volume control to its lowest level;
- Put the headset on; and then
- Slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible and avoid using the headset in noisy environments where you may be inclined to turn up the volume;
- If increased volume is necessary, adjust the volume control slowly;
- Ringing in the ears may indicate that the sound levels are too high;
- If you experience discomfort or ringing in your ears, immediately discontinue using the headset and consult a physician; and
- Stop using the headset if it causes great discomfort.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

SAFETY INFORMATION!

- Use of a headset will impair your ability to hear other sounds. Use caution while using your headset when you are engaging in any activity that requires your full attention.
- If you have a pacemaker or other electrical medical devices, you should consult your physician before using this product.

81-03046 B

- This package contains small parts that may be hazardous to children and should be kept out of reach from children. This product is not a toy – never allow children to play with this product. Always store the product out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.
- Never try to dismantle the product yourself, or push objects of any kind into the products, as this may cause short circuits which could result in a fire or electric shock.
- None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.
- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- If the product has ear tips, the ear tips should rest against, but not enter the ear canal.
- Keep all products, cords, and cables away from operating machinery.
- Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals, blasting areas, potentially explosive atmospheres, or aircrafts.
- If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact GN Netcom, Inc.
- Never mount or store the product over any airbag deployment area, as serious injury may result when an airbag deploys.
- Do not use in areas where there are explosive hazards.
- Dispose of the product according to local standards and regulations.

Remember: Always drive safely, avoid distractions and follow local laws!

Using the headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws. Use caution while using your headset when you are engaging in

any activity that requires your full attention. While engaging in any such activity, removing the headset from your ear or turning off your headset will keep you from being distracted, so as to avoid accident or injury. Do not take notes or read documents while driving.

EN

BUILT-IN BATTERY CARE: Please observe the following if the product contains a battery

- Your product is powered by a rechargeable battery.
- The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out.
- Unplug the charger from the electrical plug and the product when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the product in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the battery.
- Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A product with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Battery warning!

- "Caution" – The battery used in this product may present a risk of fire or chemical burn if mistreated.
- Do not attempt to open the product or replace the battery. It is built-in and not changeable. Use of other batteries may present a risk of fire or explosion and the warranty will be terminated.
- Only recharge your battery with the provided approved chargers designated for this product.
- Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode.
- Batteries may explode if damaged.

CHARGER CARE: Please observe the following if the product is supplied with a charger

- Do not attempt to charge your headset with anything other than the AC adapter provided. The use of any other types may damage or destroy the headset and could be dangerous. Use of other chargers may invalidate any approval or warranty. For availability of approved enhancements, please check with your dealer.

- Charge the product according to the instructions supplied with the product.

Important: Please refer to the user manual for a description of the charging status indicator lights. Some headsets cannot be used while charging.

Charger warning!

- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord. Never use a charger that is damaged.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock. Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Avoid charging your headset in extremely high or low temperatures and do not use the charger outdoors or in damp areas.

The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. Other trademarks and trade names are those of their respective owners.

FCC (wireless equipment):

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference.

Changes or modifications not expressly approved by Jabra GN Netcom, Inc. will void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

EN

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This headset, like other radio devices, emits radio frequency electromagnetic energy. The level of energy emitted by this device, however, is less than the electromagnetic energy emitted by other wireless devices such as mobile phones. The headset operates within the guidelines found in radio frequency safety standards and recommendations. These standards and recommendations reflect the consensus of the scientific community and result from deliberations of panels and committees of scientists who continually review and interpret the extensive research literature.

FCC (corded equipment):

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

The device may not be connected directly to the telephone network, but must connect to a FCC registered telephone.