### Safety precautions

### Information for parents

Please read the operating instructions and safety precautions carefully before use.

Explain the content to your children and the hazards associated with using the Bluetooth™ Headset.



Remember to comply with legal requirements and local restrictions when using the Bluetooth™ Headset. For example in aeroplanes, petrol stations, hospitals or while driving.



Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Maintain a minimum distance of 20 cm between the Bluetooth™ Headset and a pacemaker. When using the Bluetooth™ Headset hold it to the ear which is further away from the pacemaker. For more information consult your doctor.



The earpiece can be removed. Caution! Small parts like this could be swallowed by young children



The main voltage (V) specified on the power supply unit must not be exceeded. Otherwise the charging device may be destroyed.



Do not throw the device onto an open fire.



Only use original Siemens charging devices and batteries (100 % mercury-free). Otherwise you risk serious damage to health and property. The battery could explode, for instance.



The Bluetooth™ Headset must not be opened. Only changing the battery (100 % mercury-free) is permissible. You must not open the battery under any circumstances. Any other changes to this device are strictly prohibited and will invalidate the operating licence.

### Important:



Dispose of used batteries and Bluetooth™ Headsets according to the legal regulations.



The Bluetooth™ Headset can interfere with the operation of nearby TVs, radios or PCs.



Use only Siemens original accessories. In this way you will avoid possible health risks and damage to the product and ensure compliance with all relevant provisions.

Improper use will invalidate the guarantee!

### Note

In some countries there may be restrictions on the use of Bluetooth™ devices. Please check with the relevant authorities.

### **Headset overview**

### PTT key (Push-To-Talk key) Press briefly: to activate voice dialling or to accept a call. Hold down: to end a call. Mute key Switches the microphone to mute Volume rocker switch + key. Press for: louder key. Press for: quieter Ear hook **Charging socket** Loudspeaker with earpiece LED Indicates different states of the headset (p. 14) On/Off switch

Charging socket

Microphone

### Meaning of the LED display

The light emitting diode (LED) indicates the different states of the headset:

### Note

rapidly Off

The colour of the LED depends on the

charge status. When it is:
RED the battery is empty, and
GREEN there is sufficient battery power.

power.	
Steady GREEN	Indicates end of charging process.
Steady RED	Battery charging.
Flashes RED x3	Battery empty.
Constant illumination	During registration.
Flashes x5	Registration completed successfully.
Flashes x5	The headset has been reset to the default settings.
Flashes slowly	The headset is ready for operation
Flashes rapidly	<ul><li>Incoming call or</li><li>During a call</li></ul>

Headset switched off.

### Adjusting the headset

To ensure your Bluetooth™ headset rests comfortably on your ear, you can reposition the ear hook so the headset can be worn on either ear.

- 1. Pull the ear hook off back-
- 2. Turn the ear hook and carefully push it back into posi-
- for the right ear:



• for the left ear:



## Wearing the headset correctly

Wear the Bluetooth™ headset as shown in the diagram. The microphone should always point towards your mouth.



### What is Bluetooth?

Bluetooth™ is a short-range radio connection. It enables wireless communication between various terminals equipped with Bluetooth™.

The Bluetooth™ headset will only work in conjunction with a Bluetooth™-enabled mobile phone capable of supporting the headset profile, such as the Siemens S65 or the XX. The handsfree profile is preferred. Please read the notes on Bluetooth™ connections in the user guide for your mobile phone as the controls and display messages differ between phones.

Every Bluetooth™ device has a unique address and name. This ensures that it communicates with the right partner. The security concept is based on a password that the two devices exchange when they first register (p. 16).

### **Getting started**

Before you can use the Bluetooth  $^{\text{TM}}$  headset you need to:

- · charge the headset, and
- register the headset with the mobile phone.

## Charging the Bluetooth headset

As supplied, the battery is not yet fully charged.

To charge the headset you will need the charging device included in the scope of delivery.

If an ECA-500\* charging adapter is used the headset can also be charged with a Siemens Traveler Charger ETC-500/510\* or Siemens Car Charger Plus ECC-600\*.

\* These products are available from the range of original Siemens accessories.

© Siemens AG 2001, L:Mobil\Bluetooth-Headset\en\Bluetooth\_Headset\_en.fm



- 1. Insert the charging device connector ② into the headset ① as shown.
- 2. Insert the mains plug on the charging device into the mains socket.

#### Charging time

An empty battery is fully charged after about 2.5 hours.

#### Display while charging

The headset switches off automatically when it is connected to a charging device. The LED is red during charging. When the battery is fully charged the LED turns green.

Only charge the battery when the temperature is between 0 °C and 45 °C. Otherwise it will wear out prematurely.

## Registering the headset with a mobile phone

The headset must be switched on.

- Hold down the mute key and the ⊕ key simultaneously for at least 3 seconds. The LED will come on. Your mobile phone can now "search" for the Bluetooth™ headset.
- 2. Activate search mode on your mobile phone. To do this please read the notes in the user guide for your mobile phone.
- 3. When the mobile phone finds your headset this will be shown on the mobile phone display with the device name HHB-600.

If your mobile phone cannot find the headset within 3 minutes you will need to reactivate search mode (repeat step 1).

4. If requested, enter the password (PIN) for the headset into your mobile phone:

The Bluetooth™ headset is now registered with the mobile phone.

© Siemens AG 2001, L:\Mobil\Bluetooth-Headset\en\Bluetooth\_Headset\_en.fm

## Switching the Bluetooth headset on and off

Push the On/Off switch to the ON position (I). The headset is switched on. The LED flashes.

To switch off, push the On/Off switch to the off position (0).

### Resetting

To register the Bluetooth™ headset with another mobile phone you must reset the headset to the default settings:

- 1. Switch the headset on (see above).
- 2. Then press the PTT key and the key on the headset simultaneously for at least 3 seconds. The LED will flash rapidly five times.

The headset has now been reset to the original default settings. You can now register the headset with another mobile phone (p. 16).

### Calling

To use the headset to make a call, the headset must be switched on (see left) and a connection must be established with a mobile phone (p. 16).

The procedures described below only apply to Siemens mobile phones. Different procedures may be required for mobile phones made by other manufacturers

The following symbols are used to explain operation:

**8!** [

Function depends on the service provider; special registration may be necessary.

- You will know that a call is about to be interrupted if the signal quality is
- poor.

  If the mobile phone is not connected to the network you will hear a repeated high-pitched tone in your headset.

  If the Bluetooth™ connection to the
- If the Bluetooth™ connection to the mobile phone is interrupted for several seconds during a call, you can only continue the call from the mobile phone.

### Voice dialling

You can only dial numbers by voice command. A voice recording of the name must be stored with the phone number in the mobile phone address book. Please read the mobile phone user guide.

This function is not supported by all mobile phones.

- 1. Press the PTT key briefly.
- 2. Say the name.

  If the name is recognised the mobile phone will dial the relevant phone number.

  If the name is not recognised, press the PTT key again to redial.

## Dialling using the mobile phone

- 1. Dial as normal using the mobile phone.
- 2. Press the PTT key **briefly** to continue the call using the headset.

### Ending a call

**Hold down** the PTT key. The call is ended. The headset remains ready for operation.

### Setting the volume

Use the rocker switch to set the volume.

The volume setting on the headset does not affect the settings on the mobile phone.

### Accepting a call

Press the PTT key **briefly**.

### Holding a call

Press the PTT key **briefly**. To continue the call press the PTT key again.

### 8

#### Call waiting

During a call, you may be advised that there is another call waiting. You will hear a special tone during the call.

To accept the new call, press the PTT key. The existing call is put on hold.

You have the following options:

#### Swapping

To swap between the two calls, press the PTT key **briefly**.

### Rejecting the current call

**Hold down** the PTT key. The active call is ended.

The second call is put on hold. Press the PTT key **briefly** to resume this call.

### Picking up a call

From the phone to the headset Press the PTT key briefly.

### From the headset to the phone

Use the control keys on the mobile phone. Please read the phone's user guide.

### Muting the microphone

You can mute the microphone during a call. The recipient can no longer hear you. To do this, press the mute key.

### Device information/ caring for your headset

### Maintenance advice

- Clean the headset with a damp cloth or an anti-static cloth. Do not use chemical cleaning agents.
- Protect the headset against moisture and knocks. Do not expose your headset to direct sunlight.

### **Declaration of conformity**

FCC:

This device conforms with Part 15 of the FCC rules. Preconditions for operating the device: (1) the device causes no harmful interference, and (2) is not affected by any form of interference, including interference that can have undesirable effects.

**C€** 0681①





Canada: Licence No. IC xxxxxx



### **Technical data**

Li-ion bat- XXX mAh

approx. 2.5 hours

Standby

Charging

time

up to 150 hours

time

•

Talk time Range

Weight

up to 4 hours\* max. 10 metres,

.

less in buildings approx. 25 gram

Type of pro-IP20

tection

\* Depending on the mobile phone used

### **Customer service**

We offer fast, individual advice! You have several options:

Our online support on the Internet: www.my-siemens.com/customercare

We can be reached any time, any place. You are given 24 hour support on all aspects of our products. Here you will find an interactive fault-finding system, a compilation of the most frequently asked questions and answers, plus user guides and current software updates to download.

You will be given personal advice about our range of products on our Premium

### Germany 0190 - 74 58 26

(1.24 euros/minute)

### Austria 0900 - 30 08 08

(1.35 euros/minute)

Qualified Siemens employees are waiting to offer you expert information about our products and installation.

Should repairs become necessary please contact one of our service centres (S. 123).

### Note

When calling customer service, please have ready your receipt, the headset identity number and the phone identity number (IMEI, to display press \*#06#), the phone's software version (to display press \*#06#, then Info) and if necessary your Siemens Service customer number.