

Jabra

Jabra BT650s



User manual

www.jabra.com

CONTENTS

THANK YOU.....	2
ABOUT YOUR JABRA BT650s.....	2
WHAT YOUR HEADSET DOES.....	3
GETTING STARTED.....	4
CHARGING YOUR JABRA BT650s.....	4
TURNING YOUR JABRA BT650s ON AND OFF.....	4
PAIRING YOUR JABRA BT650s TO A PHONE OR OTHER DEVICE..	5
HOW TO.....	6
WHAT THE DISPLAY MEANS.....	8
USING YOUR JABRA BT650s WITH TWO MOBILE DEVICES.....	9
TROUBLESHOOTING & FAQ.....	9
NEED MORE HELP?.....	10
TAKING CARE OF YOUR HEADSET.....	10
WARNING!.....	11
SAFETY INFORMATION!.....	11
BUILT-IN BATTERY CARE:.....	12
CHARGER CARE:.....	13
WARRANTY.....	14
GLOSSARY.....	16

THANK YOU

Thank you for purchasing the Jabra BT650s Bluetooth® headset. We hope you enjoy it! This instruction manual will get you started and ready to make the most of your headset.

ABOUT YOUR JABRA BT650s

- 1 Answer/End or Play/Pause button**
- 2 Volume Control or Track Change touch sensor**
- 3 Hinges for folding of headset**
- 4 Battery indicator**
- 5 Bluetooth connectivity indicator**
- 6 Hinge release buttons**



WHAT YOUR HEADSET DOES

The Jabra BT650s lets you listen to stereo music through your Bluetooth enabled mobile phone or music player, while ensuring that you never miss a call.

- Play your music wirelessly
- Answer or end phone calls
- Reject incoming calls
- Last number redialing
- MultiUse™ – be connected to two Bluetooth devices at the same time (for instance your PC and mobile)
- Use 3.5mm music cable for wired music listening from e.g. your mp3 player or PC

Specifications

Music:

- Music time up to 6 hours, standby time up to 8 days
- Track changes (next or previous track) on touch control (AVRCP)
- A2DP (Advanced Audio Distribution Profile) for streaming music

Call:

- Talk time up to 8 hours
- Dual Microphone solution for **Noise Blackout™**
- Digital sound enhancement via DSP technology
- Noise reduction on transmitted and received audio
- Noise dependent volume control*
- Automatic volume adjustment on received audio
- Acoustic shock protection
- Qualified for Bluetooth Specification version 2.0 + EDR (enhanced data rate), supporting Headset and Hands-free Profiles for phone conversations and Advanced Audio Distribution Profile (A2DP) for streaming music
- e-SCO for enhanced audio quality
- 128-bit encryption

The device:

- Rechargeable battery with Micro-USB charging option from AC power supply, PC via USB cable or car charger (not included)

* Refer to phone's user manual **JABRA BT650s**

- Colored LED-lights for Bluetooth status and battery indicator
- Size Unfolded: H 165mm - 190mm x W 136mm x D 45mm
- Size Folded: H 78mm x W 132mm x D 45 mm
- Weight: 80 grams
- Operating range up to 10 meters (approximately 33 feet)

Please note that your Jabra BT650s can withstand a short rain shower but is not waterproof and cannot be submerged. If your device gets wet, it should be wiped clean of any traces of water in order to protect it from potential damage.

GETTING STARTED

Follow these three steps before using your headset:

- 1. Charge your headset (approximately 2 hours)**
- 2. Activate Bluetooth on your mobile phone (refer to the manual for your mobile phone)**
- 3. Pair your headset to your mobile phone**

CHARGING YOUR JABRA BT650s

Make sure that your Jabra BT650s is fully charged before you start using it for the first time. While charging, the battery indicator changes from red to green, when fully charged. Charging time is approximately 2h. You can use the Jabra BT650s during recharge.

Please note: The lifetime of the battery will be significantly reduced if your device is left uncharged for a long period. Jabra therefore recommends that you recharge your device at least once a month.

TURNING YOUR JABRA BT650s ON AND OFF

Unfolding the headset will turn it on.

Folding the headset will turn it off.

- To fold: Push the hinge release buttons on the inside of the headset (6) and carefully extend the headset at the hinges (3). The headset will now conveniently fold into a compact size.
- To unfold: Carefully unfold the headset until the release buttons lock into place.

The headset will automatically turn off after 10 minutes if not connected to a device.

PAIRING YOUR JABRA BT650s TO A PHONE OR OTHER DEVICE

Headsets are connected to phones or other Bluetooth devices using a procedure called 'pairing'. By following a few simple steps, pairing can be done in a matter of seconds..

1. Put the headset in pairing mode

1.a. First time pairing

- Fold and Unfold the headset and the Jabra BT650s will automatically enter pairing mode (indicator light (5) is solid blue) and start searching for a device.

1.b. Later pairing

- Press and hold the Answer/End button (1) until the indicator light (5) is solid blue (approximately 4 seconds).

2. Set your Bluetooth phone or device to search for the Jabra BT650s

- Follow your phone's instruction guide. First make sure that Bluetooth is activated on your mobile phone. Then set your phone to search for the headset. This usually involves going to a 'setup,' 'connect' or 'Bluetooth' menu on your phone and selecting the option to search for or 'add' a Bluetooth device.*

3. Your phone will find the Jabra BT650s

- The phone will find the headset under name "Jabra BT650s".
- Your phone then asks if you want to pair with the headset.
- Accept by pressing 'Yes' or 'OK' on the phone and confirm with the passkey or PIN = 0000 (4 zeros). Your phone will confirm when pairing is complete.

WEARING STYLE

Please note the left/right wearing indicators inside the headband. Alternatively always wear the Jabra BT650s with the Answer/end button on you right.

Adapt the size of your Jabra BT650s by extending the length of the headband.

HOW TO

The Jabra BT650s is easy to operate. The Answer/End button performs different functions depending on how long you press them:

Instruction	Duration of press
Tap	Press briefly
Double tap	Touch briefly two times within 1,5 seconds
Press	Approximately: 1 second
Press and hold	Approximately: 4 seconds

Play music (Some phones may require you to start a media player first)*

- Tap the Answer/End button (1).

Pause music

- Tap the Answer/End button – tap again to resume playing.

Stop music

- Press the Answer/End button.

Answer a call when playing music

- When listening to music and receiving a call, the music will pause and you will hear your ringtone.
- Tap the Answer/End button and the music will be paused and the call will be connected.

End a call

- Tap the Answer/End button to end an active call - when you end the call, your music will start again**.

Skip one track forward

- Double Tap on the + end of the touch control (2) - continue tapping to skip several tracks forward.

Skip one track back

- Double Tap on the – end of the touch control (2) - continue tapping to skip several tracks backward.

Answer a call

- Tap the Answer/End button (1) to answer a call

* Refer to phone's user manual **JABRA BT650s**

** Device dependent

End a call

- Tap the Answer/End button (1) to end an active call.

Reject a call**

- Press and hold the Answer/End button when the phone rings to reject an incoming call. Depending on your phone settings, the person who called you will either be forwarded to voice mail or hear the busy signal.

Make a call**

- When your Jabra BT650s is connected to your phone, all calls made from your phone will automatically be transferred to your headset. (subject to phone settings)

Redial last number**

- Double tap the Answer/End button.

Adjust sound and volume*

- Touch and slide your finger along the touch control (2) to turn volume up or down.

Mute microphone when on a phone call

- Double Tap on **—** or **+** on the touch control (2). Tap the touch control to un-mute.

Using your BT650s with the 3.5mm music cable (not Bluetooth)

- Insert the 3.5mm music cable into the micro-USB socket and connect the 3.5mm jack to the device. **Please note that the Bluetooth features (including receiving calls) are disabled when using the Jabra BT650s with the cable.**
- Using your BT650s with the 3.5mm music cable is not possible if the battery is completely discharged, so make sure that it is at least partly charged.

* Refer to phone's user manual

** Device dependent

WHAT THE DISPLAY MEANS

On the right inside of BT650s two display icons indicate different states of the product:

Bluetooth Icon (only Blue)	
Solid	In pairing mode – see “Pair Jabra BT650s to a phone or other device”
Slow Single Flash	Connected to phone and in standby mode ^(A)
Single Flash	Connected to phone and active on call ^(A)
Quick Double Flash	Incoming call
Solid (+ Battery Indicator Solid Orange)	In alternative pairing mode – see “Troubleshooting & FAQ”

Battery Indicator Icon :	
Solid Red	Charging
Solid Green	Fully charged
Single Red Flash	Low Battery
Slow Single Green Flash	Not connected to phone and standby mode ^(A)
Solid Orange (+ Bluetooth Icon Solid Blue)	In Special Pairing mode – see “Troubleshooting & FAQ”

^(A)BT650s Display icons turn off after 30 seconds of non-activity. Headset is still active, and light will flash again after a tap on the Answer/end button or any call activity.

Communication by sound alerts

Your Jabra BT650s employs sound alerts to communicate different actions or information. One important alert is “Low Battery”, which is two short beeps, and indicates 5 minutes of battery time remains.

USING YOUR JABRA BT650s WITH TWO MOBILE DEVICES

The Jabra BT650s is capable of having two mobile phones (or Bluetooth devices) connected to the headset at the same time. This will give you the freedom of having only one headset to operate both of your mobile phones. Please note that Last Number Redial will dial the number from the last outgoing call, independent of the mobile phone.

TROUBLESHOOTING & FAQ

I hear crackling noises

- Bluetooth is a radio technology which means it is sensitive to objects between the headset and the device it is connected to. You should be able to have up to 10 meters (33 feet) of distance between the headset and the connected device when there are no major objects in the way (walls, etc.).

I cannot hear the phone call in the headset

- Increase the volume on the Jabra BT650s.
- Make sure your phone is connected to the headset by i.e. tapping the Answer/End button, or viewing the Bluetooth icon in the Display

I have pairing problems

- You may have deleted the pairing connection in your mobile phone – follow the pairing instructions in 'Pair Your Headset to a Phone or other Device'.

I cannot use Reject call, Call on hold or Redial

- These features are dependent on your phone supporting them; please consult your phone's manual for details.

I cannot hear music in the headset

- Ensure that the headset is paired to your Bluetooth enabled device.
- Increase the volume on your device.
- Make sure that the Jabra BT650s is charged.

The music I hear sounds very poor

Make sure the other device supports Bluetooth 1.1 or higher including the Advanced Audio Distribution Profile (A2DP) for music streaming.

If the above procedure did not help then it is possible that your phone is using the stereo audio connection in a different way. You can enable this mode on BT650s by performing pairing in the following way:

Remove the Bluetooth connection to BT650s on your phone

Make sure the headset is on (un-folded)

Press and hold the answer / end button for more than 5 seconds until the both Display icons are solid Blue and solid Orange

Go through the regular steps in pairing the headset to a Bluetooth device.

Be aware that standby time of the Jabra BT650s can be lower when using this pairing.

NEED MORE HELP?

- 1 Web:** www.jabra.com
(for the latest support info and online User Manuals)
- 2 E-mail:** support.uk@jabra.com
Information: info@jabra.com
- 3 Phone:** 0800 0327026

TAKING CARE OF YOUR HEADSET

- Always store the Jabra BT650s with the power off and safely protected.
- Avoid storage at extreme temperatures (above 45°C/113°F – including direct sunlight – or below -10°C/14°F). This can shorten battery life and may affect operation. High temperatures may also degrade performance.
- Do not expose the Jabra BT650s to rain or other liquids.

WARNING!

EXCESSIVE VOLUME LEVELS CAN CAUSE PERMANENT HEARING DAMAGE. USE AS LOW A VOLUME AS POSSIBLE.

Headsets are capable of delivering sounds at loud volumes and high pitched tones which under certain circumstances can result in permanent hearing loss damage. Avoid prolonged use of the headset at excessive sound pressure levels. Please read the safety guidelines below prior to using this headset.

You can reduce the risk of hearing damage by following these safety guidelines

1. Prior to using this product follow these steps

- Before putting on the headset, turn the volume control to its lowest level,
- Put the headset on, and then
- Slowly adjust the volume control to a comfortable level.

2. During the use of this product

- Keep the volume at the lowest level possible and avoid using the headset in noisy environments where you may be inclined to turn up the volume;
- If increased volume is necessary, adjust the volume control slowly;
- If you experience discomfort or ringing in your ears, immediately discontinue using the headset and consult a physician.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

SAFETY INFORMATION!

- Use of a headset will impair your ability to hear other sounds. Use caution while using your headset when you are engaging in any activity that requires your full attention.
- If you have a pace maker or other electrical medical devices, you should consult your physician before using this device.
- This package contains small parts that may be hazardous to children and should be kept out of reach from children. The bags themselves or the many small parts they contain may cause choking if ingested.

- Never try to dismantle the product yourself. None of the components can be replaced or repaired by users. Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer.
- Avoid exposing your product to rain, moisture or other liquids to protect against damage to the product or injury to you.
- Observe all signs and instructions that require an electrical device or RF radio product to be switched off in designated areas such as hospitals or aircrafts.

Remember: Always drive safely, avoid distractions and follow local laws!

Using the headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions, just as use of this headset with both ears covered while driving is not permitted in certain jurisdictions. Check your local laws. Use caution while using your headset when you are engaging in any activity that requires your full attention. Also, try to keep conversations short and do not take notes or read documents.

BUILT-IN BATTERY CARE:

- Your device is powered by a rechargeable battery.
- The full performance of a new battery is achieved only after two or three complete charge and discharge cycles.
- The battery can be charged and discharged hundreds of times, but will eventually wear out. Recharge your battery only with the provided approved chargers designated for this device.
- Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime.
- If left unused, a fully charged battery will lose its charge over time.
- Leaving the device in hot or cold places, such as in a closed car in the summer and winter conditions, will reduce the capacity and lifetime of the battery.
- Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work

temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

- Do not dispose of batteries in a fire as they may explode.
- Batteries may also explode if damaged.

Battery warning!

- "Caution" – The battery used in this device may present a risk of fire or chemical burn if mistreated.
- Do not attempt to open the product or replace the battery. It is built-in and not changeable.
- Use of other batteries may present a risk of fire or explosion and the warranty will be terminated.
- Recharge your battery only with the provided approved chargers designated for this device.
- Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.
- Always store product out of the reach of children.

CHARGER CARE:

- Do not attempt to charge your headset with anything other than the AC adaptor provided. The use of any other types may damage or destroy the headset and may invalidate any approval or warranty, and may be dangerous. For availability of approved enhancements, please check with your dealer.

Important: The headset cannot be used while charging

Charger warning!

- When you disconnect the power cord or any enhancement, grasp and pull the plug, not the cord, never use a charger that is damaged.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock. Incorrect reassembly can cause electric shock or fire when the product is subsequently used.
- Avoid charging your headset in extremely high or low temperatures and do not use the charger outdoors or in damp areas.

WARRANTY

Limited One (1) -year Warranty

GN Netcom A/S (“GN”) warrants this Product to be free from defects in materials and workmanship (subject to the terms set forth below) for a period of one (1) year from the date of purchase (“Warranty Period”). During the Warranty Period, GN will repair or replace (at GN’s discretion) this Product or any defective parts (“Warranty Service”). If repair or replacement is not commercially practicable or cannot be timely made, GN may choose to refund to you the purchase price paid for the affected Product. Repair or replacement under the terms of this Warranty does not give right to any extension or a new beginning of the period of Warranty.

Claims under the Warranty

To obtain Warranty Service, please contact the GN dealer from which you purchased this product or visit www.jabra.com for further information about customer support. You will need to return this Product to the dealer or ship it to the dealer or to GN (if so indicated on www.jabra.com) in either its original packaging or packaging affording an equal degree of protection. You will bear the cost of shipping the product to GN. If the Product is covered by the warranty, GN will bear the cost of shipping product back to you after the completion of service under this warranty. Return shipping will be charged to you for products not covered by the warranty or requiring no warranty repair.

The Following information must be presented to obtain Warranty Service: (a) the product, and (b) proof of purchase, which clearly indicates the name and address of the seller, the date of purchase and the product type, which is evidence that this product is within the Warranty Period. Please further include (c) your return address. (d) daytime telephone number, and (e) reason for return. As part of GN Netcom’s efforts to reduce environmental waste you understand that the product may consist of reconditioned equipment that contains used components, some of which have been reworked. The used components all live up to GN’s high quality standards and comply with the GN product performance and reliability specifications. You understand that replaced parts or components will become the property of GN.

Limitation of Warranty

This Warranty is only valid for the original purchaser and will automatically terminate prior to expiration, if this Product is sold

or otherwise transferred to another party. The Warranty provided by GN in this statement applies only to Products purchased for use, and not for resale. It does not apply to open box purchases, which are sold "as is" and without any warranty. Specifically exempt from Warranty are limited-life consumable components subject to normal wear and tear, such as microphone windscreens, ear cushions, modular plugs, ear tips, decorative finishes, batteries and other accessories. This Warranty is invalid if the factory-applied serial number, date code label, or product label has been altered or removed from this Product. This Warranty does not cover defects or damages that result from: (a) improper storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the Product resulting from misuse; (b) contact with water, extreme humidity, sand, dirt or the like or extreme heat; (c) use of the Product or accessories for commercial purposes or subjecting the Product or accessories to abnormal usage or conditions; or (d) other acts which are not the fault of GN. This Warranty does not cover damage due to improper operation, maintenance or installation, or attempted repair by anyone other than GN or a GN dealer which is authorized to do GN warranty work. Any unauthorized repairs will void this Warranty. This Warranty does not cover defects or damages that result from the use of non-GN branded or certified products, accessories, or other peripheral equipment.

REPAIRS OR REPLACEMENTS AS PROVIDED UNDER THIS WARRANTY ARE THE EXCLUSIVE REMEDY OF THE CONSUMER. GNSHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER EXPRESS AND IMPLIED WARRANTIES WHATSOEVER, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PRACTICAL PURPOSE.

NOTE! This warranty gives you specific legal rights. You may have other rights which vary from location to location. Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or implied warranties, so the above exclusions may not apply to you. This warranty does not affect your legal (statutory) rights under your applicable national or local laws.

CERTIFICATION

CE

This product is CE marked according to the provisions of the R & TTE Directive (99/5/EC). Hereby, GN Netcom A/S, declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. For further information please consult <http://www.jabra.com>.

Bluetooth

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. Other trademarks and trade names are those of their respective owners.

Dispose of the product according to local standards and regulations.
www.jabra.com/weee

GLOSSARY

- 1 Bluetooth** is a radio technology that connects devices, such as mobile phones and headsets, without wires or cords over a short distance (approx. 10 meters/33 feet). Bluetooth is safe to use. It is secure too, so once a connection has been made no-one can listen in and there is no interference from other Bluetooth devices either. Get more information at www.bluetooth.com.
- 2 Bluetooth profiles** are the different ways that Bluetooth devices communicate with other devices. Bluetooth phones support the headset profile, the hands-free profile or both. In order to support a certain profile, a phone manufacturer must implement certain mandatory features within the phone's software.
- 3 Pairing** creates a unique and encrypted link between two Bluetooth devices and lets them communicate with each other. Bluetooth devices will not work if the devices have not been paired.

- 4 Passkey or PIN** is a code that you enter on your Bluetooth enabled device (e.g. a mobile phone) to pair it with your Jabra BT650s. This makes your device and the Jabra BT650s recognize each other and automatically work together.
- 5 Standby mode** is when the Jabra BT650s is passively waiting for a call. When you 'end' a call on your mobile phone, the headset goes into standby mode.



Dispose of the product according to local standards and regulations.

www.jabra.com/weee

Jabra

A BRAND BY

GN Netcom

© 2008 GN Netcom A/S. All rights reserved. Jabra® is a registered trademark of GN Netcom A/S. All other trademarks included herein are the property of their respective owners. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. (Design and specifications subject to change without notice).

MADE IN CHINA
TYPE: BT650s



www.jabra.com

81-02940 A