


Godox
RC-A611

(2.4G)

Godox
RC-A611

机身



Godox
RC-A611

(2.4G)

Godox
RC-A611

2. 使用遥控器调整频道/组别

- 按CH/GR按钮，组别图标闪烁。按“-”或“+”按钮选择组别，可选范围：A-F, 0-9。
- 按CH/GR按钮两次，频道图标闪烁。按“-”或“+”按钮选择频道，可选范围：1-32。

3. 使用遥控器调整 ID

- 短按两次CH/GR按钮，短按“-”或“+”按钮选择ID号，可选范围：OFF, 0-99。

4. 使用遥控器调节灯光亮度

- 短按“-”或“+”按钮调节灯光亮度。

5. 使用遥控器调节色温

- 短按遥控器SET按钮，色温图标闪烁。按“-”或“+”按钮调节色温。 (SL200II, SL300II色温无法调整)

6. 遥控器复位

- 同时按下“-”和“+”按钮可进行复位。注：只有在LED灯控制器通电后方可接收无线信号。

产品保修

尊敬的用户本保修卡是申请保修服务的重要凭证,请您配合销售商填写并妥善保留,谢谢!

产品信息	型号	产品条码
用户信息	姓名	联系电话
	通信地址	
	名称	
	联系电话	
销售商信息	通信地址	
	销售日期	
备注		

注: 此表应由销售商盖章确认。

产品信息

本文件适用于相关《产品保修信息》(见后面说明)所列产品,其他非属此范围的产品或部件(如促销品、赠品及其他出厂后附加的附件等)不在此保修承诺内。

保修期

产品及部件的相应保修期按相关的《产品保修信息》执行,保修期自产品首次购买日起算,购买日以购买产品时保修卡登记日期为准。

如何获得保修服务

您可直接与产品销售商或授权服务机构联系,也可拨打神牛产品服务电话,与我们联系,由我们的服务人员为您安排服务。申请保修时,您应提供有效的保修卡作为保修凭证,方可获得保修。如您不能提供有效的保修卡,则在我们确认产品或部件属于保修范围的情况下,也可以为您提供保修,但这不作为我们的义务。

不适用保修的情况

如产品存在下列情况,本文件项下的保证和服务将不适用: ①产品或部件超过相应保修期; ②错误或不适当使用、维护或保管导致的故障或损坏; ③不当搬运; 非按产品合理预期用途使用; ④不当连接; 非按产品规格或外力挤压; 接触或暴露于不适当温度、溶剂、酸碱、水浸或潮湿环境; ⑤由非神牛授权机构或人员安装、修理、更改、添加或拆卸造成的故障或损坏; ⑥产品或部件原有识别信息被修改或删除; ⑦无效保修卡; ⑧使用非合法授权、非标准或非公开发行的软件造成的故障或损坏; ⑨因不可抗力或意外事件造成的故障或损坏; ⑩其他非因产品本身质量问题导致的故障或损坏。遇上述情况,您应向相关责任方寻求解决,神牛对此不承担任何责任。因非在保修期或保修范围内的部件、附件或软件导致产品不能正常使用的,不是保修范围内的故障,产品使用过程中正常的色色、磨损和消耗,不是保修范围内的故障。

产品保修和服务支持信息

产品的保修期和服务类型按以下《产品保修信息》执行:

产品类别	选项名称	保修期(月)	保修服务类型
部件	主机	12	客户送修
	电池	3	客户送修
其他	充电器等带电性能的部件	12	客户送修
	如电源线、数据线、闪光灯、闪光灯保护盖、灯架、包装等。	无	无保修

神牛产品售后服务电话 0755-29609320-8062

合格证
QC PASS

深圳市神牛摄影器材有限公司
地址:深圳市宝安区福海街道塘尾社区
耀川工业区厂房2栋
电话:0755-29609320(8062)
传真:0755-25723423
邮箱: godox@godox.com

GODOX Photo Equipment Co.,Ltd.
Add: Building 2,Yaouchan Industrial Zone, Tangwei Community,FuHuai Street--Bao'an District,Shenzhen 518103,China
Tel:+86-755-29609320(8062)
Fax:+86-755-25723423
E-mail: godox@godox.com
godox.com Made in China

Body



Godox
RC-A611

(2.4G)

Warning

This product is for commercial use. Operating frequency: 2412.99MHz ~ 2454.45MHz
Maximum Average EIRP Power: 5dBm

Declaration of Conformity

GODOX Photo Equipment Co.,Ltd. hereby declares that this Remote Control/RC-A611 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. In accordance with Article 10(2) and Article 10(10), this product is allowed to be used in all EU member states. For more information of DoC, Please click this web link: https://www.godox.com/DOC/Godox-RC-A611_DoC.pdf.

The device complies with RF specifications when the device used at 0mm from your body.

Operation

1. Wireless Control

RC-A611 has control function, and can control multiple groups of LED lights. The remote has 32channels and 100 IDs to avoid interference. Please set the channels, groups and IDs of LED light to the same as those of RC-A611 remote control before usage.

2. Adjusting Channel/Group with the Remote Control

- Press the CH/GR button and the group icon blinks.
- Press the“-”/+”button to choose a group (A to F, 0 to 9).
- Press the CH/GR button twice and the channel icon blinks.
- Press the“-”/+”button to choose a channel(1 to 32).

2. Adjusting ID with the Remote Control

- Double click the CH/GR button and press the“-”/+”button to choose ID from OFF or 0 to 99.

3. Adjusting Light Brightness with the Remote Control

- Press the“-”/+”button to adjust the light brightness.

4. Adjusting Color Temperature with the Remote Control (The color temperature value of this LED light cannot be adjusted)

- Press the SET button of the remote control and the color temperature icon blinks. Press the“-”/+”button to adjust the color temperature.

5. Remote control reset: press down “-” and “+” button simultaneously to reset.

Note: The wireless signal can be received only when the controller of LED light is powered on.

Technical Data

Remote Control	RC-A611
Power Supply	3V(AAA*2)(not include)
Wireless Frequency	2.4GHz
Distance (emptiness)	100m
Channel	32
Group	16 groups(A-F, 0-9)
Standby Time	Over one year
Operation	-10°C ~ 50°C
Temperature	
Dimension	120*38*15mm
Net Weight	30g

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Warranty

Dear customers, as this warranty card is an important certificate to apply for our maintenance service, please fill in the following form in coordination with the seller and safe-keep it. Thank you!

Product Information	Model	Product Code Number
Customer Information	Name	Contact Number
Seller Information	Name	Contact Number
	Address	
	Address	
	Date of Sale	

Note: This form shall be sealed by the seller.

Applicable Products

The document applies to the products listed on the Product Maintenance Information (see below for further information). Other products or accessories (e.g. promotional items, giveaways and additional accessories attached, etc.) are not included in this warranty scope.

Warranty Period

The warranty period of products and accessories (implemented according to the relevant Product Maintenance Information). The warranty period is calculated from the day (purchase date) when the product is bought for the first time. And the purchase date is considered as the date registered onto warranty card when buying the product.

How to Get the Maintenance Service

If maintenance service is needed, you can directly contact the product distributor or authorized service institutions. You can

also contact the Godox after-sale service call and we will offer you service. When applying for maintenance service, you should provide valid warranty card. If you cannot provide valid warranty card, we may offer you maintenance service once confirmed that the product or accessory is involved in the maintenance scope, but that shall not be considered as our obligation.

Inapplicable Cases

The guarantee and service offered by this document are not applicable in the following cases: ① The product or accessory has expired its warranty period; ② Breakage or damage caused by inappropriate usage, maintenance or preservation, such as improper packing, improper usage, improper plugging in/out external equipment, falling off or squeezing by external force, contacting or exposing to the improper temperature, solvent, acid, base, flooding and damp environments, etc; ③ Breakage or damage caused by non-authorized institution or staff in the process of installation, maintenance, alteration, addition and detachment; ④ The original identifying information of product or accessory is modified, alternated, or removed; ⑤ No valid warranty card; ⑥ Breakage or damage caused by using illegally authorized, nonstandard or non-public released software; ⑦ Breakage or damage caused by force majeure or accident; ⑧ Breakage or damage that could not be attributed to the product itself. Once met these situations above, you should seek solutions from the related responsible parties and Godox assumes no responsibility. The damage caused by parts, accessories and software that beyond the warranty period or scope is not included in our maintenance scope. The normal

Product Type	Name	Maintenance Period(month)	Warranty Service Type
Parts	Battery	12	Customer sends the designated site
	Circuit Board	3	Customer sends the designated site
	Electrical parts (e.g.1301 etc)	12	Customer sends the designated site
Other Items	Flash (use power cord and sync cable modeling lamp), cable cover, etc	No	Without warranty

discoloration, abrasion and consumption are not the breakage within the maintenance scope.

Maintenance and Service Support Information

The warranty period and service types of products are implemented according to the following Product Maintenance Information:

Godox After-sale Service
Call +86-755-29609320(8062)