



BC-4GMCPGa

Quick Installation Guide



Getting to Know your Device



1. **SIM card Slot Cover:** Open the cover and insert SIM card into the slot with right direction.
2. **Telephone Port (RJ-11):** Connect your telephone to Dual-Band Modem with a RJ-11 telephone cable.
3. **LAN Port (RJ-45):** Port for connecting PC, hub and switch or other network equipment by RJ-45 Ethernet cable.
4. **WPS Button:** Press “WPS” button, so, router can easily connects to client which also support WPS function.
5. **Reset Button:** Press “Reset” button less than 5 seconds to reboot the device. Or press and hold the Reset button 10 seconds to set router to factory default settings.
6. **Power Adapter Socket (DC-12V):** Plug adapter DC pin into this socket.
7. **Power Switch**

Installation

Please follow the steps below to install the device:

Step1: Insert SIM card into the device with right direction.

Step2: Insert the power cord into the DC-12V power jack; and insert the plug into power outlet.

Step3: Power ON the device using the switch button. The device will start the booting process.

After a few seconds, the LED lights will start blinking.

Step4: Connect the RJ45 Ethernet cable to the LAN port of the device and your PC, or connect wirelessly using the default SSID and Password at the back label of your device.

Easy Setup

Please follow the steps below to configure your device through the web interface:


Step1: Open the Web browser (Internet Explorer) and enter the default IP address of the Dual-Band Modem : <http://192.168.1.1>

Step2: Enter Dual-Band Modem administrator login username/password to access the web management interface. The default username/password is **admin/admin**.



Step3: The main page after login will display the default setting of SSID, Encryption, and Password.

Step4: You could specify an SSID (Service Set ID) and Password then click **Apply**.



Troubleshooting Tips

If you are experiencing any issues with your device:

- Restart your device.
- Restore your device to its factory default settings.
- Contact Telefonica Network or visit the website
<http://www.telefonica.com.ar/>

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Country Code selection feature to be disabled for products marketed to the US/CANADA.

Operation of this device is restricted to indoor use only.