

ConnectSense®

Smart Outlet

Getting Started



1. Plug In Your Smart Outlet



2. Wi-Fi Settings



- Go to the Settings app and tap Wi-Fi
- Scroll to the bottom under “SET UP NEW DEVICE...” and select your Smart Outlet. It will be listed as ConnectSense Outlet-XXXXXX
- This will take you to the accessory set up screen where your primary Wi-Fi network will be selected by default. Select this or enter an alternate Wi-Fi network

3. Download App + Sign In



- Download the ConnectSense app from the App Store or connectsense.com/app
- Follow the steps to create a ConnectSense account or sign in to your existing account

4. Add Device and Enter HomeKit Pin to Pair



- Click the + in the upper right hand corner to add a new device
- Select ConnectSense Outlet-XXXXXX
- Enter your HomeKit Pin located on the back of your outlet or on the card included in the box to complete the pairing process

Questions?

If you have questions about installing your Smart Outlet, visit connectsense.com/support or call +1 (800) 975-4743.

End User License

For more details on the ConnectSense end user license go to connectsense.com/eula

Warranty

The ConnectSense Smart Outlet is covered by a One Year Limited Warranty. Details are available at connectsense.com/warranty

©2015 Grid Connect Inc.

ConnectSense®

[ConnectSense.com](https://connectsense.com)

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.