



## 600L Icicle Light Set

### IMPORTANT SAFETY INSTRUCTIONS

600 (3x200L) Mini iTwinkle light show Item Number: 00610

When using electrical products, basic precautions should always be followed including the following:

### READ AND FOLLOW ALL SAFETY INSTRUCTIONS

- This is an electrical product - not a toy! To avoid the risk of fire, burns, personal injury and electric shock it should not be played with or placed where small children can reach it.
- Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided contact a qualified electrician for proper installation.
- This seasonal use product is not intended for permanent installation or use.
- Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- Do not let lamps rest on the supply cord or on any wire.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- Do not use this product for other than its intended use.
- Do not hang ornaments or other objects from cord, wire, or light string.
- Do not place lighting string on carpeting, drapes, furniture or allow it to contact vinyl siding while the power is on.
- Do not perform any maintenance or troubleshoot for bad/broken lamps while the power is on.
- Do not close doors or windows on the product or extension cord as this may damage the wire insulation.
- Do not cover the product with cloth, paper or any material not part of the product when in use.
- This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless plug can be fully inserted. Do not alter or replace the plug.
- This product is equipped with push-in type lamps. Do not twist lamps
- This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also, unplug any additional strings or products that may be attached to the product. Replace the fuse as per the User Servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded.
- Read and follow all instructions that are on the product or provided with the product.

### SAVE THESE INSTRUCTIONS

#### USE AND CARE INSTRUCTIONS

- When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.


#### USE AND CARE INSTRUCTIONS (Continued)

- If the product is placed on a tree, the tree should be well secured and stable.
- Before using, or reusing, inspect product carefully. Discard any products that have cut, damaged or frayed wire insulation or cords, cracks in the lampholders or enclosures, loose connections, or exposed copper wire.
- When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections and wires.
- When not in use, store neatly in a cool, dry location protected from sunlight.

#### USER SERVICING INSTRUCTIONS


**String Set Fuse Replacement:** Most often fuses blow because too many sets have been strung end-to-end,

- Before changing fuses, make sure the set is unplugged.
- Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- Using a flathead screwdriver, open fuse cover. Slide open the fuse access cover on top of attachment plug towards blades.
- Remove fuses carefully.
- Risk of fire. Replace fuse only with 3 Amp, 125 Volt fuse (provided with product).
- Close fuse cover. Slide closed the fuse access cover on top of attachment plug. Make sure door is fully closed and fuses are completely covered.
- Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.




**Control Box Fuse Replacement:** Replace the fuse.

- Grasp the plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- Using a flathead screwdriver, open fuse cover. Slide open the fuse access cover on top of attachment plug towards blades.
- Remove fuses carefully.
- Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse (provided with product).
- Close fuse cover. Slide closed the fuse access cover on top of attachment plug. Make sure door is fully closed and fuses are completely covered.
- Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.




**Replace Steady Bulb:** Before changing bulbs, make sure set is unplugged.

- Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling cord.
- Hold bulb by the plastic base and pull bulb/base straight out of socket.
- Replace bulb with only 2.5 Volt, 0.35 Watt regular brightness midget push-in type lamp provided with product.
- Push spare bulb/base assembly into socket. Do not twist bulb when inserting into socket. If bulbs are twisted, part of the set will not light.



#### Replace Steady Bulb (Continued)

Follow a-b) above If the spare bulbs provided with the product have no plastic base or the plastic base does not fit. Then 1) Remove the old bulb by straightening the bulb wires and pulling bulb straight from the base. (Fig. a), 2) Replace the new bulb by straightening the bulb leads and aiming each wire into a separate hole in the plastic base (Fig. b), 3) Make sure each bulb lead comes out an exit opening at the bottom of the plastic base. Now bend each lead up such that each bulb lead fits closely against the narrow side and in the center of the plastic base (Fig. c).



### CAUTION:

- To reduce the risk of fire and electric shock:
  - Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal, and
  - Do not mount or support strings in a manner that can cut or damage wire insulation.
- To reduce the risk of overheating, replace burned-out lamps promptly. Use 2.5 Volt, 0.35 Watt lamps only.
- This lighting string is rated 202 Watts (1.68 Amps), do not overload. Connect other lighting strings or decorative outfits end-to-end to a maximum of 420 watts (3.5 Amps) total. If connecting to a lighting string that does not have a Wattage (W) rating (found on the tag 6 inches of the plug) calculate the wattage as follows: Multiply the current (\_\_\_ A) which is on the flag-type tag by 120. For Example: Lighting string is rated 120 V, 60Hz, 0.2 Amps.  $0.2 \times 120 = 24$  Watts. Add the wattage of each lighting string together for a total of 420 Watts or less. (Do not exceed 420 Watts.)
- Risk of fire. This product employs overload protection (fuse bulb) in each series circuit to provide overload protection in addition to the fuse(s) located in the plug. Do not replace the fuse bulb contained in this set with any other type of bulb. Use only spare fuse bulbs provided with this product.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- this device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Modifications not approved by the party responsible for compliance could void user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- \* Reorient or relocate the receiving antenna.
- \* Increase the separation between the equipment and the receiver.
- \* Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- \* Consult the dealer or an experienced radio/TV technician for help.


(See other side for Operating Instructions)



Just follow these quick and easy steps to set up and use your new iTwinkleLIGHT™ string set.

Remove the product from box and install as desired.

**Note:** Control box has two outlets. Plug two sets into one outlet and one into the other like Fig. 1.



**Step 1.** Plug in your iTwinkle unit to automatically enable Bluetooth. The blue lamp indicates the connection status:

- a. **Blinking Blue** – Searching for available connection to Apple device.
- b. **Steady Blue** – Connected to Apple device.



**Step 2:** With your iPad® iPhone® iPod touch®: Touch **Settings**, **General**, **Bluetooth**, turn **ON** to search for active devices.



**Note:** The effective operating range between your device and the string set is up to 33' (10m).


**Step 3.** Search your device to find "00610 600 Icicle". Touch it.  
**Note:** To install application your device must have Internet capability. (If you haven't installed the App Software)



**Step 4.** Once connected a window will appear prompting you to install the free App software.




**Step 5.** Touch 'Yes' to install. Once installed this window will not appear again.



**Step 7.** Once installed the iTwinkleLight icon will appear on your screen. Find it. Touch it to launch program.



**Step 6.** The free iTwinkleLight App appears. Touch **Free** and then touch **Install App**.



**Step 8.** If this screen appears your Bluetooth device is available. Touch **Allow** to connect or **Ignore** to search for other devices.



**Step 9.** The iTwinkleLight Main Menu appears with 4 items per screen. Scroll to select your item.



**Note:** A green circle shows your Apple device is connected to your product. Red dash shows your product is not connected.

**Step 10.** Product Features screen will now appear. Touch any icon at the bottom of the screen to activate that feature.



"Made for iPod," "Made for iPhone," and "Made for iPad" mean that an electronic accessory has been designed to connect specifically to iPod, iPhone, or iPad, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, iPhone, or iPad may affect wireless performance.

©2013 Nicolas Holiday Inc.,  
9F, No. 37, Guangfu N. Rd  
Taipei, Taiwan 10560  
All rights reserved

For Indoor Use Only 120 V 60 Hz  
**This is not a toy, for decorative use only.**

To view these instructions online please visit us at [www.geholidaylighting.com](http://www.geholidaylighting.com)  
or call customer support toll free at 1-877-398-7337

**Note:** Touch the house icon in the upper right corner to return to the iTwinkleLight Main Menu

Icon	Feature	Displays	Description
	<b>Music</b>	Music Player	Touch iTwinkle Music to enjoy 1 of 8 pre-loaded songs and light shows. Touch My Music to select songs from your iTunes music library and play songs from any country.
	<b>Voice</b>	Microphone	Speak... the lights flash to your voice. Select an icon to hear your message replayed in a child-like or Santa voice.
	<b>Pattern</b>	Pattern Icons	Scroll icons to select 1 of 8 programmed light shows. <b>Note:</b> This pattern is used for the Dimmer feature.
	<b>Tap Me</b>	Shake Icon	Tap to change color of lights. Hold the device securely; SHAKE wrist to change colors.
	<b>Dimmer</b>	Bulb	Slide finger right or left to adjust bulb brightness.

*Holiday magic at your touch.*

Scan this QR Code with your smart phone to learn more about iTwinkle



Made for  
iPod iPhone iPad

