




Smart Hub

User Manual





① Connect Smart Hub with Smartphone/Tablet

Plug the Smart Hub into a power outlet using the included power cord. Then, you may need to check whether Smart Hub is ready to be registered. You will see the slowly blinking purple LED light on the middle-button of Smart Hub with BEEP BEEP sound when it is available for its installation. Otherwise, you may need to reset it by pressing Reset Button for 10 seconds on its backside. Please release the Reset Button when you could hear BEEP BEEP sound again which means resetting Smart Hub has completed successfully.

② Find a network named "HS_Rayhub" on Wi-Fi Settings, and enter the password

printed on RayCAM manual book.

③ Now press the "NEXT" button.

← Hub Registration Wi-Fi Setting

The Hub is currently unavailable for wired connection. Please try the following Wi-Fi setting.

Wi-Fi ID

Please enter your ID

Wi-Fi Password

Please enter your passwo

[Connect Smartphone/Tablet with WiFi]
Enter Camera Name, Password, Wi-Fi ID, and Wi-Fi Password

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.