

OWNER'S MANUAL

Installation Of Battery

Remote Controller

1. Remove the battery cover on back of Remote Controller.
2. Install one(1) piece L1028 12V battery in the battery compartment of Remote Controller.
3. Replace the battery cover.
4. Replace the battery when control distance gets short.

Main Unit-The Bullet

1. Remove the battery cover on Bullet by pushing in the direction as shown.
2. Install two(2) N/LR1/AM5 1.5V batteries in the battery compartment of Bullet.
3. Replace the battery cover.
4. Replace the batteries when vibration gets weak.

Operation

1. Press ON/OFF button on Remote Controller until the Bullet starts vibration at level 1 & blue LED illuminate
The unit is now turned to "ON".
2. Press MODE button to select an ideal vibration level and pulse model.
3. The unit has built-in 5 different levels of vibration and 8 different models of pulse.
4. The 5 levels of vibration starts with very light at the beginning and finishes with very heavy vibration on the 5th level.
5. The 8 different models of pulse are specially designed for great pleasure.
6. All these 13 modes are operated in sequence by pressing the MODE button.
7. When you stop using the unit, press ON/OFF button to "OFF".

The FCC wants you to know

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.