

Thank you for choosing this mobile phone. You can read the manual, a comprehensive understanding of the use of mobile phones and enjoy its perfect functionality and simple method of operation.

#### Insert SIM card

1. Power off the phone and remove other external power
2. Take off the back cover and remove the battery of the phone
3. Insert SIM card into the SIM card slot in the phone.

#### Remove and Install the battery

The attached Li-ion battery along with the phone can be used after unpacking. For the first three times, please use up the power and charge it fully for new battery to perform well

#### Install the battery

1. Put the battery in the battery compartment, note that the metal end of the battery should be firstly inserted
2. Put on the back cover.

#### Remove the Battery

1. Take off the back cover.
2. Put finger on the side finger grip, and then lift up the battery from the finger grip to remove the battery

#### Call

1. Hold the Power key to power on the phone. The phone will

automatically search for the network

2. When the phone is powered on, hold the Power key to power off the phone

## **Locked and unlock the screen**

You can drag the unlock icon to a function icon for a certain distance, thus you can unlock the screen and enter that function module. To lock the screen, you only need to press the power button in any screen, the phone then enter sleep mode.



## Enter the desktop


Unlock the screen and enter the desktop, all your applications will be displayed on the desktop. You can touch the icon to open the corresponding program, you can also press and drag the icon to sort. If you want to uninstall the application, drag the icon to the trash at the top.



## Manage contacts


Please select the import contacts mode for the first time, the phone support several import contacts mode. You can import contacts in

SIM card or SD card; also you can set the synchronization account, or create a new contact directly.




## Make a call

You can make calls directly from the desktop which can also be used to search for contacts.




## Send Message

Write a message, you can add one or more recipients. Text, pictures, facial expressions, contact information, audio and video are supported for the message content.



## Write email

After you have set your email account, you can write and send you email, and you can get the notification when new email arrived.



## Photo and video


Launch the camera to take pictures. continuous shooting, timing, effects, etc. are supported. To record video, you just need to switch camera to video mode.



## **Image viewer**


Gallery application supports folder path, or you can double-click to zoom through a single picture, you can slide left or right to the next picture.






## Music

Music application supports online music through the internet.




## Internet

Browser support double-click or sliding to scale webpage. fast access to frequently used sites through site navigation. Support multi-tab, click the tab to switch pages.



## View Notifications

When you have a new phone call, message or some other notification information, you can slide down from the status bar to see the notification details.



## **Multi task**

Phone supports multiple tasks running simultaneously, you only need to long press the home button in unlock state



## Change wallpaper

You can change lock screen wallpaper or desktop wallpaper.











## **Add desktop widget**

To add a desktop gadget you can long press the empty area on the desktop.




## **File manager**

Through file manager, you can get the current usage of mobile phone memory card. File manager support quick browsing through classified documents, or manage files by path. also, remote file management capabilities are supported through WIFI from the remote computer.

| BROWSE  | FILE  | FTP  |
|---|---|--|
| <br>Music<br>(164) | <br>Videos<br>(42)   | <br>Pics<br>(110) |
| <br>Themes<br>(0)  | <br>Docs<br>(78)     | <br>Zips<br>(0)   |
| <br>APKs<br>(6)    | <br>Favorites<br>(1) |  |

SD card: 3.7 GB    Space available: 2.8 GB



|               |                |              |
|---------------|----------------|--------------|
| Music: 242 MB | Videos: 449 MB | Pics: 5.1 MB |
| Themes: 0 B   | Docs: 9.4 MB   | Zips: 0 B    |
| APKs: 8.8 MB  | Misc: 152 MB   |              |



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This mobile phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. \*Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the

power output.

The highest SAR values for the model phone as reported to the FCC when tested for use at the ear and on the body are:

**Head: 1.27W/kg, Body-worn: 0.722W/kg**

**The maximum scaled SAR in hotspot mode is 1.33 W/kg**

**Simultaneous Transmission: 1.383W/kg**

(Measurements differ among phone models, depending upon available accessories and FCC requirements.)

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid) after searching on **FCC ID: RH2-UP-500MZ**

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and the positions the handset a minimum of 1.0 cm from the body. Use of other accessories may not ensure compliance with

FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 1.0 cm from your body when the phone is switched on.