

Model Number – QLX 7622

Description – Nostalgic Record Player

Technical Description

It is a light & sound effect item. Sound activation is provided when the record is placed on the spindle and the arm is moved over the record. When activated, the chip will play one of the three sound segments that is associated with the ID laminated within the record.

While the music is playing, the LED around the stationary turntable is to appear to rotate (face in / out sequence) at 78-RPM clock wise direction.

Battery attachment and replacement

- Lift to remove the battery compartment cover.
- Insert 3 new “AG13” alkaline batteries. As indication at battery compartment.
- Replace the battery compartment cover.

Care & Maintenance

- Do not immerse this toy in water.
- If music or lights from this toy become faint, or if there is no music or lights, please replace the batteries.

Battery Tips

- Use only alkaline batteries.
- Do not use rechargeable batteries.
- Do not attempt to recharge non-rechargeable batteries.
- Insert batteries as marked and always follow the toy and battery manufacturer’s instructions.
- Use only the same or equivalent type of battery as recommended.
- Do not short-circuit battery terminals.
- Do not mix old and new batteries. Do not mix different types of batteries, such as alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium).
- Batteries are to be inserted with the correct polarity.
- Always remove exhausted or dead batteries from the product.
- Remove batteries from the product before extended storage.

Model Number – QLX 7622

Description – Nostalgic Record Player

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.