INFORMATION TO USER:

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation; if this equipment does cause harmful interference to radio or television reception, which can be determined by determined by turning the equipment off and on, the user is encouraged to try to crrent the interference by one or more of the fllowing measures:

- Reorient/Relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit difference from that to which the recerver is connected.
- 4. Consult the dealer or an experienced radio/TV technician for help.
- Shielded interface cable has to be used to ensure product compliance.


CAUTION: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment

Table of Contents

Warning21	Troubleshooting	Specification	Standard Signal Table17	Adjusting OSD11	Power Management Feature10	Name and Function of Front 8	Installing Monitor Driver6	The range of control Angle5	Connection to Computer4	Parts 3
-----------	-----------------	---------------	-------------------------	-----------------	----------------------------	------------------------------	----------------------------	-----------------------------	-------------------------	---------

Good Posture Guide

- Place the monitor to face the user and then adjust the monitor angle.
- Take a break (for about 10 minutes) at every hour during the work with monitor.
- Refer to the following figure to take the correct posture.




- Look down the monitor below the horizon.
- Adjust the monitor to prevent reflection.
- Relax shoulders and arms, and sit back on the chair.
- Maintain the arms horizontally and place hands softly on the keyboard.

to acquire required angle.

Keep feet flat on the ground.

Parts














User's Manual Warranty Card



MANUFACTURER : AcBel MODEL: API-208-98010 For use only with

Connection to Computer

Basic Connection



- 1. Use 220 V or 110 V. (Free Voltage)
- 2. Connect monitor and computer via computer cable (See figure ②)
- Power on the monitor and computer.
- Connection is finished.

4

The range of control Angle

▼ How to Adjust the Stand

