

JBL® CHARGE

Quick Start Guide



- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a dry cloth.



- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.

- Use only with the cart, stand, tripod, bracket or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as: when the power supply cord or plug has become damaged, when liquid has been spilled or objects have fallen into the apparatus, when the apparatus has been exposed to rain or moisture, when the apparatus does not operate normally, or the apparatus has been dropped.
- Do not expose this apparatus to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the apparatus.
- To completely disconnect this apparatus from the AC mains, disconnect the power supply cord plug from the AC receptacle.
- The mains plug of the power supply cord shall remain readily operable.
- Do not expose batteries to excessive heat such as sunshine, fire or the like.

Important Safety Instructions

FCC AND IC REGULATIONS (USA AND CANADA ONLY)

FCC AND IC INFORMATION FOR USERS:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS 210. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RSS-102 Statement: This equipment complies with Industry Canada radiation exposure limits set forth for an uncontrolled environment.

Déclaration CNR-102: Cet équipement est conforme à l'exposition aux rayonnements Industry Canada limites établies pour un environnement non contrôlé.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: EXPOSURE TO RADIO FREQUENCY RADIATION

To comply with FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter.
CAUTION: Changes or modifications not expressly approved in writing by HARMAN International may void the user's authority to operate this equipment.

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

SEE MARKING ON BACK OF PRODUCT.




THE LIGHTNING FLASH WITH AN ARROWHEAD SYMBOL, WITHIN AN EQUILATERAL TRIANGLE, IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UNINSULATED "DANGEROUS VOLTAGE" WITHIN THE PRODUCT'S ENCLOSURE THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS.




THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE PRODUCT.






1x




1x





1x



1x













1.




2.




3.






**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**




Flashing blue/red


**Unit is on;
Bluetooth
connected**



Continuous blue




**Battery
needs charging**



Flashing red

**Battery
level low**



Continuous blue

**Battery
level medium**




Continuous blue

**Battery
level high**



Continuous blue



Unit is off



**Unit is on;
Bluetooth
not connected**



Flashing blue

**Unit is on;
Bluetooth
in pairing mode**



Flashing blue/red

**Unit is on;
Bluetooth
connected**



Continuous blue

SPECIFICATIONS

Transducers: 2 x 1-1/2" (38mm)

Amplifier power: 2 x 5W

Frequency response: 150Hz – 20kHz

Signal-to-noise ratio: >80dB

Battery type: Li-ion rechargeable

Bluetooth transmitter frequency range: 2.402 – 2.480GHz

Bluetooth transmitter power: 0 ~ 9dBm

Bluetooth transmitter modulation: GFSK, $\pi/4$ -DQPSK, 8-DPSK

Listening time on battery power: > 12 hours

Battery charge time: 3.5 hours

Dimensions (Dia x H): 2-29/32" x 6-29/32"
(74mm x 175mm)

SPÉCIFICATIONS

Transducteurs : 2 x 1-1/2 po (38mm)

Puissance d'amplificateur : 2 x 5W

Courbe de résonance : 150Hz – 20kHz

Rapport signal sur bruit : >80dB

Type de batterie : Li-ion rechargeable

Plage de fréquence de l'émetteur *Bluetooth* : 2.402 – 2.480GHz

Puissance de l'émetteur *Bluetooth* : 0 ~ 9dBm

Modulation de l'émetteur *Bluetooth* : GFSK, $\pi/4$ -DQPSK, 8-DPSK

Autonomie d'écoute : > 12 heures

Durée de charge : 3.5 heure

Dimensions (Dia x H) : 74mm x 175mm
(2-29/32 po x 6-29/32 po)



HARMAN CE1588

HARMAN International Industries, Incorporated
8500 Balboa Boulevard, Northridge,
CA 91329 USA
www.jbl.com

© 2013 HARMAN International Industries, Incorporated. All rights reserved.
JBL is a trademark of HARMAN International Industries, Incorporated,
registered in the United States and/or other countries. The *Bluetooth* word
mark and logos are owned by the *Bluetooth* SIG, Inc. and any use of such
marks by HARMAN International Industries, Incorporated is under license.

Features, specifications and appearance are subject to change without notice.

Part #: 950-0479-001 Rev. A