

315\*148mm



www.heuixint.com

HEUIXINT

Portable Bluetooth Speaker  
Model:S2



Welcome


Thank you for choosing this product. For better use of the speaker, we recommend you read the User Manual carefully and keep it for future reference.

Package

- 1 x Bluetooth Speaker
- 1 x Micro USB Cable
- 1 x User Manual

Function Description

- 1. Power ON / OFF
- 2. Micro USB Charging Port
- 3. Last Track / Volume -
- 4. Play / Pause
- 5. Next Track / Volume +
- 6. Hands-free Call
- 7. Bluetooth



Power ON / OFF

Power On: Press and hold ON/OFF Button (1) to turn the Speaker ON. And there will be a prompt sound.  
Power Off: If you long press the Power Button while it is powered on, the power will be turned off.

Bluetooth Mode


- 1. The default mode is Bluetooth Mode when you turn on the speaker for the first time.
- 2. Turn on the Bluetooth Function of your Mobile Device to search and select "S2". The Speaker and Mobile Device will now be Paired.
- 3. Long press the Volume - Button to play the Last Track; Short Press to decrease the Volume.
- 4. Long press the + Button to play the Next Track; Short Press to increase volume. There will be prompt sound when you reach the MAX Volume.
- 5. Press Play/Pause Button to Pause or Play the Music.
- 6. Press the Bluetooth Button to disconnect Bluetooth, and push it again to reconnect.

Hands-free Call

In Bluetooth Mode, when there is an incoming call, press Phone Button to Answer it, press again to Hang Up.

TF card function

- 1.Please insert the TF card when you would like to listen the TF card songs.
- 2.Please short press the '🔊' to exchange the Bluetooth.




Charging

- 1. The Speaker has a built-in rechargeable battery. Please ensure it is fully charged via the Micro USB Cable before use.
- 2. Open the USB cover, then plug the Micro USB charging cable.
- 3. The charging time is approx. 3 hours under 5V, 1A condition; the continuous working time is approx. 3.5 hours.

About IPX5 Splashproof

- 1. The speaker is IPX5 splashproof, which means that it offers protection from a 6.3mm spray of water (12.5 liters per minute) in any direction from 3 meters distance.
- 2. IMPORTANT: To ensure the speaker is splashproof, please remove all cable connections and tightly close the cap. And do not expose it to water while charging. Otherwise exposing the speaker to liquids may result in permanent damage to the speaker.



Specifications

Bluetooth Version: V4.2  
Speakers: 48mm 4Ω, 5Wx2  
Frequency Response: 80Hz to 20kHz  
SNR:> 80dB  
Distortion Rate:> 1%  
Battery Type: Lithium-ion (3.7V / 2200mAh)

Cautions

- 1. It's probably due to low battery in case the speaker failed to be turned on. Thus please try to charge the battery then turn on again.
- 2. Please turn off the speaker during charging. It helps to increase the battery service life.
- 3. Ensure the lithium device is fully charged when used for the first time.
- 4. Make sure the battery is fully charged if it is unused for a long period.
- 5. Do not expose the battery to extreme temperatures, never above 45°C.
- 6. Do not attempt to modify, repair, or disassemble on your own.
- 7. Low battery shall cause malfunction of the buttons or a decrease of the volume. Charge the battery to fix the problem.
- 8. Only use the power cable and power supply provided by our manufacture.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modocations to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.