

Model Numbers of the Lock DataSeal family, approved by FCC with  
FCC ID: OB6-IGRS41916

IG-LK-40-916  
IG-LK-41-916  
IG-LK-42-916  
IG-BR-40-916  
IG-BR-41-916  
IG-BR-42-916

### The FCC wants you to know:

This device complies with Part 15 of FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by Hi-G-Tek Ltd. could void the user's authority to operate the equipment.

Instructions concerning human exposure to radio frequency electromagnetic fields:  
A distance of at least 20cm. Between the equipment and all persons should be maintained during the operation of the equipment.

# Lock DataSeal Installation Guide

UM4725 Rev. A0

## Lock DataSeal

### General

This installation guide covers the installation of HI-G-TEK's Locking seals family of products. The Lock Seal ( Fig.1) contains electronic module (1), locking pin (2) and locking unit (3) with a key (4).

Fig.2 and Fig.3 shows various locking units




Fig. 1




Fig. 2




Fig. 3

#### Installation:

To install the Lock Seal, unlock and remove the locking unit, insert the locking pin into the padlock eyes, insert the locking unit and turn the key to lock again. Remove the key - making sure you do not open the lock again.

**Hi-G-Tek Ltd**

**Tel: +972-3-5339359**

**Fax: +972-3-5339225**

**[www.higtek.com](http://www.higtek.com)**