

i>clicker Gen2 Remote User's Manual

i>clicker Gen2 Remote FCC

FCC ID: T24-RLR14

Changes not expressly approved by Holtzbrinck Publishers could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an output on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product complies with FCC OET Bulletin 65 radiation exposure limits set forth for an uncontrolled environment.

i>clicker Gen2 Remote IC

IC: 6495A-RLR14

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

i>clicker Gen2 Remote Instructions

VOTE STATUS

✓ = Vote received

⊙ = Vote not received

CLOSED – polling is not active

NO BASE – incorrect frequency or too far from base

LOW BATTERY

No bars and flashing battery icon indicate less than 25 hours of battery power.

REGISTRATION

Unique i>clicker ID is located on sticker below and on display during power up.

CHANGE FREQUENCY

Press and hold orange Power button until frequency code flashes. Enter 2-letter frequency code given by instructor.

QUESTION MODE

Press blue Refresh button before voting to enter correct question mode.