



DEX Adapter

Model DEX-BLE-1

Quick Start Guide



DEX-ENUS-QS Rev A
3/16

Out of the Box


Make sure that your shipping box contains these items:

- DEX Adapter (DEX-BLE-1)
- Quick Start Guide


If any of these items are missing or appear damaged, contact your Customer Account Representative. Keep the original packaging in the event that you need to return the DEX adapter for service or if you want to store it while not in use.

The DEX adapter was designed to fit in your pocket when not in use. The adapter has a belt clip to make it easy for you to attach the DEX adapter to your belt. The operating temperature is -20 °C to 50 °C (-4 °F to 122 °F).

DEX Adapter Front Features




DEX Adapter Back Features



Connect the DEX Adapter to Your System

The DEX adapter easily connects to direct store delivery (DSD) receiving systems including DEX/UCS store systems, vending machines, and other retail equipment.

- Pull the cable out of the molding and insert the DEX adapter into the receiving system.



DEX Adapter

Model DEX-BLE-1

Quick Start Guide



DEX-ENUS-QS Rev A
3/16

Out of the Box


Make sure that your shipping box contains these items:

- DEX Adapter (DEX-BLE-1)
- Quick Start Guide


If any of these items are missing or appear damaged, contact your Customer Account Representative. Keep the original packaging in the event that you need to return the DEX adapter for service or if you want to store it while not in use.

The DEX adapter was designed to fit in your pocket when not in use. The adapter has a belt clip to make it easy for you to attach the DEX adapter to your belt. The operating temperature is -20 °C to 50 °C (-4 °F to 122 °F).

DEX Adapter Front Features




DEX Adapter Back Features



Connect the DEX Adapter to Your System

The DEX adapter easily connects to direct store delivery (DSD) receiving systems including DEX/UCS store systems, vending machines, and other retail equipment.

- Pull the cable out of the molding and insert the DEX adapter into the receiving system.



Turn On the Bluetooth Radio

You need to turn on the Bluetooth® radio before you can pair the DEX adapter with your mobile computer.

- Push down on the Power button every time you want to use the DEX adapter.



Pair the DEX Adapter with a Mobile Computer

There are two ways to pair the DEX adapter with the mobile computer:

- Read the NFC tag by touching the mobile computer to the adapter.
- Scan the bar code on the back of the adapter.

The mobile computer initiates the pairing process with the adapter.

Turn On the Bluetooth Radio

You need to turn on the Bluetooth® radio before you can pair the DEX adapter with your mobile computer.

- Push down on the Power button every time you want to use the DEX adapter.






Pair the DEX Adapter with a Mobile Computer

There are two ways to pair the DEX adapter with the mobile computer:

- Read the NFC tag by touching the mobile computer to the adapter.
- Scan the bar code on the back of the adapter.

The mobile computer initiates the pairing process with the adapter.

Agency Information

| | |
|--|---|
|  UL and C-UL Statement UL and C-UL listed: UL 60950-1, Second Edition and CSA C22.2 No.60950-1-07, Second Edition. |  Norme UL et C-UL Homologué UL et C-UL : UL 60950-1, seconde édition et CSA C22.2 No.60950-1-07, seconde édition. |
|  | |

USA

FCC Part 15 Subpart B Class B




This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

Agency Information

| | |
|--|---|
|  UL and C-UL Statement UL and C-UL listed: UL 60950-1, Second Edition and CSA C22.2 No.60950-1-07, Second Edition. |  Norme UL et C-UL Homologué UL et C-UL : UL 60950-1, seconde édition et CSA C22.2 No.60950-1-07, seconde édition. |
|  | |

USA

FCC Part 15 Subpart B Class B

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. Honeywell is not responsible for any radio or television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Honeywell.

The correction is the responsibility of the user.

Use only shielded data cables with this system. This unit has been tested with cables less than 3 meters. Cables greater than 3 meters may not meet class B performance.

Caution: Any changes or modifications made to this equipment not expressly approved by Honeywell may void the FCC authorization to operate this equipment.

RF Exposure Warning

This equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. Honeywell is not responsible for any radio or television interference caused by unauthorized modifications of this equipment or the substitution or attachment of connecting cables and equipment other than those specified by Honeywell.

The correction is the responsibility of the user.

Use only shielded data cables with this system. This unit has been tested with cables less than 3 meters. Cables greater than 3 meters may not meet class B performance.

Caution: Any changes or modifications made to this equipment not expressly approved by Honeywell may void the FCC authorization to operate this equipment.

RF Exposure Warning

This equipment complies with FCC RF exposure limits set forth for an uncontrolled environment.

This equipment must not be co-located or operating in conjunction with any other antenna or transmitter.

Support

To search our knowledge base for a solution or log into the Technical Support portal and report a problem, go to www.hsmcontactsupport.com.

User Documentation

For the user guide and other documentation, go to www.honeywellaidc.com.

Limited Warranty

For warranty information, go to www.honeywellaidc.com and click **Resources > Warranty**.

Patents

For patent information, see www.hsmpats.com.

Disclaimer

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. HII disclaims all responsibility for the selection and use of software and/or hardware to achieve intended results.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

Copyright © 2016 Honeywell International Inc. All rights reserved.

Support

To search our knowledge base for a solution or log into the Technical Support portal and report a problem, go to www.hsmcontactsupport.com.

User Documentation

For the user guide and other documentation, go to www.honeywellaidc.com.

Limited Warranty

For warranty information, go to www.honeywellaidc.com and click **Resources > Warranty**.

Patents

For patent information, see www.hsmpats.com.

Disclaimer

Honeywell International Inc. ("HII") reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. The information in this publication does not represent a commitment on the part of HII.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. HII disclaims all responsibility for the selection and use of software and/or hardware to achieve intended results.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

Copyright © 2016 Honeywell International Inc. All rights reserved.