
Bluetooth headset user guide

Bluetooth headset features



 Talk/End/Reject and Power -To accept/end/reject call; turn power ON or OFF of the headset.
Microphone -Voice input for outgoing audio.
LED indication -Light indication of the headset status.
Charging port – Plug for charging the battery.
Speaker – Listen for incoming audio.
Internal buzzer -Sound notification of headset status

Introduction

This bluetooth headset is a light weight wireless system utilizing bluetooth wireless technology. The headset contains a microphone and a speaker; it's for hands free communications with mobile phones. The power is provided by integral rechargeable battery.

Any device that you want to use with this Bluetooth headset must be compatible with Bluetooth technology version 1.1 and support the product and make sure that you:

- 1. Fully charge headset at least 12 hours before you use it the first time.
- 2. Pair the headset with your Bluetooth phone or other devices before you start making calls.

What's in the package?

1. One bluetooth headset.



3. One user guide

4. One hanging string

2. One adaptor

Choose right or left ear wearing style

Headset can be worn on either ear. Just plug in the speaker to your ear.

Prepare to use your Bluetooth headset

1. Charging and battery time

Before use your headset, you need to fully charge the battery.

NOTE: When the headset is under charging, it stays on "OFF" mode. You'll need to turn "ON" the headset to use after the charging.

- A. Connect the adaptor into an electrical outlet.
- B. Plug the adaptor's connector into charging port.
- C. While charging, the blue indicator light will stay solid on, when charging is completed, the light will be off.

Then you can take the adaptor's connector out from the headset and disconnect the adaptor from the electrical outlet.

D. Charging time is about 2.5-3 hours. (Note: First time use, please charge at least 12 hours)



2. Linking the headset to the phone (Pairing)

Before you use your headset for the first time, you must pair the headset to a Bluetooth phone. The Bluetooth connection between the headset and your phone can be established by setting up a paired link. With a paired link, the phone remembers the headset's ID, and process with future use.

3. Pairing the headset to the phone

Before you can pair your headset you need to put it into pairing mode.

Note: Pairing must be done every time while the headset establishes a link with a different Bluetooth phone. Pairing mode can be entered by 2 methods:

One: When you charge the headset, the headset will automatically enter pairing mode. It will directly enter the blow C. stage. Or

Two: Enter from the power OFF state. You will need to start from the below B. stage.

NOTE: During pairing, it is recommended that the headset and phone distance is as close as possible with no solid objects in between.

To proceed pairing the headset with the bluetooth phone, please follow below stages:

- A. Check the mobile phone user guide, and then find out the locations of Bluetooth device discovery.
- B. Ensure headset is switched off.
- C. Press and hold the button on headset for 3 seconds, the blue LED rapid flashing. This means the headset is in pairing mode.
- D. Perform a Bluetooth device discovery from the mobile phone. NOTE: It may take several seconds to establish connections.
- E. The phone's display will advise that it has found HH311 and ask you to confirm that you want to pair with it. Confirm this.
- F. Enter the passkey 1234, when your phone menu prompts you, and the phone will start to pair the headset.
- G. Your phone screen will advise that pairing has been successful, and the blue LED on your headset will change state, it will flash once every 3 sec. when Bluetooth pairing has been established.

If the pairing fails, the blue LED keep rapid flashing for about 2 minutes, then stop. A re-pairing procedure is needed. Please refer to above A. ~ G.

NOTE: Your phone screen will also give the status. Once the headset and phone have successfully paired, you are ready to place and receive calls.

Turning your headset ON and OFF

To switch your headset on, press the button for about 3 seconds, the blue LED rapid flashing, release the button. The headset power is turn ON. After 2 minutes, the LED will slow flash; indicate headset is awaiting a call.

To switch your headset off, press and hold the button for 3 seconds until there are 5 times blue LED flashing, then release the button. You will find no LED indication.

Making a call with the headset by voice dialing

If your bluetooth phone supports voice dialing, you can use this feature with the headset. Please refer to your phone's user guide for more information on voice control.

- 1. Voice dialing to your phone must be turned on and voice tags stored.
- 2. The headset power is ON.

- 3. Press the button once on the headset.
- 4. A short tone will prompt you and you can speak the voice "tag" name as entered in the phone's voice dial phone book.
- 5. The phone automatically dials your selection, and you see the details of the call on the phone screen.
- 6. When connected, you are free to communicate normally by the headset.

NOTE: Make sure the headset and the cell phone are under link stage. For the examples of Ericsson and Nokia cell phones, the - and - symbols mean "link" status. For Nokia cell phone, it is necessary to press

Nokia celi priories, trie - and - symbols mean link status. Foi Nokia celi priorie, it is necessary to press

the bigger button once to make the $\frac{1}{2}$ symbols on the cell phone when the headset is out of 10 meters, power off or after charging.

Making a call from the mobile phone

- 1. Using the phone's keypad, dial the phone number.
- 2. To send the call, press the phone's SEND/CALL key the phone initiates the all.
- 3. The call will then transfer automatically to the headset when connection is made.

Ending a call from the headset

To end a call, press the button on headset. Or you can end the call from the phone key pad. Or when the other side hangs up the phone, the call ends automatically.

Receiving/Answering a call

If there is an incoming call, a ring tone will sound in your headset; just press the button on headset to answer the call.

If your cell phone supports auto answering a call, the headset will take the incoming call and you don't need to press any button.

Speaker volume control button

To adjust the volume of headset, you may use phone's volume up down buttons to adjust the headset volume.

Low battery warning

The headset needs re-charging when the blue LED is quick flash 6 times every 3 sec. You can also hear a special tone of DO-LU-DO-LU-DO from the headset every about 40 sec.

Once the low battery warning starts, there will be around 10 minutes talk time left, charging the headset is necessary.

Visual LED chart:		
Headset state	LED indication state	Remark
Standby	Flash 1 time every 3 seconds	In headset profile
	Flash 3 times every 3 seconds	In handsfree profile
Initial a call (Use voice dial)	Flash 2 times every 3 seconds	
During a call	Flash 4 times every 3 seconds	
Power on/off	Flash 5 times every 3 seconds	
Low battery	Flash 6 times every 3 seconds	
Pairing	LED rapid flashes for 2 minutes	Each time turn power on and charging headset will automatically enter the pairing

Audio and visual indicators

Audio indicator chart:

Headset state	Audio indication	
Volume button	Repeated single tone when the button either lower or upper is pressed.	
Incoming call	Ring tone	
Low battery	DO-LU-DO-LU-DO tone every 40 sec.	
Initiate voice dial	Headset rings as cell phone default sound.	

Bluetooth headset specification

Compatible bluetooth 1.1 headset profile and handsfree profileMaximum distance30 Feet (10 meters)Weight of headset18.5 gTypical standby time168 hoursTypical talk time5 hoursTypical re-charge time2.5-3 hoursBattery typeLi-ion rechargeableNOTE: Talk time and standby time are varied according to different mobile phones.

Storage of headset

- 1. Always store the headset and audio gateway safety protected.
- 2. Avoid storage at high temperatures (above 60 C/134 F) such as in a hot vehicle or in direct sunlight. (Storage at high temperature can degrade performance and reduce battery life.)
- 3. Do not expose the headset and audio gateway or any of its supplied parts to rain or other liquids.

Certification and safety approvals/general information

This product is CE, FCC, BQB marked. Please note that this product uses radio frequency bands not harmonized within EU. Within the EU, this product is intended to be used in Austria, Belgium, Denmark, Finland, France, Germany, Greece, Ireland, Italy, Luxembourg, The Netherlands, Portugal, Spain, Sweden, United Kingdom and within EFTA in Iceland, Norway and Switzerland.

Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by your distributor will void the users' authority to operate the equipment.

Bluetooth is a trade mark owned by Bluetooth SIG, Inc.

Caution:

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Important information on safe and efficient operation. Read this information before using your phone. Users are not permitted to make changes or modify the device in any way. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warranty and parts replacement

Battery: This headset is equipped with a lithium polymer rechargeable battery. Replacement or service must be done at a qualified service center or returned to the manufacturer.

Use only the battery supplied.

Use only the supplied and approved AC charger.

We warrant this product against all defects in material and workmanship for a period of one year from the date of original purchase. The conditions of this warranty and our responsibilities under this warranty are as follows:

* The warranty is limited to the original purchaser.

* A copy of your receipt or other proof of purchase is required. Without proof of purchase, your warranty is defined as beginning on the date of manufacture as labeled on the products.

* The warranty is void if the serial number, date code label or product label is removed, or if the product has been subject to physical abuse, improper installation, modification, or repair by unauthorized third parties.

* The responsibility of our products shall be limited to the repair or replacement of the product at it's sole discretion.

* Any implied warranty on our products is limited to one year from the date of purchase on all parts, including any cords and connectors.

* Specifically exempt from any warranty are limited-life consumable components subject to normal wear and

tear, such as microphone, decorative finishes, batteries, and other accessories.

* We are not liable for any incidental or consequential damages arising from the use or misuse of any our product.

* This warranty gives you specific rights and you may have other rights which vary from area to area.

* Unless otherwise instructed in the user guide, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on this unit, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.

* We will not assume any responsibility for any loss or damage incurred in shipping. Any repair work on our products by unauthorized third parties voids any warranty.

FCC Statement

The changes or modifications not expressly approved by the party responsible for compliance could void the user's

authority to operate the equipment.

User Information

This device complies with part 15 of FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

To comply with FCC RF exposure requirement, this device and its antenna must be co-located or operating in the conjunction with any other antenna or transmitter.