

ENGLISH

## QUICK USER GUIDE

[www.hyperkin.com](http://www.hyperkin.com)

© 2019 Hyperkin Inc. Hyperkin® is a registered trademark of Hyperkin Inc. Super NES® is a registered trademark of Nintendo® of America Inc. Bluetooth® is a registered trademark of Bluetooth Sig, Inc. This product is not designed, manufactured, sponsored, endorsed, or licensed by Nintendo® of America Inc. nor Bluetooth Sig, Inc. in the United States and/or other countries. All rights reserved. Patent Pending. Made in China.

### BEFORE YOU BEGIN

- The CONTROLLER BUTTON is located on the very top
- The CONTROLLER LED INDICATOR is located on the face.
- The MICRO CHARGE PORT is located on the very top

### Charging Your Product

1. Connect the provided MICRO CHARGE CABLE to your product. Connect the other end to a USB power source.
2. A solid RED light on the CONTROLLER LED INDICATOR indicates the Product is charging.
3. The RED light will turn off when the product is fully charged.

Note: You can use the product even while it is charging.

4. A slowly flashing RED light on the CONTROLLER LED INDICATOR means the product is low on battery.

### Helpful Hints

- The Product can operate up to about 30 feet from your SNES console.
- After 5 minutes of no activity, the Product will go to SLEEP.
- If the Product is ON and not synced, the CONTROLLER LED INDICATOR will slowly flash BLUE for 20 seconds, then go to SLEEP.
- The Product will automatically connect after the initial syncing.

When connecting to a BT-compatible device such as a computer or smartphone, the controller will show up as "Input device (keyboard, mouse, etc.)" while pairing. Once paired, the controller will be listed as "Hyperkin Pad." Setup and functionality may vary depending on your device.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF exposure compliance statement:

This device has been evaluated to meet the general RF exposure requirement, it can be used in portable exposure condition without restriction.