i-rocks™

X-Slim 2.4GHz Cordless Keyboard

Manual

**Quick Installation Guide**

RF-6570

Welcome

Welcome to join the i-rocks™ cordless world. The i-rocks™ RF-6570 wireless keyboard and optical mouse combo uses the latest 2.4GHz ISM RF technology to provide you with extended range and flawless communication between the keyboard, mouse, and your computer.

Four automatically selected channels eliminate any possible interference when this keyboard and mouse combo is used around other RF devices. The 2.4GHz ISM RF Digital Radio technology allows the RF-6570 to stay connected to the devices in up to a 15M radius.

The 2.4GHz wireless communication link operates in the 2400 - 2483 MHz frequency band available unlicensed world wide for Industrial, Scientific and Medical (ISM) applications. For users that demand the highest performance, quality, and convenience, the RF-6570 keyboard and mouse combo is a perfect choice.

Package Contents

· Wireless keyboard X 1
· Wireless optical mouse X 1
· Receiver X 1
  (mini receiver stores in the mouse body.)
· AAA size alkaline batteries X 2
· AA size alkaline batteries X 2
· Travel pouch X 1
· Quick installation guide X 1

Hardware Installation

1. Connect the USB mini receiver to your computer by plugging in the receiver connector into your PC USB port.

2. **Set up the Keyboard**
   Take the keyboard and make sure the 2 x AA alkaline batteries on the back are installed correctly, replace battery door.

   (Follow the polarity signs in the battery compartment.)

---

4. ID setting process in keyboard, mouse and the receiver.

5. Press keyboard "ESC" key of the keyboard to make sure the connection.
   (This process must be completed within a few press seconds and within 50cm of its receiver the steps will need to be repeated.)

6. Turn on mouse. The red sensor display light representative power on can work.
   (When not in use, turn mouse off to save batteries.)

7. Press mouse left button of the mouse to make sure the connection.
   (This process must be completed within a few press seconds and within 50cm of its receiver the steps will need to be repeated.)

8. If the mouse or keyboard doesn't work properly, please reset of your computer or re-plug in the receiver into your computer.

9. Please fellow 3 to step 7.

---

10. Enjoy using your keyboard and mouse.

Troubleshooting

Keyboard or mouse does not work!

1. Check the mini receiver connections.

2. Follow the ID setting process.

3. **Battery Warning:** Remove batteries when not using your cordless device for long period of them Change batteries immediately when prompted by keyboard LED blinks red when battery is low or mouse scroll wheel glow red another if the cursor on your screen does not move or move erratically when you move your mouse.

4. Increase the distance between the mouse's receiver and the base units of other wireless devices.

---

5. Turn off any wireless devices and their base units that are near the RF-6570 receiver.

6. If you are using the RF Keyboard or mouse on a metal surface, move it and the receiver to a non-metal surface. Metals, such as iron, aluminum or copper, shield the radio frequency transmission and may slow down the keyboard or mouse's response time or cause the keyboard or mouse to fail temporarily.

System Requirements

· Microsoft® Windows® 98SE, Windows® ME, Windows® 2000 or Windows® XP operating system.
· Microsoft® Internet Explorer 5.0 or later version.
· USB port

All product names are trademarks or registered trademarks of their respective owners. Microsoft®, Windows® and Windows® logo are trademarks or registered trademarks of Microsoft® Corporation in the United Stated and /or other countries.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pur-suant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is en-couraged to try to correct the interference by one of the following measures:

◎Reorient or relocate the receiving antenna.
◎Increase the separation between the equipment and receiver.
◎Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
◎Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example – use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.