

## Cordless 2.4GHz **Keyboard and Mouse Kit**



Quick Installation Guid

## IRK15RP

## Cordless 2.4GHz Keyboard and Mouse Kit US 1-1 Cordless 2.4GHz Keyboard and Mouse Kit US 1-2

## Specification

- · Key number: 104 Keys(By language)
- · Battery : AAA X 2 PCS

## · Interface : Wireless 2.4GHz

· Interface : USB

Package Contents

- · AAA size alkaline batteries X 4 · USB Dongle Receiver X 1
- Quick installation guide X 1

## System Requirement

 Microsoft system Windows<sup>®</sup> 8 / Windows<sup>®</sup> 7 / Windows Vista<sup>®</sup> Windows® XP or later

SB Keyboard and Optical Mouse Kit

Congratulations on your purchase of a Cybernet IRK15RP, The IRK15RP

wireless keyboard and optical mouse combo uses the latest 2.4GHz RF

technology to provide you with extended range and flawless communication

between the keyboard, mouse, and your computer. It provides users the

highest performance, quality, and convenience. The IRK15RP keyboard

and mouse combo is a perfect choice in your digital life.



Cordinas 2.460); Replacett and Muses K 9999







- · Interface : Wireless 2.4GHz
- · Num Lock / Caps Lock / Battery low indicator
- · Battery Life: Up to 12 Months(4hrs/day) · Effective Distance: About 10 M
- Dimension: 456(L) x 173(W) x 16(H) mm

- - · Kev number : 6 kevs Resolution: 800 / 1200 / 1600 DPI(Optical).
  - Battery low indicator
  - · Power ON/OFF switch
  - · Battery Life: Up to 6 Months(4hrs/day)
  - · Effective Distance: About 10 M.
  - · Battery : AAA X 2 PCS Dimension: 106.0(L) x 68.0(W) x 39.5(H) mm

Dimension: About 19.1(L) x 14.65(W) x 6.1(H) mm

- Available USB Port





# Product Information


· Keyboard's LED Battery low.

Kevboard's Hot Kev

Caps · Indicate the Caps lock state Num · Indicate the Num lock states.

Function keys

144



Cordless 2.4GHz Keyboard and Mouse Kit US 1-3



unction description
Backward
Forward
top Browse the web
Refresh the web
Previous track
Volume down


## Cordless 2.4GHz Keyboard and Mouse Kit US 1-4

Mute
Play/Pause
Stop
Volume up
Next track
Web Browser
E-Mail
֡֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜֜

## DPI Resolution Exchange (800/1200/1600 DPI)

- · Press DPI exchange button to change the resolution in a cycle.
- · LED will flash to show the status of the resolution after pressing DPI exchange button.
- · When turn off the power of mouse it will resume 800 DPI.
- DPI Resolution : 800 → 1200 → 1600
- LED Flash Time : One → Two → Three


## DPI exchange button




## Cordless 2.4GHz Keyboard and Mouse Kit US 1-5

## Hardware Installation I. Set up the Keyboard (Put provided batteries into keyboard's batteries housing)

Take the keyboard and make sure the 2 x AAA alkaline batteries on the back are installed correctly, replace battery door, (Follow the polarity sign in the battery compartment.)



- 2. Set up the Mouse (Put provided batteries into mouse's batteries housing.)
- · Open the battery housing cover under the cordless mouse's bottom side.
  - Install the provided batteries into the battery housing. (Please follow the polarity signs in the battery housing.)
  - · Close the mouse battery housing cover



## Cordless 2.4GHz Keyboard and Mouse Kit US 1-6


## Turn on the power switch on the back of keyboard.

Connect the USB mini receiver to your computer by plugging in the receive

connector into your PC USB port, wait until automatic installation has

3. Easy automatic wireless connection :

4. Ready to use.



## 2. Unplug and Plug again the USB dongle receiver into your computer's

Cordless 2.4GHz Keyboard and Mouse Kit US 1-7

3. Waiting for the USB plug and play initialization completed.

## 4. For mouse ID setting:

Unplug the USB donale then plug in the USB receiver, turn on the power. press Mouse's "Middle Button" & "Right Button" and hold about 5 seconds

## 5. For keyboard ID setting :

ID Setting

- Unplug the USB dongle then plug in the USB receiver, turn on the power Press Kevboard's "Esc" key & "K" key and hold about 5 seconds
- 6. Ready to use
- 7. Step 4 and 5 should be finished in 15 seconds If the mouse or keyboard doesn't work properly, please remove the USB dongle receiver from computer's USB port, then repeat do step 4 or 5 step again.

## What do I do if the cordless mouse or keyboard does not work?

Cordless 2.4GHz Keyboard and Mouse Kit US 1-8

- · Check the USB dongle receiver is connected to your computer's USB
- and keyboard. (The positive (+) and negative (-) ends of each battery must match the polarity signs in the battery housing)
- Make sure the batteries power qualities are good for use.
- Make sure the ID Setting process is well completed.

Make sure the batteries are correctly installed into your cordless mouse

- · Please change batteries immediately when the cordless mouse battery low LED glow red or the cursor on screen does not move or move erratically
- Please change batteries immediately when the cordless keyboard. mouse battery low indicator light up.
- · Warning: Please remove batteries from your cordless mouse when not using for a long period of time.
- · Wireless performance: Metal object close to or in between the device. (Please remove objects.)
- Mouse will have reduced tracking performance on very shiny or transparent

## Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class E

digital device, pur-suant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

This equipment generates, uses and can radiated ra-dio frequency energy and, if no installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will no occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipme

Cordless 2.4GHz Keyboard and Mouse Kit

off and on, the user is en-couraged to try to correct the interference by one of the

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

©Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

©Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modification not expressly approved by the party responsible for compliance could void the user authority to operate this equipment.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two condi-tions:

(1) This device may not cause harmful interference, and(2) this device must accept

any inter-ference received, including interference that may cause undesired operation