



Trio[®] Activity Tracker

PE961 model

User Manual

Package contents

The product contains the following items:

- **Trio[®] Activity Tracker**



- **Strap**




- **Clip**



- **USB Key**



- **USB Charger**



Trio[®] Tracker layout



Charging the Trio[®]

1. Snap in the Trio[®] Tracker to the USB charger. Please follow (a) and (b) procedures.



(a)



(b)

2. After being snapped in, plug the end of the USB cable into the USB port of your PC.



Attaching Trio[®] to the clip

In attaching the Trio[®] to the clip, locate the “arrow” sign of the clip and the Trio[®] Tracker as this is your guide so that it will fit accordingly. See example images.




(a) Top View



(b) Rear View

Attaching Trio[®] to the strap

In attaching the Trio[®] to the strap, locate the “arrow” sign of the strap and the Trio[®] Tracker as this is your guide so that it will fit accordingly. See example image.



Detaching Trio® from the Clip or Strap



To remove the Trio® Activity Tracker from the Strap, locate the Trio® logo facing inwards, and then push both edge of the Tracker.

To remove the Trio® Activity Tracker from the clip, locate the letter “ T “ of the Trio® logo and then on the left side facing inwards, push both edge of the Tracker.

Setting up Trio® Tracker

If you haven't activated your Trio® yet, or you need to replace it:

1. Tap your Trio® Activity Tracker to wake it up for the first time.
2. Plug the wireless USB key into your computer.
3. Download and install the Trio syncing software.

To download the Trio® application to your Android/iOS smartphone or tablets, visit first the [Compatible Devices](#) page.

Wearing

To calculate your movement accurately, wear the Trio[®] Tracker close to your body.

- Using the Clip



**in your pocket
(pants or shirt)**



**clipped to your
belt or waistband**



**clipped to your
bra strap**

- Using the Strap



Syncing

To sync the Trio[®] with your computer, you have to download and install the sync app from our website and then you need to plug in the USB key. Please refer to this [link](#). (*Note: You need to login first before downloading the application.*)

The Trio[®] will sync automatically throughout the day if your computer is on, the USB key is plugged in, and the Trio is within 20 feet range from the computer.

To sync your Trio[®] manually:

1. Launch the application.
2. Wait for the message “Insert a USB key to sync your Trio”.
3. Once displayed, insert/plug-in the USB key.
4. Wait for the message “Ready to sync”.
5. Using your Trio[®] tracker, go to “**SYNC**” screen then **press** and **hold** any of the touch sensors for at least 3 seconds. (*Note: There’s a syncing animation after pressing any of the touch sensors.*)
6. Wait until the syncing is completed.

You can also sync with our mobile sync app using Android/iOS smartphones and tablets that have the Bluetooth 4.0 or Bluetooth Low Energy (BLE) capability.

Specifications

Type	Description
General	
Type	Wearable / clip-on
Tracking metrics	Motion / Steps, Calories, Distance
Processor	nRF-51822
Memory	2Mb
Water Resistance	3 ATM
Power	
Rechargeable battery	Yes
Battery life	Approx. 7-10 days
Battery charging time	Approx. 30 – 60 minutes
Syncing and connectivity	
Syncing type	Wireless (Bluetooth Low Energy)
Display	
Screen resolution	128 x 36 mm
Screen type	OLED

FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

WARNING Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the body is W/kg.