

CB526 Pocket Director Call Box

The CB526 is a mini director call box designed for pocket or clip-on use. The 4-membrane switch assembly is designed without a reset button and is intended to be carried by store employees desiring to trigger messages from various locations within the store.

The CB526 call box has a single assurance LED, it will flash for ¼-sec when a button is pressed.



Programming the CB526:

If at any point during the programming sequence 30 seconds expire without a button being pressed, the address programming mode will be exited and the previously programmed address will continue to be used. The assurance LED will flash 5 times to indicate that mode programming has been exited.

1. Press and hold button 2 for 5 seconds. The assurance LED will flash once.
2. Press and hold button 1 for 5 seconds. The assurance LED will flash twice.
3. Press and hold button 2 for 5 seconds. The assurance LED will flash three times.
4. Press button 1 once.
5. Press button 2 once, the assurance LED will flash once.
You are now in Address Programming Mode.
6. To program the hundreds value, press button one 1-9 times.
7. Press button two, one time to save the hundreds value.
8. To program the tens value, press button one 1-9 times.
9. Press button two, one time to save the tens value.
10. To program the ones value, press button one 1-9 times.
11. Press button two, one time to save the ones value.

The assurance LED will now flash back the address that was programmed.

NOTE: To program the number zero ("0") do not press button 1, instead, press 2.
During the flash back sequence, the LED indicates a zero by staying on longer.

FCC Notice of Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Class B statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.