

Getting Started Guide







welcome

Congratulations on your new phone purchase.

This guide will help you to quickly come up to speed on the important features of your phone.

Keep in mind your phone has:

- Fast Processor: Featuring the Intel® Atom™ processor
 1.2GHz that enables fast web browsing, super-responsive apps, and effortless multi-tasking, so that enjoying the things you love to do has never been easier.
- Intelligent Camera: Featuring an advanced 5MP HD camera that lets you capture images quickly - up to 7 photos a second - so you'll never miss the best shot, even in challenging environments.




 Dual-SIM Functionality: Featuring two SIM card slots, so you will never miss a call again. Just plug in your SIM cards and decide which one to use as you go - no need to switch off your phone or change cards in and out.

NOTE: Screen images and icons are simulated for the purpose of this guide. Actual displays may vary. Instructions in this guide may change depending on the software version on your device.





your phone - front view














your phone - back view














insert battery, SIM cards & SD card

Turn phone over and locate slot on bottom.

Pull up on slot to remove back cover.

Insert card(s) according to diagram.

Insert battery with arrow pointing to top of phone.



TIP: Data can be enabled on only one SIM card at a time. The slot labelled SIM 1 is the default position for data usage.


TIP: For additional media storage, insert an SD card.







charge the battery



NOTE: For optimal charging, please use the USB cable and charger provided with the phone.








turn the phone on and off

Hold down the power button to turn the phone on.

Hold down the power button, then touch **Power off** to turn the phone off.





sleep / lock / wake

When the power is on, and you want to put the phone in sleep mode, press the power button.

When the phone is in sleep mode, and you want to wake the phone, press the power button to bring up the unlock screen.

unlock phone / camera

Unlock your phone by dragging the circle lock to the right.

Launch the Camera app by dragging the circle lock to the left.



TIP: For extra protection, set a security lock. Press System settings Security Screen lock.





home screen & apps



TIP: To move an icon, touch and hold it, then drag the icon to a new location.









status & notifications

The Status bar shows your phone's status and notifications. The Notification panel is your centre for new events—like new email, voicemail, updates, and more.



NOTE: Select services are displayed across the top of the Notification panel (Wi-Fi, Bluetooth, GPS, Account sync, and Display Brightness). Touch an icon to turn that service ON or OFF. Services that are ON are illuminated and have a blue bar beneath them.





Page: 9

















calling & texting

Incoming calls



Place a call





3. Touch to place your call.

Set a ringtone

- 1. From the Home screen, press , then touch System settings - Sound - Phone ringtone.
- 2. Touch a ringtone to hear it. Touch OK to select it.

Send a text

1. From the Home screen, touch



2. Touch 3. Enter a recipient's name.

4. Touch the Enter text field and enter a message.

Touch to send your message.







using dual SIM cards

Set 2G or 3G network

- Choose a tab at the top of the page (SIM 1 or SIM 2), then touch Use only 2G networks.

Change data SIM settings:

- 1. From the Home screen, touch
- 2. Touch to launch the SimConfig app.
- At the bottom of the screen, 1 (by default) is blue and displays APPS. Touch 2 to use SIM 2 for data.



Place a call

- 1. From the Home screen, touch
- Dial a phone number using the dial pad.
- Touch either or to particular SIM card.

 to place your call using that particular SIM card.

Send a text

- 1. From the Home screen, touch
 - h 😕

- 2. Touch
- 3. Enter a recipient's name.
- 4. Touch the Enter text field and enter a message.
- Touch either SIM 1 Send or SIM 2 Send to send your message using that particular SIM card.





wireless connections

Connect to Wi-Fi

- From the Home screen, press System settings.
- 2. If Wi-Fi is OFF, touch OFF to toggle it on.
- 3. Touch Wi-Fi. The available networks display.
- 4. Touch a network, then touch Connect.

Pair Phone with Bluetooth Device

- From the Home screen, press System settings.
- 2. If Bluetooth is OFF, touch OFF to toggle it on.
- Touch Bluetooth. The available Bluetooth wireless technology-enabled products display.
- 4. Select the product you wish to pair.
- Confirm the product number and touch Pair to pair the product. Once paired, your phone will automatically connect with the product.









camera & video

Take a picture

- in your apps. 1. Touch
- Frame your subject in the camera.
- 3. Touch the Shutter button to take your picture and save the image to the Gallery.

For Burst mode, touch MODE, and then touch the Shutter button to take a series of pictures and save the images to the Gallery.

Shoot a video

- 1. From the Camera app, touch the Mode button, and then select the camcorder.
- 2. Touch the Shutter button to begin recording. When done, press the Shutter button again to stop recording and save the video to the Gallery.

Share a photo

- 1. From the Home screen, touch then touch
- 2. Touch an album to open it, then touch the picture you want to share.
- Touch in the upper right corner.
- 4. Touch an application for sending the photo (such as Gmail to email the photo, or Messaging to send the photo via text messaging).





safety, regulatory & legal

SAFETY AND OPERATIONAL GUIDELINES

IMPORTANT: Please review and adhere to these simple guidelines. Failure to do so may be dangerous or illegal. All statements, information and recommendations contained herein do not constitute a warranty of any kind, either expressed or implied. The information contained herein is subject to change without notice. Please read the complete user guide for further information.

- Always comply with all local legal requirements or restrictions when using the phone, for example, in airplanes, gas or petrol stations, in hospitals, or while driving.
- Elements of the phone are made of glass, and may break or become scratched if dropped or used improperly. You may be able to reduce the chances of any such harm by utilizing a case for your phone.
- As with any electronic device, please keep your phone away from any water including, for example, rain, wash basins or toilets.
- Do not attempt to repair or modify your phone yourself. This includes any access to or attempted replacement of the battery. Any attempt to do so will invalidate your warranty and regulatory approvals.
- Your mobile phone may be equipped with Global Positioning System (GPS) or Assisted GPS (AGPS) technology, which may be used to determine the approximate location of the mobile phone. When connected to a wireless network, the phone may transmit location-based information including to third-party application providers. Please read your using manual and check the settings of any installed applications to ensure that you manage these location based services in accordance with your privacy preferences.
- Mobile phones can interfere with the functioning of medical devices such as hearing aids or pacemakers. Keep at least 20 cm (9 inches) between the phone and pacemaker. When using the mobile phone hold it to the ear which is furthest away from the pacemaker. For more information, consult your doctor.
- Always keep the phone and accessories out of reach of small children.
 Small parts such as the SIM card and SIM card eject tool can be dismantled and swallowed by small children.
- Keep the phone away from electromagnetic data carriers such as credit cards, disk drives, etc. Information stored on them could be lost.







- Permanent hearing loss may occur if you use earphones or headphones at high volume. You can adapt over time to a higher volume, which may sound normal but can be damaging to your hearing. Set your volume to a safe level. If you experience discomfort or buzzing in your ears, reduce the volume or discontinue use of your earphones or headphones.
- Ring tones, info tones and hands-free talking are reproduced through the loudspeaker. Do not hold the phone to the ear when it rings or when you have switched on the handsfree function. Otherwise you risk serious permanent damage to your hearing.
- Please use only the power supply that was supplied with your phone.
 Failure to do so may damage the phone. The power supply must be plugged into an easily accessible AC mains power socket when charging the battery. The only way to turn off the charging device after charging the battery is to unplus it.
- You must not open the battery or battery cover under any circumstances. All other changes to this device are strictly prohibited and will invalidate the warranty and regulatory approvals.
- The phone may cause interference in the vicinity of television sets, radios, computers and other electronic components.
- Dispose of unwanted batteries and phones in accordance with local law.
- Improper use of the device will invalidate the warranty! These safety instructions also apply to original accessories.
- Do not store the phone or any of its accessories on or near an automotive air bag, or air bag deployment area.
- Some people may be susceptible to blackouts, seizures or debilitating headaches when exposed to bright, flashing light such as, for example, when playing video games or watching other video content on the device. If you have experienced such medical issues in the past, please consult your physician before engaging in such activity on this device.
- Please take care not to use your device in potentially explosive environments such as, for example, fueling stations, fueling areas, fuel or chemical storage facilities, or areas where the air may contain chemical or dust particles such as grain particles or metal powders.
- The repetitive motion of certain actions, such as pressing keys or other repetitive finger motions, may cause discomfort in your hands, wrists, arms, shoulders, neck and other parts of your body. If you experience any such discomfort, please discontinue such actions until you have had an opportunity to consult with your physician.
- · Connect only to USB interfaces with USB 2.0 version or higher.






- This phone includes a radio transmitter and receiver to transmit and receive, respectively, electromagnetic energy operating at various radio frequencies (RF energy). The device is designed to operate within local regulatory requirements concerning the exposure of this RF energy to human beings. Nonetheless, however you use your phone, you should keep the phone 15mm away from your body to limit your exposure to RF energy.
- When using a wireless hands-free system (headphone or headset), please use a device with a low-power Bluetooth emitter.
- Please try to limit the length of your calls or send a text message instead. This is particularly relevant to children, adolescents, and those who are or may be pregnant.
- · Please use the device when the signal quality is good.
- People with active medical implants should keep the mobile phone preferably at least 15cm away from the implant.

NOTE: The operating temperature for this device is 0C to 45C; ensure the operating temperature for the adapter is not higher than 35C.



In-Box Contents:

- Handset
- AC Adapter
 USB Cable
- Headset



CE Additional Warnings and DoC Information

Hereby, Intel Corporation declares that this mobile phone is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

The Declaration of Conformity may be obtained from:

Intel Corporation
2200 Mission College Blvd
SC1-20
Santa Clara, CA 95054 USA
Attn: Product Certification Manager









"To prevent possible hearing damage, do not listen at high volume levels for long periods."

FCC Statements

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:



- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Information (SAR):

This mobile phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless mobile phones employs a








unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. *Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output.

While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement. Equipment Authorization has been granted to this model with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of www.fcc. gov/oet/ea/fccid after searching on FCC ID: O2Z-BTXZ0.



GOVERNMENT OF INDIA DEPT. OF

TELECOMMUNICATIONS RF EXPOSURE (SAR) The maximum reported SAR VALUE of this device is:

The maximum reported SAR VALUE of this device is: 1.54W/kg per 1gram of tissue.











Notice

The information contained herein is subject to change without notice. All statements, information and recommendations contained herein do not constitute a warranty of any kind, either expressed or implied. Please review this product guide thoroughly, with particular attention paid to any safety sections, to make sure that you use your phone safely.

Copyright © 2011-2012 Intel Corporation. All rights reserved. This publication is protected by copyright. No part of the

publication may be used, reproduced, or translated, in any form, without the prior written consent of Intel Corporation.

Intel, Intel Atom, Intel Inside, and the Intel Inside logo are trademarks of Intel Corporation in the U.S. and/or other countries.

Google, Gmail, Google Maps, YouTube, Google Calendar, Android, and Android Market are trademarks of Google, Inc. Use of these trademarks is subject to Google's permission.

*Other names and brands may be claimed as the property of others.

