

**Model: iSB-5001**

# Instruction manual

We take this opportunity to thank you for purchasing the i-ON iSB-5001 Bluetooth Speaker. We strongly suggest that you study these operating instructions carefully. Before attempting to operate the unit, and that you note all the listed precautions.

## CONTENTS

<b>SAFETY INSTRUCTIONS</b>	<b>PAGE 2</b>
<b>INTRODUCTION</b>	<b>PAGE 3</b>
<b>CONTENTS</b>	<b>PAGE 3</b>
<b>SPECIFICATIONS</b>	<b>PAGE 3</b>
<b>USING iSB-5001</b>	<b>PAGE 4</b>
<b>TROUBLESHOOTING GUIDE</b>	<b>PAGE 5</b>
<b>CARE &amp; MAINTENANCE</b>	<b>PAGE 6</b>



## SAFETY INSTRUCTIONS

- FOR HOUSEHOLD AND INDOOR USE ONLY
- PLACE THE APPLIANCE ON A FLAT, STABLE SURFACE WITH ADEQUATE VENTILATION AND AWAY FROM OTHER SOURCES OF HEAT. MINIMUM DISTANCES AROUND THE APPLIANCE FOR ADEQUATE VENTILATION IS 10CM. DO NOT COVER OR RESTRICT VENTILATION OPENINGS.
- CHILDREN SHOULD BE SUPERVISED TO ENSURE THEY DO NOT PLAY WITH THE APPLIANCE, AND THE APPLIANCE AND CABLE SHOULD BE KEPT COMPLETELY OUT OF REACH OF YOUNG CHILDREN.
- THIS APPLIANCE IS NOT DESIGNED FOR USE BY CHILDREN, OR PERSONS WITH REDUCED PHYSICAL, SENSORY OR MENTAL CAPABILITIES, AND SHOULD NOT BE USED BY SUCH PERSONS UNLESS THEY CAN DO SO SAFELY. WHERE NECESSARY, SUCH PERSONS (OR ANYONE WITH LACK OF EXPERIENCE OR KNOWLEDGE) SHOULD FIRST BE GIVEN SUPERVISION OR INSTRUCTION CONCERNING USE OF THE APPLIANCE BY A PERSON RESPONSIBLE FOR THEIR SAFETY.
- FULLY UNWIND THE CABLE BEFORE PLUGGING IN AND ENSURE THE CABLE IS POSITIONED AWAY FROM AREAS WHERE IT IS LIKELY TO GET DAMAGED OR CAUSE A TRIP HAZARD.
- THE OUTPUT CORD OF THIS MAINS ADAPTOR CANNOT BE REPLACED. IN THE EVENT OF DAMAGE TO THE CABLE, JACK PLUG OR ADAPTOR, THE ENTIRE ADAPTOR UNIT SHOULD BE REPLACED.
- CONNECTIONS MUST ONLY BE MADE VIA THE MAINS ADAPTOR SUPPLIED, NEVER CONNECT THE APPLIANCE DIRECTLY TO THE 240V MAINS SUPPLY.
- NEVER USE THE ADAPTER SUPPLIED WITH ANY OTHER APPLIANCE.
- THE MAINS ADAPTOR WILL BECOME WARM IN USE; DO NOT COVER OR PLACE ON OR NEAR SURFACES THAT COULD BE AFFECTED BY HEAT SUCH AS TABLE TOPS AND CARPETS.
- DO NOT PULL ON CABLE TO DISCONNECT FROM MAINS SUPPLY.
- KEEP APPLIANCE, CABLE, MAINS ADAPTOR PLUG DRY AND AWAY FROM AREAS WHERE IT IS LIKELY TO GET SPLASHED. AVOID USING IN HOT, HUMID ENVIRONMENTS.
- DO NOT PLACE ITEMS WITH NAKED FLAMES OR CONTAINERS WITH LIQUIDS ON THIS APPLIANCE.
- SWITCH OFF AND UNPLUG WHEN NOT IN USE AND BEFORE CLEANING OR SERVICING THE APPLIANCE.
- SERVICING OF THIS APPLIANCE MUST ONLY BE CARRIED OUT BY A QUALIFIED ELECTRICIAN. SERVICING IS REQUIRED WHEN THE APPARATUS HAS BEEN DAMAGED IN ANY WAY: SUCH AS LIQUID HAS BEEN SPILLED OR OBJECTS HAVE FALLEN INTO THE APPARATUS; THE APPARATUS HAS BEEN EXPOSED TO RAIN OR MOISTURE, DOES NOT OPERATE NORMALLY, OR HAS BEEN DROPPED- DO NOT ATTEMPT TO SERVICE THIS PRODUCT YOURSELF.
- OPENING OR REMOVING COVERS MAY EXPOSE YOU TO DANGEROUS VOLTAGES OR OTHER HAZARDS.
- TO PREVENT RISK OF FIRE OR ELECTRIC SHOCK, AVOID OVERLOADING WALL OUTLETS, EXTENSION CORDS, OR INTEGRAL CONVENIENCE RECEPTACLES
- ALWAYS ENSURE THE MAINS ADAPTOR PLUG IS READILY UNPLUGGABLE – DO NOT USE WITH 'LOCKABLE' SOCKETS OR PERMANENTLY WIRE TO MAINS.



The lightning flash with arrow-head symbol, within an equilateral triangle, is intended to alert the user to the presence of un-insulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

### CAUTION

**RISK OF ELECTRIC SHOCK  
DO NOT OPEN**

WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The exclamation point within an equilateral triangle is intended to alert the user to presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance

## INTRODUCTOIN

The i-ON iSB-5001 is a universal wireless portable speaker that works with your iPod, iPhone & iPad or any Bluetooth devices. It is a compact and powerful speaker lets you enjoy your music anytime and anywhere.

### CONTENTS:

- 1 x iSB-5001,
- 1 x User manual,
- 1 x Micro USB Power Cable,
- 1 x Audio cable

## SPECIFICATIONS

- Compatible with all wireless Bluetooth devices
- On-to-go design is perfect for travel
- Bluetooth Range Up to 33' (10 m)
- Speaker Output: 4W
- Battery Capacity: 1000mAh
- Playback Time Up to 5 Hours
- Battery Charge Time: 2 Hours
- Line-in port with included audio cable
- Bluetooth Support: A2DP (Wireless Stereo Bluetooth)
- Dimension: 5.2 x 1.8 x 1.8 in (131.5 x 46.5 x46.5 mm)
- Operating Temperature: 14 to 131 °F (-10 to 55 °C)

## USING iSB-5001

### Charging the Unit

- Connect the micro USB plug to the micro USB charging port on the back of the unit.
- Connect the standard USB plug end of the cable to a power USB port on a computer or other USB charging device. For first time use, charge unit for about 3 hours.
- A red light glows steadily while the unit is charging and turns OFF once the unit is fully charged.
- If unit is not powered on when micro USB plug is connected, the red light glows steadily to indicate unit is charging.
- For best sound performance, only operate the unit when fully charged.

### Using Bluetooth: Pairing Your Device

For First Time use (auto pairing):

- Turn on your Bluetooth-enabled device and turn on Bluetooth capability as described in the device's user manual.

- Move the Power ON/OFF Switch on the unit to the ON position (right). The first time the unit is turned on it will enter auto pairing mode, indicated by a rapidly flashing blue light. "isb-5001" should appear on your device's menu. If "Not Paired", "Not Connected" or similar message appears, tap on "iSB-5001" to complete pairing.
- Once paired with a device, the blue light will glow steadily. There should be an indication on your device that pairing is complete ("Connected" or similar). On some devices, you must then select "Use as Audio Device" or similar on the device's Bluetooth menu. Once paired, your device should auto-link to the iSB-5001 whenever within range (about 30 feet). If auto pairing did not work, press and hold the Bluetooth Pairing Button located on the back of the unit for 2 seconds to retry pairing.

Once the Unit Has Paired with A Device (auto linking):

- When the unit has been paired with a device, the next time it is powered on, the unit will turn on in auto link mode and attempt to auto link to a previously paired device, indicated by a slowly flashing blue light. If a linked device is found, the indicator will glow solid blue.
- If no linked device is found, the blue light will continue to flash slowly. Press and hold the Bluetooth Pairing Button located on the back of the unit for 2 seconds. The unit will enter pairing mode, 2 short beeps will sound and the light will flash blue rapidly while the unit attempts to pair.

### **Playing Audio Via Bluetooth**

- Move the Power ON/OFF Switch to the ON position (right) to listen to audio streamed wirelessly from your paired iPad, iPhone, iPod or other Bluetooth device. The blue light will flash as the unit searches for a previously paired device, and then turn solid blue once a previously paired device is detected.
- Use the controls on your device to play or pause audio, navigate tracks and control volume from your Bluetooth device.
- When done listening, move the Power ON/OFF Switch to the OFF position (left) to turn the unit off.
- NOTE: Aux-in audio is disabled when Bluetooth audio is playing from a different device.

### **Playing Audio via Aux In**

- Connect the included 3.5 mm audio plug to the headphone or line-out jack on your audio device and the other end into the Aux-in Jack on the back of the unit.
- Move the Power ON/OFF Switch to the ON position (right) to listen to audio via aux in. The indicator light will flash blue.
- Power on the audio device and use the controls on the device to play or pause audio, navigate tracks and control volume. If your audio device is already paired with the unit, the light will glow steadily blue as in Bluetooth mode, but you will hear your audio via aux-in.
- When done listening, move the Power ON/OFF Switch to the OFF position (left) to turn the unit off. Remember to turn off your audio device, too.

### **Playing Audio via Aux Out**

- You can connect the unit to an external speaker via the Aux-out jack located on the back of the unit to expand the audio playing in Bluetooth or Aux-In modes.
- Connect a 3.5 mm audio cable plug to the Aux- out jack on back of the unit and connect the other end to the line-in jack on your external speaker.
- Move the Power ON/OFF Switch to the ON position (right).
- Power on a Bluetooth or aux-in audio device and use the controls on the device to play or pause audio, navigate tracks and control volume.

- When done listening, move the Power ON/OFF Switch to the OFF position (left) to turn the unit off. Remember to turn off your audio device, too.

## **TROUBLESHOOTING GUIDE**

### **Unit doesn't respond (no power)**

- Make sure unit is completely charged.
- Check that all connections are correct and properly plugged in.
- Make sure your device is properly paired with the iSB-5001.
- Make sure the Power ON/OFF Switch switch is not in the OFF (left) position.

### **Resetting the Unit**

- If the unit is "frozen" or locks up, you may wish to reset it. To do so, turn the unit ON and press the end of paperclip or similar into the reset port on the back of the unit for less than 2 seconds to reset it without clearing Bluetooth settings. The unit will reset and power back on. (If pressed for longer than 2 seconds, the unit will reset but will not power back on.)
- To reset Bluetooth settings, turn unit ON then press and hold the Bluetooth Pairing Button on the back of the unit for 8 seconds. The light will flash red rapidly and a tone will sound. You will then need to re-pair any previously linked devices.

### **Trouble pairing device/computer with iSB-5001**

- Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing.
- Make sure you have the latest firmware for your device.
- Make sure your device is working properly. Check your device's manual for details on Bluetooth pairing and linking.

## **CARE AND MAINTENANCE**

- Ensure the unit is switched off and unplugged from any electrical outlet
- Wipe the case with a slightly moist, lint-free cloth.
- Do not use any cleaning fluids containing alcohol, ammonia or abrasives.
- Do not spray an aerosol at or near the radio.
- Do not allow liquids to spill or objects to drop into any openings.
- Always use original packaging if it is necessary to transport the unit at any time.

If this unit is used in a dusty environment, it may be necessary to have the unit serviced at your local dealer periodically. It is not advisable to allow large deposits of dust to accumulate within the unit as it may prevent adequate cooling. Similarly dust deposits which become damp can sometimes lead to electrical problems which may cause severe damage to the delicate electronics within this unit.

## WEEE marking



“Information for the Consumers”



Disposal of your old product

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused. When this crossed out wheeled bin symbol is attached to a product it means the product is covered by the European directive 2002/96/EC.

Please make yourself aware of the local collection system for electrical and electronic products. Please act according to your local rules and do not dispose of your old product with your normal household waste. The correct disposal of your old product will help prevent potential negative consequences for the environment and human health.



This product complies with European low voltage ( 2006/95/EC )  
And electromagnetic compatibility ( 2004/108/EC ) directives.

**FCC Warning:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.