


Instruction Manual

47-1004F, 47-1004G & 47-1004H

REMOTE CONTROL INSTALLATION

1. Locate and connect the input and output terminals to the correct terminals.



Output Terminal #1: 300W (Incandescent Lamp)

Output Terminal #2: 1200W (Resistive Load)

Output Terminal #3: 1200W (Resistive Load)

Remark: The total max. output for Terminal #2 & #3 is 1200W.

REMOTE CONTROL

The remote control has a range of approximately 50 ft. (15.25m), it does not have to be pointed the fireplace and can pass through most obstacles (including walls). It is supplied with one of 2187 independent frequencies to prevent interference with other units. The frequency designation is indicated on the back of the transmitter.

A. Remote Control Initialization

This procedure is required every time there is a loss of power to the remote control with the receiver. (i.e. power failure, breaker tripped, main power switch is turned off).

1. Ensure that power is supplied through the receiver.
2. Locate manual controls (Blue, “ - ”), (Grey “ + ”) and (Black “ GND ”) Wires
3. Activate main power switch, red indicator light 1 will flash.
4. Press and hold the ON switch (short Grey & Black wires) for 5 seconds. The second red indicator light will flash.
5. Press ON button located on the remote control transmitter. This will synchronize the remote control transmitter and receiver.

B. Remote Control Usage

The remote control operates the system levels sequentially. The level is increased every time the ON button on the transmitter is pressed. The receiver can be turned off at any point by pressing the OFF button on the remote control transmitter.

Remark: Output Terminal #1: Indicator #1 (Red wire)
 Output Terminal #2: Indicator #2 (Orange wire)
 Output Terminal #3: Indicator #3 (Yellow wire)

C. Manual Control

The fireplace can also be controlled in a similar manner to the remote control with switches located on the receiver.

1. On Switch (short Grey & Black wires)
Operates receiver in the same manner as the remote control transmitter. Pressing this button has the same effect as the ON button on the remote control. Pressing once to the activates Level 1, twice activates Level 2, three times activates Level 3.
2. Off Switch (short Blue & Black wires)
Pressing this button has the same effect as the OFF button on the remote control. Pressing once to shut the unit off.

WARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Specifications

Input Rating.....	AC 120V, 60Hz
Output Rating.....	AC 120V, 60Hz
Resistive Load.....	1200W
Incandescent Lamp.....	300W
Operation Temperature.....	0 - 40°C
Storage Temperature	-25 - 60°C