

# Owner's Manual

## WIRELESS REMOTE SWITCH

MODEL: 47-1010A-T

FCC ID: ELY547-47-1010A-T      IC1492A-471010AT  
FCC ID: ELY547-47-1010R      IC 1492A-471010R

The WIRELESS REMOTE SWITCH for use with all electric appliances from your easy chair or bedside. Safe and convenient with simple plug-in installation.

### Instructions:

1. Connect the AC Input wires to an AC 120V Power Source. (During connecting, make sure there is no AC power.)
2. Connect the Output Wires to the Input wires of the controlled device.
3. Install a 12 volt. battery into the transmitter.
4. Turn appliance ON, then control the appliance by simply pressing the ON or OFF button of the transmitter.

### Note:

1. Main switch of the electric appliance must be in the *ON* position prior to using the Remote Control.
2. Wireless Remote Switch works up to 50''(15.4m) away.
3. Wireless Remote Switch may be used to control most other electrical devices including T.V.s, stereos and lamps.

### CAUTION

1. For indoor use in dry areas only.
2. For use on electrical devices with 15amp resistive load or max Power 1000W inductive load.
3. 120 volt AC supply.

## WARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## Specifications

|                            |                   |
|----------------------------|-------------------|
| Input Rating.....          | AC 120V, 60Hz     |
| Output Rating.....         | AC 120V, 60Hz     |
| Resistive Load.....        | 15A               |
| Motor Load.....            | 1/3HP             |
| Incandescent Lamp.....     | 500W              |
| T.V.....                   | 400W              |
| Operation Temperature..... | 0 - 40°C          |
| Storage Temperature .....  | -25 - 60°C        |
| Safety Standard .....      | ETL/cETL          |
| Dimensions .....           | 99 x 67 x 53 (mm) |
| Weight .....               | 125 (g)           |